

AD _____

COOPERATIVE AGREEMENT NUMBER: DAMD17-95-2-5008

TITLE: Effect of Sub-Lethal Organic and Metallic Toxicant
Concentrations on Neurological Biomarkers of Neonates

PRINCIPAL INVESTIGATOR: James T. Blankemeyer, Ph.D.

CONTRACTING ORGANIZATION: Oklahoma State University
Stillwater, Oklahoma 74078-0266

REPORT DATE: May 1996

TYPE OF REPORT: Final

PREPARED FOR: Commander
U.S. Army Medical Research and Materiel Command
Fort Detrick, Frederick, Maryland 21702-5012

DISTRIBUTION STATEMENT: Approved for public release;
distribution unlimited

The views, opinions and/or findings contained in this report are those of the author(s) and should not be construed as an official Department of the Army position, policy or decision unless so designated by other documentation.

19970908 052

REPORT DOCUMENTATION PAGE

Form Approved

OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.

1. AGENCY USE ONLY (Leave blank)

2. REPORT DATE

May 1996

3. REPORT TYPE AND DATES COVERED

Final (7 Apr 95 - 6 Apr 96)

4. TITLE AND SUBTITLE

Effect of Sub-Lethal Organic and Metallic Toxicant
Concentrations on Neurological Biomarkers of Neonates

5. FUNDING NUMBERS

DAMD17-95-2-5008

6. AUTHOR(S)

James T. Blankemeyer, Ph.D.

7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES)

Oklahoma State University
Stillwater, Oklahoma 74078-0266

8. PERFORMING ORGANIZATION
REPORT NUMBER

9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)

Commander
U.S. Army Medical Research and Materiel Command
Fort Detrick, Frederick, Maryland 21702-5012

10. SPONSORING/MONITORING
AGENCY REPORT NUMBER

11. SUPPLEMENTARY NOTES

12a. DISTRIBUTION / AVAILABILITY STATEMENT

Approved for public release; distribution unlimited

12b. DISTRIBUTION CODE

13. ABSTRACT (Maximum 200)

Exposure of humans to lethal or clearly harmful levels of toxicants is straightforward to assess. Counting the number of survivors or enumerating injuries provides an accurate, repeatable method for assessing toxicant effect. However, chronic exposure to very low levels of toxicants is much more problematic. Effects to very low levels of toxicants often produces effects temporally separate from exposure and not linkable in a cause and effect relationship. Our study probed the relationship between low levels of toxicants and neurological responses. After exploratory assays of various neurotoxic chemicals, we used trimethyltin to assess neurological damage to embryos, the most sensitive stage of the life cycle. We found that we were able to detect these low levels of trimethyltin by video image analysis of neural fields using the electrochromic dye Di-4-ANEPPS. We also used analysis of retrograde transport of scrape-loaded tracer dye through neurons. We found that there was no detectable difference in the neuronal paths traced by the tracer dye.

DTIC QUALITY INSPECTED A

14. SUBJECT TERMS

Toxicology, neurotoxicology, chronic exposure, fluorescent
dye, membrane potential, Di-4-ANEPPS, FluoroGold

15. NUMBER OF PAGES

289

16. PRICE CODE

17. SECURITY CLASSIFICATION
OF REPORT

Unclassified

18. SECURITY CLASSIFICATION
OF THIS PAGE

Unclassified

19. SECURITY CLASSIFICATION
OF ABSTRACT

Unclassified

20. LIMITATION OF ABSTRACT

Unlimited

FOREWORD

Opinions, interpretations, conclusions and recommendations are those of the author and are not necessarily endorsed by the US Army.

Where copyrighted material is quoted, permission has been obtained to use such material.

Where material from documents designated for limited distribution is quoted, permission has been obtained to use the material.

STB Citations of commercial organizations and trade names in this report do not constitute an official Department of Army endorsement or approval of the products or services of these organizations.

STB In conducting research using animals, the investigator(s) adhered to the "Guide for the Care and Use of Laboratory Animals," prepared by the Committee on Care and Use of Laboratory Animals of the Institute of Laboratory Resources, National Research Council (NIH Publication No. 86-23, Revised 1985).

For the protection of human subjects, the investigator(s) adhered to policies of applicable Federal Law 45 CFR 46.

In conducting research utilizing recombinant DNA technology, the investigator(s) adhered to current guidelines promulgated by the National Institutes of Health.

In the conduct of research utilizing recombinant DNA, the investigator(s) adhered to the NIH Guidelines for Research Involving Recombinant DNA Molecules.

In the conduct of research involving hazardous organisms, the investigator(s) adhered to the CDC-NIH Guide for Biosafety in Microbiological and Biomedical Laboratories.

Dr. Blum May 6, 1996
PI - Signature Date

Table of Contents

Front Cover.....	1
SF298, Report documentation Page.....	2
Foreword.....	3
Table of Contents.....	4
Executive Summary.....	8
Title Page.....	9
Literature Review.....	10
Hypothesis/Objectives.....	15
Methods.....	16
Statement of Work.....	22
Acronym/Symbol Definitions.....	23
Results.....	24
Figures and Tables.....	40
Photomicrographs.....	80
Conclusions.....	116
Bibliography.....	117
Data records (Appendix).....	126

Figures, Tables and Pictures (micrographs)

All following experiments were performed with frog embryos. F indicates a figure, T indicates a table, and P indicates a photomicrograph.

<u>Figure</u>	<u>Description</u>	<u>Page</u>
F5	Effect of α -chaconine (fluorescence--positive control)	40
T1	Naphthalene survival	41
T2	Kainic acid survival (1)	42
T3	Kainic acid survival (2)	43
T4	Kainic acid survival (3)	44
T5	Colchicine survival (1)	45
T6	Colchicine survival (2)	46
T7	Colchicine survival (3)	47
F6	Fluorescence assay of naphthalene effect (1)	48
F7	Fluorescence assay of naphthalene effect (2)	49
F8	Fluorescence assay of kainic acid effect	50
F9	Fluorescence assay of colchicine effect	51
T8	Vinblastine Survival Data	52
T9	Vinblastine Survival Data	53
F10	Fluorescence Assay of Vinblastine Effect	54
F11	Fluorescence Assay of Vinblastine Effect	55
F12	Fluorescence Assay of α -Chaconine Effect	56
F13	Fluorescence Assay of Mimosine Effect	57
T10	Mimosine Survival Data	58
T11	Albizzia Survival Data	59
F14	Fluorescence Assay of Glycine Effect	60
F15	Fluorescence Assay of Glutamate Effect	61
F16	Fluorescence Assay of Homocysteic Acid Effect	62
T12	List of low α -chaconine effects	63
T13	TCAOB & TCAB Survival Data	64
T14	Acrylamide Survival Data	65
F17	Fluorescence Assay of Acrylamide Effect	66
T15	α -Chaconine Survival Data	67
T16	TCAOB & TCAB Survival Data	68
T17	Acrylamide Survival Data	69
T18	Trimethyltin Survival Data	70
T19	Trimethyltin Survival Data	71
T20	Trimethyltin Survival Data	72
F18	Fluorescence Assay of Trimethyltin Effect	73
T21	Trimethyltin Survival Data	74
T22	Trimethyltin Survival Data	75
T23	Trimethyltin Survival Data	76
F19	Fluorescence Assay of Trimethyltin Effect	77
T24	TCAOB & TCAB Survival Data	78
F20	Glycoalkaloid structures	79

<u>Figure</u>	<u>Description</u>	<u>Page</u>	
P1	Fluorescence Micrograph 1 of α -Chaconine Effect	80	
P2	Fluorescence Micrograph 2 of α -Chaconine	81	Effect
P3	Fluorescence Micrograph 3 of α -Chaconine Effect	82	
P4	Fluorescence Micrograph 4 of α -Chaconine Effect	83	
P5	Fluorescence Micrograph 5 of α -Chaconine Effect	84	
P6	Fluorescence Micrograph 6 of α -Chaconine Effect	85	
P7	Fluorescence Micrograph 7 of α -Chaconine Effect	86	
P8	Fluorescence Micrograph 8 of α -Chaconine Effect	87	
P9	Fluorescence Micrograph 9 of α -Chaconine	88	Effect
P10	Fluorescence Micrograph 10 of α -Chaconine	89	Effect
P11	Fluorescence Micrograph 11 of α -Chaconine Effect	90	
P12	Fluorescence Micrograph 12 of α -Chaconine Effect	91	
P13	Fluorescence Micrograph 13 of Trimethyltin Effect	92	
P14	Fluorescence Micrograph 14 of Trimethyltin Effect	93	
P15	Fluorescence Micrograph 15 of Trimethyltin Effect	94	
P16	Fluorescence Micrograph 16 of Trimethyltin Effect	95	
P17	Fluorescence Micrograph 17 of Trimethyltin Effect	96	
P18	Fluorescence Micrograph 18 of Trimethyltin Effect	97	
P19	Fluorescence Micrograph 19 of Trimethyltin Effect	98	
P20	Fluorescence Micrograph 20 of Trimethyltin Effect	99	
P21	Fluorescence Micrograph 21 of Trimethyltin Effect	100	
P22	Fluorescence Micrograph 22 of Trimethyltin Effects	101	
P23	Fluorescence/Light Micrograph 23 of Fluro-Gold	102	
P24	Fluorescence/Light Micrograph 24 of Fluro-Gold	103	
P25	Fluorescence/Light Micrograph 25 of Fluro-Gold	104	
P26	Fluorescence/Light Micrograph 26 of Fluro-Gold	105	
P27	Fluorescence/Light Micrograph 27 of Fluro-Gold	106	

<u>Figure</u>	<u>Description</u>	<u>Page</u>
P28	Fluorescence/Light Micrograph 28 of Fluro-Gold	107
P29	Fluorescence/Light Micrograph 29 of Fluro-Gold	108
P30	Fluorescence/Light Micrograph 30 of Fluro-Gold	109
P31	Fluorescence/Light Micrograph 31 of Fluro-Gold	110
P32	Fluorescence/Light Micrograph 32 of Fluro-Gold	111
P33	Fluorescence/Light Micrograph 33 of Fluro-Gold	112
P34	Fluorescence/Light Micrograph 34 of Fluro-Gold	113
P35	Fluorescence/Light Micrograph 35 of Fluro-Gold	114
P36	Fluorescence/Light Micrograph 36 of Fluro-Gold	115

Executive Summary

A principal concern of toxicology whether it be mammalian, vertebrate, or environmental is and will continue to be the effect of low, sub-lethal, concentrations of toxicants on organisms. One effect of low-level toxicants is on neural properties. That is, low levels of naphthalene do not kill aquatic organisms but do alter behavior. We used frog tadpoles to evaluate the effect of low toxicant levels on neurophysiology.

An existing bioassay was extended into neural and neurological analysis. FETAX (Frog Embryo Teratogenesis Assay:Xenopus) was published by Dumont in the early eighties (1) and extended and validated by Bantle, Dawson, and Fort (2). FETAX uses embryos from a fully aquatic frog, *Xenopus laevis*, as a model for vertebrate and mammalian development. The endpoints normally associated with FETAX are percent lethality, percent malformation, percent control growth, and minimum concentration to inhibit growth. To better model the mammalian embryonic environment, a Metabolic Activation System was included in the assay with promising results(3).

CHAWQ (Cell Health Assay of Water Quality) was developed in the late eighties by Blankemeyer as a cellular assay which uses a suite of cellular biomarkers to establish the mode and mechanism of action of toxicity(4). The cellular biomarkers are:

- Membrane potential(5,6)
- Cellular calcium (7,8)
- Cell necrosis (8)
- Cellular pH (8,9)
- DNA quantity/environment(8,10)

CHAWQ uses *Xenopus* embryos, usually in the small cell blastula stage(11), so that the cellular biomarkers can be interpreted in terms of FETAX endpoints. Other stages of frog embryos can and have been used as well as *Daphnia*, minnows, and mammalian muscle and erythrocytes.

Final Technical Report
for U.S. Army Biomedical Research Development Lab
Contract #DAMD17-95-2-5008
submitted by

Oklahoma State University

James T. Blankemeyer
Department of Microbiology and Molecular Genetics
207 LSW
Stillwater, OK 74078
405-744-9688
JTBLANK@OKWAY.OKSTATE.EDU

Literature Review

During the course of this contract we investigated the properties and effect on embryos of several neurotoxic chemicals. A brief review of those chemicals follows:

Acrylamide

Acrylamide (2-propenamide), a benzene derivative, is a widely used industrial chemical in water treatment, construction, and oil recovery and is widely used in as a polymer in biological research. The monomer is clearly toxic to humans, with rapid skin absorption accompanied by symptoms of ataxia, numbness of limbs, fatigue, and eye and skin irritation (20).

One of the neurological modes of action is the reduction of conduction velocity. In one set of experiments, subcutaneously injected acrylamide (at 0.35 mM/kg) reduced sciatic nerve conduction velocity and subsequent paralysis of hindlimbs in six weeks in Wistar rats. Weight of soleus and plantaris muscles was reduced at this dosage level but not at the high dosage level (31).

Dose-dependent acrylamide modes of action are also suggested in human exposure although the data has been extrapolated from the usual rat models. Behavioral endpoints including grip and acoustic startle reflex were assessed under a dose vs. time paradigm. Results suggested that "behavioral endpoints showed both qualitative and quantitative changes as a result of dose rate". (27)

Mechanism of action studies employing cell lines showed that acrylamide altered the gross morphology and induced neurofilament accumulation in PC12 cells, a pheochromocytoma cell line. Acrylamide also regulated the neurofilament synthesis via the mRNA of three neurofilament subunit genes but not via NGF. Dexamethasone antagonized acrylamide induced neurofilament synthesis. These studies suggest there is a dexamethasone-sensitive step common to NGF and acrylamide mechanisms of action.(30)

These results show why acrylamide is a widely used model for rat autonomic neuropathy and may be important in development of neurophysiological biomarkers with meaningful endpoints. (Costa) The dose-dependent mechanisms apparently operating in acrylamide toxicity are probably representative of complex mechanisms underlying apparently simple modes of action. (29) and has been adopted as a standard method of producing neuropathology in rat models.

ALBIZZIA

Albizzia is probably one or more of the Julibrosides, isolated from the stem bark of the silktree, *Albizzia julibrissin*. We were unable to locate any specific references to toxicity although there is considerable interest in bio-ameliorative effects (#2).

Colchicine

Colchicine, an alkaloid from *Colchicum autumnale*, is a tool in cell biology that inhibits the doubling of chromosomes by interfering with microtubular assembly and organization during late anaphase/telophase. The same mechanism apparently operates to alter anterograde or retrograde transport in axons thus inhibiting movement of vital materials from/to the soma or cell body (20).

Cochicine is toxic to mice at doses of 3.5 mg/kg i.v. There have been attempts to use colchicine as an antineoplastic drug and as an anti-cirrhotic; these form the bulk of the literature save the use of colchicine as a molecular probe in cell biology.(20)

When rats with CCl₄ induced cirrhosis were treated with colchicine and trimethylcolchicinic acid (a colchicine derivative) significantly reversed liver disease markers suggesting that the effect on cirrhotic livers was mechanistically based. (39). Similar studies using colchicine with lactosimated serum albumin suggest that the combination was more effective than colchicine alone and that the morphological effect of the colchicine was to reduce fibrotic activity.(43)

Glutamate

Glutamate has neurotoxic effects characteristic of the excitatory amino acids (EAA) and a wide range of other effects including altering the metabolism of ischemic cardiac cells and antiproliferative activities in rheumatoid cell culture models (see 44-49).

Glycine

Glycine, as is glutamate, evokes significant interest as a member of the EAA group, a set of amino acids that have interesting properties, generally associated with agonist or antagonist properties of the NMDA (N-methyl-D-aspartate) effects. Current interest is in motor activity in relationship to PCP (53)

and the glycine site in the NMDA complex (54).

Glycoalkaloids

Solanaceous plants, including crops such as potatoes, tomatoes, and eggplant as well as the toxic weeds black nightshade and jimsonweed, and tobacco, synthesize secondary plant metabolites during growth and post-harvest storage and processing. Glycoalkaloids are secondary plant metabolites in potatoes whereas the primary glycoalkaloid in tomatoes is tomatine (1). In commercial potato cultivars, the primary glycoalkaloids are α -chaconine and α -solanine, present in approximately equal amounts (2). These glycoalkaloids have similar structures except for the differences in carbohydrate side chains. For example, α -chaconine has a glucose-rhamnose side chain whereas α -solanine has a galactose-glucose-rhamnose side chain. Glycoalkaloids are present in highest concentrations when the potato or tomato is green, or damaged, or stored potatoes (3). That is, a section of a potato that is green will have a higher concentration of glycoalkaloids than a nearby white portion of the potato. Mishandling or poor storage increases the concentration of glycoalkaloids. We can infer that the glycoalkaloids evolved as a plant defense mechanism against herbivores and are probably toxic (4).

TOXIC EFFECTS OF GLYCOALKALOIDS

Potato glycoalkaloids are implicated in human toxicity. A surprisingly low level of potato glycoalkaloids, ca. 5 mg/kg, is lethal to humans(5). α -Chaconine is linked to spinal defects in mammalian embryos such as *spina bifida* (5). *Spina bifida* occurs at a frequency of 5 per 1000 live births(6). Analysis of miscarried pregnancies shows that the frequency of *spina bifida* per conceptions is ca. 20 per 1000 (6). Consumption of potatoes by humans results in significant serum levels of glycoalkaloids and glycoalkaloid by-products (6,7). Of the many animal models exposed to the glycoalkaloids, hamsters are the most sensitive to glycoalkaloids and mimic suspected human sensitivity to glycoalkaloids (8). While mammals are clearly affected by glycoalkaloid toxicity, many studies have employed non-mammalian models to increase sample size and ease of experimental manipulation. For example, frog embryos are affected in two clear modes: [1] high concentrations of glycoalkaloids (2 mg/L) are embryo-lethal; [2] lower concentrations (ca. 0.1 mg/L) are teratogenic (2). Some of the malformations observed upon exposure to α -chaconine are anencephaly, lack of neural tube closure, or other spinal defect, pathologies very similar to those demonstrated in glycoalkaloid toxicity to mammals. Since glycoalkaloids produce similar spinal failures in frogs as in

humans, frogs are a reasonable model for studying interactions of toxicants with development.

BENEFICIAL EFFECTS OF GLYCOALKALOIDS

Besides the well-established toxicity of the glycoalkaloids to vertebrates, glycoalkaloids are also quite toxic to fungal growth (). Solasodine glycosides have been suggested as anti-cancer agents ().

EFFECT OF FOLIC ACID ON NEURAL TUBE PATHOLOGY

Folic acid has been linked to the prevention of human spinal defects by strong epidemiological evidence (12). In the membrane potential assay with frog embryos, folic acid reduces the toxicity of the glycoalkaloids when membrane potential is used to measure toxicity (see Preliminary Data). Data linking glycoalkaloids with membrane potential changes suggests that the mechanism of action is a specific effect on cell membranes.

KAINIC ACID (KAINATE)

Kainic acid is normally associated with epileptic seizures, occurring after administration to mammals. When the brains of these animals or when kainic acid is directly injected or otherwise positioned near brain tissue, a lesion occurs with a clear cause and effect relationship. It is usually associated with the class of excitatory amino acids or EAA's. Typical of EAA associated activity is N-methyl-D-aspartate or NMDA (see 56-60).

MIMOSINE

Mimosine is a toxic non-protein amino acid that is a major constituent of the tropical legumes *Leucaena* and *Mimosa*. Mimosine causes acute and chronic toxicosis in livestock ingesting those legumes. In cell culture trials, mimosine blocked DNA synthesis when applied at pharmacological levels (0.4 mM)(62). At least in this system mimosine has a mechanism of action consistent with iron chelation since the DNA synthesis inhibition was reversed by addition of excess iron sulfate.

NAPHTHALENE

We have worked extensively with naphthalene in our lab, using it as a model "oil field" pollutant to test the response of organisms, including frogs and daphnia, to field doses of naphthalene (13). Naphthalene is an oil byproduct that has many industrial uses as well as being an insecticide.

TRIMETHYLTIN

Trimethyl tin is an organometal chemical that produces selective lesions in hippocampal pyramidal cells in both neonate and learning dysfunction in adult rats (67,68).

VINBLASTINE

Vinblastine, a vinca alkaloid, is an antineoplastic drug that strongly affects the assembly of microtubules and thus alters neural anterograde transport and other cellular, microtubule dependent, processes (20). The antineoplastic activity of vinblastine is probably due to a reduction in blood flow to the tumor (73).

HYPOTHESIS

Hypothesis: Measurement of neurological endpoints will extend FETAX assay and correlate effects of sub-lethal concentrations of toxicants with measures of neurotoxicity.

Technical Objectives:

- 1 To determine whether the test chemicals affect neural development and neural properties, we will qualitatively and quantitatively measure tadpole neuron location as well as neuronal properties.
- 2 To establish the relevance of the neurological endpoints, we will use a conventional bioassay and a cellular bioassay in conjunction with the neurological assays. Conjointly assaying the chemicals permits direct comparison of results using matched pair statistics.
- 3 Accomplishment of these Technical Objectives will result in experimental paradigms, protocols and biological endpoints for integrated bioassessment.

METHODS

FETAX DESCRIPTION

FETAX (Frog Embryo Teratogenesis Assay: *Xenopus*) uses South African clawed frog embryos in assessing survival, growth, and malformation as endpoints in a four-day assay (2). Use of the embryonic stage of the organism probably exposes the most sensitive stage of the life-cycle to the toxicant. Use of the multiple endpoints enables detection of multiple effects of toxicants (2). FETAX has been evaluated with over sixty chemicals, is established as an ASTM standard (2), and is now undergoing inter-lab validation. The copious amount of data existing for FETAX makes validation of the membrane potential and other CHAWQ (Cell Health Assay of Water Quality) biomarkers realistic since there is a 96 hour FETAX response available for most of the chemicals. Dr. Jack Bantle, who is responsible for standardizing FETAX and responsible for its worldwide reputation, is the co-P.I. on this proposal. The CHAWQ assay (4,8), using a suite of cellular biomarkers, developed to assess the cellular mode and mechanism of toxicity, uses the same breeding and embryo selection protocol as the FETAX assay.

CHAWQ DESCRIPTION

CHAWQ (Cell Health Assay of Water Quality), developed by me over the last four years, uses blastula stage embryos is to rapidly assess the quality of water and to determine the mode and mechanism of action of toxicants. The rationale behind CHAWQ is that long-term deleterious effects on cells exposed to water will be reflected in short-term alterations of cellular biomarkers. CHAWQ uses 30 embryos per replicate and takes about thirty minutes to perform. CHAWQ evaluates principal indicators of cellular health by using non-invasive optical transducers of cellular biomarkers (8). The CHAWQ assay has been used to evaluate the toxicity of potato glycoalkaloids (4) and been calibrated for membrane potential response using valinomycin and gramicidin as known modifiers of membrane permeability (5). The calibration study showed that an increase in dye fluorescence is correlated with a depolarization of the negative cell membrane potential towards zero. An ASTM monograph as well as other publications (4,5,8) delineates the instrumentation, biomarkers, and shows a CHAWQ can be used to discriminate mode and mechanism of action. Lastly, a patent application and is in review for the use of the technique on *Daphnia* as a rapid replacement for the four and seven-day *Daphnia* survival and reproduction assays for water quality.

The extension of the bioassays into neural analysis was

suggested by the studies of Kandel and collaborators on *Aplysia*. Kandel (see 18 for instance) showed, in an impressive series of experiments, that conditioning of the siphon withdrawal reflex in *Aplysia* was associated with a demonstrable change in the dendritic structure surrounding the identified interneurons. The simplicity of the *Aplysia* neural network aided in the analysis; however similar techniques can be applied to vertebrates with respect for the limitations imposed by smaller neuronal size and complex neural architecture of vertebrates.

We employed naive and pre-exposed tadpoles in our analysis of behavior. We will use the tadpoles surviving the FETAX and CHAWQ assays as experimental subjects for the neurological assays. We will use the control tadpoles from FETAX and CHAWQ as naive tadpoles for our neurological studies. We will use exposed tadpoles as pre-exposed tadpoles in the neurological studies.

D.4.1 CHAWQ INSTRUMENT

Figure 1 is a schematic layout of the instrumental portion of the CHAWQ instrument. The light from a xenon short-arc lamp (not shown) enters two monochromators (MONO1 and MONO2). The monochromators have mechanically operated slits and electro-mechanical monochromator drives (not shown). The light outputs of the monochromators are combined by an optical chopper into a single beam containing the two wavelengths from the monochromators.




Figure 1. Schematic diagram of CHAWQ instrumentation

The combined beam is split into two beams by a beam splitter (BEAM SPLITTER). One beam goes through a sample chamber (S); the other passes through the reference chamber (R). The sample chamber consists of 3 mm quartz microcuvette mounted inside a baffled aluminum sample box (see Figure 2 for details). Inside the sample chamber (the microcuvette) are the test embryos. The combined light beam is used to obtain fluorescence data from both the sample and reference organisms (eg. frog embryos). The beam excites the electrochromic dye Di-4-ANEPPS which has been pre-loaded into the embryos. Di-4-ANEPPS fluoresces proportionally to the membrane potential. The fluorescent emission is measured by counting the photons passing through the emission monochromators (MONO3 and MONO4). The counting is accomplished by photon-counting the output from photomultiplier tubes (PMT) and transferring the count rate to an instrumentation package.

Figure 2 is a detailed representation of the sample chamber portion of CHAWQ. That is, the boxes labeled R and S in Figure 1 are drawn in Figure 2 in detail. In Figure 2, light enters the sample chamber from the left of the figure and is focused onto the central box which contains a 3 mm quartz microcuvette. Baffles (drawn but not labelled) prevent the light from being inadvertently scattered into the emission monochromator.

The light entering the microcuvette excites the embryos containing electrochromic dye Di-4-ANEPPS (or other fluorescent dye). The emission from the dye-loaded embryos exits at a 90 ° angle to the excitation light. The emission from the embryos is captured and focused onto a monochromator (not shown) which is attached to the exit port.




Figure 2. Side and Top View of Sample Chamber

Figure 3 describes the loading process used to place the embryos in the 3 mm quartz cuvette in Figure 2. The blastula-stage embryos are loaded into the cuvette by drawing the embryos into a widened, fire-polished pipette. The embryos are then carefully dropped out of the pipette into the 3 mm cuvette, previously filled with FETAX solution (16). A separate pipette, attached to a vacuum line, is used to draw off excess FETAX solution. Since the embryos have less than neutral buoyant density in FETAX solution, the embryos slowly sink to the bottom and stack vertically. The entire process of loading and reading the sample with the CHAWQ instrument takes less than two minutes. Since the exposure time in the cuvette is so short, no stirring or temperature control has been required.

VIDEO IMAGE ANALYSIS BIOASSAY

To answer some of the questions raised in this proposal, we will morphologically analyze the activity and location of neural

pathways in the tadpoles. The absence of pigment in the albino *Xenopus* tadpole makes the tadpole an excellent experimental subject for this assay. We will, using the same Di-4-ANEPPS dye as used in the CHAWQ assay, identify single neurons and bundles by differences in membrane potential between the neurons and the surrounding tissue. The neurons have a resting potential of ca. -70 millivolts while the tissue has a typical membrane potential of -30 millivolts. In preliminary experiments we have been able to analyze moto-neurons against the background of muscle.

We will use the dye to assess location of particular neurons. We expect to identify vagal, brachial, and femoral bundles. We will assess the membrane potential, using the Di-4-ANEPPS dye, firing rate, and anatomical location using the image processor setup described for the avoidance-preference and swimming bioassay. We will use a multichannel image intensifier to acquire the faint images from the neurons.





Figure 3. Embryo Loading Protocol

NEURONAL PATTERN ANALYSIS

We will evaluate the neural pathways using neuronal tracing techniques. There are a variety of neuronal tracers available commercially. These include: Lucifer Yellow, Cascade Blue, and the CellTracker series from Molecular Probes. We plan to use these dyes in anterograde and retrograde tracing. These dyes are injected into the cells by the following means:

Iontophoretic injection or pressure injection- Dye is loaded into a micropipette and injected into a particular neuron. In vertebrates the problem is in identifying the neuron prior to injection. Once the dye is injected, the dye diffuses through the



axon and is localized through fluorescence image analysis.

Ablation of a neural field or scrape loading relies on a broad-brush loading of neurons by severing the neurons at a particular point, then following the course of the dye diffusion by fluorescence analysis.

DYE/MICROELECTRODE DESCRIPTION

Microelectrode experiments were carried out using a setup schematicized in Figure 4 as modified for this project. The microelectrode is mounted in a mechanical micromanipulator mounted on the microscope stage. The microelectrode is "pulled" from borosilicate glass using an ISA or Narashige horizontal microelectrode puller. These pullers usually make electrodes in the 10 megohm range with steep tapers and concentric tips. The electrodes are backfilled with KCl solution and tip-filled through capillary action from the fluorogold solution.

Embryos were placed in dishes of FETAX and allowed to grow for 48+ hours. An embryo was chosen from the group and anesthetized. An injection of Fluro-gold was given into the eye of the embryo. The amount of 73.6 nl was measured by the Nanoject pump. The embryo was then placed into a dish of FETAX.

Embryos developed for another 96+ hours. At this point, they were anesthetized and formalined. The specimens were prepared for sectioning by placing them on a metal block already frozen in liquid nitrogen) and dropping water around La provide an adhesion to the surface. - The block was then Placed into the liquid nitrogen until the water Was completely frozen. The Cryostat was cooled to -20 degrees C. The block was then placed into the holder and 20 micron sections were obtained. They were placed sequentially onto a slide for viewing. The sections were viewed with a fluorescence microscope. A blue/green 420K blocking filter was used. Photos were taken with a 40X objective and 5X photo eyepiece.

ANIMAL CARE

PROTOCOL

Adult albino *Xenopus laevis* pairs were kept in aquaria and periodically mated to produce fertilized eggs. These embryos are the experimental subjects for the proposed research. All embryos are terminated at the end of the experiments (typically 96 hours after fertilization).

Adult pairs are bred about every six weeks. HCG (human chorionic gonadotropin) is injected into the *Xenopus laevis* female and male

about 12 hours prior to the experiment. About six hours after HCG injection, the adults will perform amplexus. About 500 embryos are obtained from each mating. The embryos are de-jellied and sorted into viable and non-viable embryos. The viable embryos are then placed into petri dishes in FETAX solution. At the appropriate time, depending on the experiment, the embryos are sorted into groups of 20 and labeled as control and experimental. Chemicals and dyes are introduced into the various dishes as the particular protocol requires. Typically several groups will be designated as control and graded concentrations of toxicant will be added to multiple dishes using three groups for each concentration of chemical. At about four hours after fertilization, the assay is performed on the embryos (CHAWQ assay - see Experimental Design and Methods). The embryos were euthanized after eight hours or are maintained until 96 hours so that the FETAX measurements of length, malformation, and viability can be collected on the groups of embryos (control and experimental). After 96 hours all embryos are euthanized. Adults are kept as long as possible for breeding stock and are never used in experiments. When the adults become debilitated, diseased, or dysfunctional, they are euthanized. As far as we can understand there is no pain, distress, or discomfort to the experimental subjects (four hour embryos). Since the embryos do not have developed nervous systems at this stage we believe that there is no distress from the dyes, toxic chemicals, or measurement techniques.

Euthanasia

Embryos were terminated at 96 hours by anesthetizing embryos in 3-amino benzoic acid ethyl ester (CAS # 886-86-2) and euthanizing the embryos in a formalin solution. Adults are kept for as many breedings as possible. Diseased or dysfunctional adult frogs are euthanized also with 3-amino benzoic acid and formalin solution. This method of euthanasia is consistent with the recommendations of the Panel on Euthanasia of the American Veterinary Medical Association Panel on Euthanasia JAVMA 188 (3) : 252-268 (1986).

STATEMENT OF WORK/SUMMARY OF RESULTS

The Statement of Work was modified during the course of the study to accommodate the new exciting results uncovered by the research. We found that the excitatory amino acids (EAA) had no effect on frog embryos and thus were unsuitable candidates for further testing on the whole animal level. Then, in consultation with the CO we altered the research to include testing of trimethyl tin (TMT). TMT proved to be a potent chemical in our assay. Use of TMT permitted us to achieve the original goals of the research without major alteration in research plan or methodology. We analyzed the effects of TMT with FETAX, CHAWQ, video image analysis, and neuronal tracing. We found clear evidence that the presence of TMT causes localized changes in the membrane potential of regions of the tadpoles brain and found that the pathway of traced neurons showed little or no alteration when developing embryos were exposed to TMT.

ACRONYM/SYMBOL DEFINITION

CHAWQ Cell Health Assay of Water Quality. A cellular assay capturing cellular signals leading to toxicity.

FETAX Frog Embryo Teratogenesis Assay: *Xenopus*. A 96 hour bioassay evaluating mortality and malformation in frog embryos.

EC50 (also ED50) Concentration or dose of toxicant producing 50 % effect.

LC50 (also LD50) Concentration or dose producing 50 % mortality in a test sample.

NOEC No observable effect concentration. Concentration of toxic chemical statistically inferred to have no significant effect on organism.

LOEC Lowest observable effect concentration. Lowest concentration of toxic chemical statistically inferred to have a significant effect on organism.

BIOASSAY An assay of toxicity which depends on biological responses as compared to chemical responses.

BIOMARKER Property or characteristic of biological systems that is used as an indicator of the health of the organism.

IMAGE ANALYSIS Use of computers and computer software to evaluate and interpret digitized images.

RESULTS

At the commencement of the contract, we performed the preliminary analysis of response with the specified chemicals and additional chemicals suggested by the contract officer. We have completed preliminary analysis of the results and submit the results for your consideration. We used the following chemicals and performed developmental, growth, and cellular response tests on frog embryos using these chemicals:

α -chaconine
kainic acid
naphthalene
colchicine

Data from survival experiments (in tables) and fluorescence analysis of membrane potential (bar graphs) follow this page. Following is a synopsis of the results obtained.

As outlined in the proposal narrative, we initially used kainic acid (KA), colchicine, and variations on kainic acid to induce central nervous system pathologies. Unfortunately, the embryos neglected to cooperate. They did not respond to any concentration of KA or colchicine during the 96 hour FETAX assay or CHAWQ assay (three trials each). We detected no significant differences in survivability, growth, or behavior after high doses of KA, colchicine, and some of the KA alternatives. I realize that KA and like compounds do not cross the blood-brain barrier and are routinely iontophoretically injected. However I really expected some effect especially with doses 10x the LC50 in rodents or frogs. We did get a nice positive FETAX response to vinblastine; we are repeating this experiment. The non-response to KA and colchicine caused us to change our experimental timetable. Below is a commentary on the specific experiments.

Figure 5 is an experiment illustrating the fluorescence response from the positive control experiment (labelled PC) on all subsequent experiments. This concentration of the potato glycoalkaloid, α -chaconine, produces a large increase in fluorescence and was thus used to provide a positive control parameter for subsequent tests. α -Chaconine, at 50 mg/L, is 100 % lethal at 24 hours of exposure.

Table 1 is a survival and malformation experiment using naphthalene exposures for 96 h. Note that there was no difference in survival between the negative control and the various exposures to naphthalene. This result is consistent with previous exposure experiments.

Table 2 represents one of the exposure experiments to kainic

acid or kainate. There was no significant difference between negative control and experimental data points. The positive control, the 5 mg/L of α -chaconine, was lethal to 100 % of the embryos by the end of the second day. Table 3 and Table 4 are the results from additional trials of kainic acid. As occurred in the first trial (Table 2), there was no significant difference between negative control survival and the experimental concentrations of kainic acid.

We next used various concentrations of colchicine in survival and malformation experiments. Tables 5, 6, and 7 represent results from experiments determining the survival and malformation from concentrations of colchicine. In one trial, represented in Table 7, we saw some mortality but only at unrealistically high concentrations of colchicine.

Figure 6 represents the fluorescence response of embryos exposed to naphthalene and negative and positive controls. In this experiment there was no significant difference among the response to the negative control and the concentrations of naphthalene. Figure 7 represents an experiment with embryos that were refractile to the positive control. In subsequent experiments we discarded trials such as this one. It is included here to illustrate the acceptability of trial data.

Figure 8 represents the results of experiments wherein kainic acid was used to in a fluorescence trial using the CHAWQ protocol. Note the marked increase in fluorescence due to the positive control and that the various concentrations of kainic acid produced a fluorescence response not significantly different from the negative control.

Colchicine was used to test the response of the embryos in a trial depicted in Figure 9. In this experiment the PC produced a marked increase in fluorescence whereas the negative control results were indistinguishable from the various concentrations of colchicine.

After the disappointing results and after discussion with the contract officer, we tested compounds that had neurotoxic modes of action. Those toxic compounds included: naphthalene, α -chaconine, colchicine, methotrexate, and mimosine. Naphthalene has general neurotoxic effects unfortunately not limited to the CNS. α -chaconine has neurotoxic effects at low concentrations that are mostly restricted to the CNS. Methotrexate has developmentally neurotoxic effects on frog embryos. Mimosine has no effect on embryos survivability or growth but produce amazing behavioral changes. The tadpoles show strange swimming patterns, often swimming in circles or in a few cases always swimming upside down.

After we completed the preliminary testing, we initiated the testing of responses of the frog embryos by exposing the embryos during temporal windows of toxicant exposure and analyzing the membrane potential response by fluorescence video image processing and photographic means. We initiated retrograde neural tracing by exposing embryos to fluoro-gold and tracing neural pathways. We setup and perfected our cryostat and image analysis software. We included completed testing, not furnished with the last report, from the first quarter of the Contract and preliminary results from the second quarter of the contract. We used the following chemicals and performed developmental, growth, and cellular response tests on frog embryos using the below-mentioned chemicals:

- α -chaconine
- vinblastine
- mimosine
- glutamate
- glycine
- homocysteic acid
- albizia

Results from survival experiments (in tables) and fluorescence analysis of membrane potential (graphs) follow this preliminary page.

As previously described (above), we initially used kainic acid (KA), colchicine, and variations on kainic acid to induce central nervous system pathologies. Unfortunately, the embryos neglected to cooperate. They did not respond to any concentration of KA or colchicine during the 96 hour FETAX assay or CHAWQ assay (three trials each). We detected no significant differences in survivability, growth, or behavior after high doses of KA, colchicine, and some of the KA alternatives. These results follow. Use of some plant glycoalkaloids showed interesting toxicity (mimosine) or behavioral responses (albizia)

The non-response to KA and colchicine also caused us to change our experimental timetable and to use α -chaconine as a chemical to invoke neuropathology. Using timed exposure of embryos to low doses of α -chaconine, we were able to assess the effect on embryonic membrane potential on a regional basis and sometimes on an organ by organ basis. We include a few of the many images we have gathered. These images are captured by video image processing using hardware and software and by photographic means.

Table 8 represents the results obtained from vinblastine exposures of frog embryos. In this experiment high doses of vinblastine, 5 and 10 mg/L produced a slight effect of survival of the embryos on day 4 (96h). Significantly all of the dead embryos showed significant malformation. Table 9 presents the results of a second trial with a larger range of concentrations. Again the higher concentrations produced death and malformation. Figure 10 graphically portrays the fluorescence results from a CHAWQ assay. In this figure a slight decrease in fluorescence (meaning a hyperpolarization of the membrane potential) was observed at concentrations near that required to produce noticeable malformation/death in survival experiments. Figure 11 is a trial using higher ranges of vinblastine. Fig 12 is a low dose experiment using α -chaconine.

Figure 13 is a trial using the CHAWQ protocol of an interesting alkaloid, mimosine. We see from this figure that there is a clear membrane potential effect that is biphasic. That is low concentrations of mimosine depolarize the membrane whereas high concentrations (>15 mg/L) hyperpolarize the membrane. Table 10 represents a trial using mimosine on the 96 h survival assay. Unfortunately we had poor survival in the controls so the data is suspect. Unfortunately we were unable to obtain more mimosine to continue our study of this interesting alkaloid.

Table 11 represents experiments using the rare alkaloid abizzia on survival and malformation of embryos. Albizzia had no effect on survival or malformation but had clear effects on behavior. Upside down swimming and circling behaviors were observed in these 96h tadpoles.

Figure 14 represents the results of experiments wherein the EAA glycine was used in CHAWQ fluorescence assays. Except for some unexplained hyperpolarization at low concentrations, there was little effect on the membrane potential. Figure 15 for glutamate, another EAA, and Figure 16 for homocysteic acid.

Table 12 is the order of battle for the series of

photographs following the table. These photographs identify and report the effect of application of α -chaconine during the later developmental stages. We used the CHAWQ protocol but did not examine the embryos with fluorescence until the latter days of the trial. Subsequent experiments applied the dose of α -chaconine later (after 24h).

This next section is a pictorial view of glycoalkaloid toxicity. Embryos were exposed to Di-8-ANEPPS and low concentrations of α -chaconine.

Based on the results from the first half of the contract we employed additional chemicals suggested by the contract officer at no additional cost or expense to the Army. Also, based on comments from the Contract Officer, we delayed microinjection of KA and similar compounds into the developing embryos. We used other neurotoxicants suggested by the contract officer, eg. acrylamide, trimethyltin.

During the third quarter of the contract, we initiated the testing of responses of the frog embryos by exposing the embryos during temporal windows of toxicant exposure and analyzing the membrane potential response by fluorescence video image processing and photographic means. We concentrated on analyzing the effect of trimethyltin on the neural pathways of frog embryos. As can be viewed in our data, these efforts met with success. We were able to demonstrate changes in membrane potential patterns when trimethyl tin embryos were compared to controls. We used the following chemicals and performed developmental, growth, and cellular response tests on frog embryos using the below-mentioned chemicals:

- trimethyltin
- TCAOB & TCAB
- acrylamide

Results from survival experiments (in tables) and fluorescence analysis of membrane potential (graphs and pictures) follow.

Table 13 describes an experiment using an environmental toxicant TCAOA and TCAOB. These were generously provided by Dr. Jim Catallo. TCAO is a food derived toxic chemical with suspected neural properties (i.e. behavioral aberrations). Unfortunately the chemical is stage specific killing and malforming the embryos at the end of day 1 (24+ h). Unfortunately we had to use a very high concentration of DMSO so in this experiment we were unable to conclude that the TCAO was toxic. When we used 1 % DMSO to dissolve the TCAO, we found that the chemical was toxic but only after the embryos had reached the tadpole stage. We are still

not sure what the mechanism of toxicity is for this chemical. The 1% results are presented in Tables 16 and 24.

Acrylamide had a mild toxic effect even at high concentrations. These results are presented in Table 14 and Table 17. Figure 17 suggests there is some effect on the embryos, just not a lethal one since the effect of acrylamide is to hyperpolarize the membrane potential (lower fluorescence).

Table 15 presents a quality control experiment with our positive control. We run these periodically to insure our system is still producing the same responses as earlier trials.

Trimethyltin (TMT) was tested first at high concentrations. In Table 18, we note that all of the embryos were dead after day 2 in 10 mg/L TMT. At lower concentrations (Tables 19 - 23) all of the embryos were deformed and dead while there was almost 100% survival in the negative controls. From these experiments we infer that the EC_{50} for malformation is near 0,5 mg/L while the LC_{50} is near 7 mg/L.

Figures 18 and 19 represent a fluorescence response to trimethyltin. Note the hyperpolarization at low doses.

During the fourth quarter of the contract, we initiated the testing of embryos by analyzing the response of neural tissues to trimethyltin using to evaluation paradigms, video image analysis of living tadpoles using voltage sensitive dye and tracing of the injected dye Fluorogold through retrograde transport. In the case of the voltage sensitive dye clear changes in intensity and pattern were noted and analyzed to the level of the available equipment. We noted that certain regions of the tadpole brain were selectively illuminated upon exposure to TMT. These responses are photographically presented in the pages following this narrative. Brighter regions are interpreted as depolarization of the cell membranes in the region. The last set of pictures is a tracing of the retrograde transport of FluoroGold in a control embryos. The sections were cut on a cryostat and then photographed with UV excitation to limit background fluorescence. The tadpoles exposed to TMT showed no significant difference in pattern.

DESCRIPTION OF PHOTOMICROGRAPHS

FLUORESCENCE OF ALBINO EMBRYOS EXPOSED TO LOW CONCENTRATIONS α -CHACONINE

Photomicrograph 1: 24+ hour old embryo incubated in FETAX solution for 24 hours then di-8-Anepps for 30 min. Exposure time is 5 sec. Negative control for photomicrographs 1-6.

Photomicrograph 2: 24+ hour old embryo incubated in 0.50 mg/L α -chaconine for 24 hours then di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 3: 24+ hour old embryo incubated in 1.00 mg/L α -chaconine for 24 hours then di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 4: 24+ hour old embryo incubated in 2.50 mg/L α -chaconine for 24 hours then di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 5: 24+ hour old embryo incubated in 5.00 mg/L α -chaconine for 24 hours then di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 6: 24+ hour old embryo incubated in 10.0 mg/L α -chaconine for 24 hours then di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 7: 72+ hour old embryo incubated in FETAX solution for 48 hours then 0.25 mg/L α -chaconine for 24 hours and di-8-Anepps for 30 min. Exposure time is 5 sec. Can be used as negative control for photomicrographs 7-12.

Photomicrograph 8: 72+ hour old embryo incubated in FETAX solution for 48 hours then 0.50 mg/L α -chaconine for 24 hours and di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 9: 72+ hour old embryo incubated in FETAX solution for 48 hours then 1.00 mg/L α -chaconine for 24 hours and di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 10: 72+ hour old embryo incubated in FETAX solution for 48 hours then 2.50 mg/L α -chaconine for 24 hours and di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 11: 72+ hour old embryo incubated in FETAX solution for 48 hours then 5.00 mg/L α -chaconine for 24 hours and di-8-Anepps for 30 min. Exposure time is 5 sec.

Photomicrograph 12: 72+ hour old embryo incubated in FETAX

solution for 48 hours then 10.0 mg/L α -chaconine for 24 hours and di-8-Anepps for 30 min. Exposure time is 5 sec.

FLUORESCENCE OF ALBINO EMBRYOS EXPOSED TO LOW CONCENTRATIONS OF TRIMETHYLTIN

Photomicrograph 13: 24+ hour old embryo incubated in FETAX solution for 24 hours then in di-4-Anepps for 4 hours. Exposure time is 1 sec. Negative control for pictures 13-18.

Photomicrograph 14: 24+ hour old embryo incubated in FETAX solution for 24 hours then in 0.10 mg/L trimethyltin and di-4-Anepps for 4 hours. Exposure time is 1 sec.

Photomicrograph 15: 24+ hour old embryo incubated in FETAX solution for 24 hours then in 0.25 mg/L trimethyltin and di-4-Anepps for 4 hours. Exposure time is 1 sec.

Photomicrograph 16: 24+ hour old embryo incubated in FETAX solution for 24 hours then in 0.50 mg/L trimethyltin and di-4-Anepps for 4 hours. Exposure time is 1 sec.

Photomicrograph 17: 24+ hour old embryo incubated in FETAX solution for 24 hours then in 1.00 mg/L trimethyltin and di-4-Anepps for 4 hours. Exposure time is 1 sec.

Photomicrograph 18: 24+ hour old embryo incubated in FETAX for 27 hours and di-4-Anepps for 2.5 hours. Photo is with 5X objective and exposed for 1 sec. Negative control for photomicrographs 18-22.

Photomicrograph 19: 24+ hour old embryo incubated in 0.10 mg/L trimethyltin for 27 hours and di-4-Anepps for 2.5 hours. Photo is with 5X objective and exposed for 1 sec.

Photomicrograph 20: 24+ hour old embryo incubated in 0.25 mg/L trimethyltin for 27 hours and di-4-Anepps for 2.5 hours. Photo is with 5X objective and exposed for 1 sec.

Photomicrograph 21: 24+ hour old embryo incubated in 0.50 mg/L trimethyltin for 27 hours and di-4-Anepps for 2.5 hours. Photo is with 5X objective and exposed for 1 sec.

Photomicrograph 22: 24+ hour old embryo incubated in 1.00 mg/L trimethyltin for 27 hours and di-4-Anepps for 2.5 hours. Photo is with 5X objective and exposed for 1 sec.

Photomicrograph 23: Section 1 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure

time was 30 seconds.

Photomicrograph 24: Section 3 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 25: Section 4 and 5 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 26: Section 5 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 27: Section 11 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 28: Section 12 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 29: Section 13 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 30: Section 16 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 31: Section 20 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 32: Section 22 of negative control injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 33: Section 1 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30

seconds.

Photomicrograph 34: Section 3 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 35: Section 3 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 46: Section 4 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 37: Section 7 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 38: Section 8 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 39: Section 8 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 40: Section 13 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 41: Section 15 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 42: Section 15 of albino embryo incubated in 0.10

mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 43: Section 18 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 44: Section 27 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 45: Section 30 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 46: Section 33 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 47: Section 34 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 48: Section 35 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 49: Section 36 of albino embryo incubated in 0.10 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 50: Section 3 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30

seconds.

Photomicrograph 51: Section 4 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 52: Section 7 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 53: Section 8 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 54: Section 9 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 55: Section 10 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 56: Section 11 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 57: Section 12 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 58: Section 12 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 59: Section 12 of albino embryo incubated in 0.25

mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 60: Section 12 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 61: Section 14 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 62: Section 15 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 63: Section 16 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 64: Section 17 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 65: Section 18 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 66: Section 19 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 67: Section 19 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30

seconds.

Photomicrograph 68: Section 22 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 69: Section 23 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 70: Section 24 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 71: Section 24 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 72: Section 26 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 73: Section 27 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 74: Section 29 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 75: Section 30 of albino embryo incubated in 0.25 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 76: Section 35 of albino embryo incubated in 0.25

mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 77: Section 3 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 78: Section 3 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 79: Section 5 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 80: Section 6 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 81: Section 7 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 82: Section 7 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 83: Section 8 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 84: Section 10 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30

seconds.

Photomicrograph 85: Section 11 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 86: Section 13 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 87: Section 13 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 88: Section 13 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 89: Section 14 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 90: Section 15 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 91: Section 21 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

Photomicrograph 92: Section 29 of albino embryo incubated in 0.50 mg/L trimethyltin for 48+ hours and then injected with Fluro-Gold into the eye. Both a light micrograph and fluorescence micrograph were combined to show the area of tracing. Exposure time was 30 seconds.

alpha-Chaconine (group 2)
3/31/95 disk 178




Figure 5

(30 mg/L stock naphthalene) CONCENTRATION OF NAPHTHALENE	SURVIVAL	
	DAY 0	DAY 3
Negative control	50	45
Positive control (50mg/L a-Chaconine	50	0
2.5 mg/L Naphthalene	50	42
5.0 mg/L Naphthalene	50	42
10.0 mg/L Naphthalene	50	45
15.0 mg/L Naphthalene	50	42
30.0 mg/L Naphthalene	50	48

May 12, 1995

(50 mg/L stock kainic acid) CONCENTRATION OF KAINIC ACID	SURVIVAL				
	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
Negative control	60	58	56	55	55
Positive control (5mg/L a-Chaconin	40	28	0	0	0
0.2 ml kainic acid	60	58	58	58	58
1.0 ml kainic acid	60	58	58	58	58
2.0 ml kainic acid	60	60	58	58	58
5.0 ml kainic acid	60	56	55	53	53
10 ml kainic acid	60	59	59	59	58

May 31, 1995

50 mg/L kainic acid stock)
CONCENTRATION OF KAINIC ACID

	DAY 0	DAY 1	SURVIVAL DAY 2	DAY 3	DAY 4
negative control	50	50	49	47	47
50 mg/L kainic acid	50	50	50	50	49
25 mg/L kainic acid	50	49	48	48	48
12.5 mg/L kainic acid	50	47	47	47	47

May 31, 1995

(50 mg/L kainic acid stock) CONCENTRATION OF KAINIC ACID	SURVIVAL				
	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
negative control	50	49	49	49	48
5 mg/L kainic acid	50	50	50	50	49
2.5 mg/L kainic acid	50	50	49	49	49
1 mg/L kainic acid	50	49	48	48	47
0.5 mg/L kainic acid	50	50	48	48	47
0.25 mg/L kainic acid	50	50	49	47	47
0.125 mg/L kainic acid	50	49	47	47	46
0.05 mg/L kainic acid	50	49	47	47	47

June 1, 1995

(50 mg/L colchicine stock)		SURVIVAL				
CONCENTRATION OF COLCHICINE	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4	
ative control	50	49	48	48	48	
mg/L colchicine	50	50	50	49	49	
2.5 mg/L colchicine	50	50	50	49	49	
1 mg/L colchicine	50	50	49	49	49	
0.5 mg/L colchicine	50	50	49	49	49	
0.25 mg/L colchicine	50	50	50	49	49	
0.125 mg/L colchicine	50	50	50	50	50	
0.05 mg/L colchicine	50	50	49	49	48	

June 1, 1995

(50 mg/L colchicine stock)


CONCENTRATION OF COLCHICINE	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
negative control	100	99	98	98	9
positive control (5 mg/L alpha-Chacon	50	42	15	0	
0.2 ml colchicine	100	100	98	96	9
1 ml colchicine	100	99	94	94	9
2 ml colchicine	100	100	99	98	9
5 ml colchicine	100	100	97	96	9
10 ml colchicine	100	100	99	99	9

June 1, 1995

(50 mg/L colchicine stock)		SURVIVAL				
CONCENTRATION OF COLCHICINE	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4	
ative control	25	25	19	18	18	
sitive control (50 mg/L a-Chacon	25	25	22	21	21	
5 mg/L	25	25	18	17	17	
15 mg/L	25	25	21	19	19	
25 mg/L	25	25	22	21	19	
50 mg/L	25	0	0	0	0	


June 8, 1995

Naphthalene on Albino embryos 5/9/95 disk 180




IC = fetax solution (negative control)
 'C = 50 mg/L a-Chaconine (positive control)

Naphthalene on African embryos 5/3/95 disk 180



NC = negative control (fetus solution)
PC = positive control (50 mg/L a-Chaconine)


Kainic Acid on Albino embryos 5/26/95 disk 182



NC = negative control

PC = positive control (50mg/L a-Chaconine)

Colchicine on Albino embryos
6/8/95 disk 183



NC = negative control

PC = positive control (50 mg/L a- Chaconine)

Vinblastine on Normal Embryos

June 29, 1995		Number Survived		COMMENTS
Dish #	CONCENTRATION	DAY 0	DAY4	
15,16	Negative Control	50	46	
13,14	0.1562 mg/L	50	47	
11,12	0.3125 mg/L	50	48	
9,10	0.625 mg/L	50	46	
7,8	1.25 mg/L	50	44	
5,6	2.5 mg/L	50	45	
3,4	5.0 mg/L	50	39	all malformed
1,2	10.0 mg/L	50	37	all malformed

Vinblastine on Embryos

7/3/95

DISH #	CONCENTRATION	TOXICANT	DAY 0 (embryos per dish)	DAY 4 (96HR.) -SURVIVAL (embryos per dish)
1	10 mg/L	Vinblastine	25	16
2	10 mg/L	Vinblastine	25	21
3	5 mg/L	Vinblastine	25	16
4	5 mg/L	Vinblastine	25	23
5	2.5 mg/L	Vinblastine	25	21
6	2.5 mg/L	Vinblastine	25	23
7	1.25 mg/L	Vinblastine	25	22
8	1.25 mg/L	Vinblastine	25	22
9	0.625 mg/L	Vinblastine	25	24
10	0.625 mg/L	Vinblastine	25	22
11	0.3125 mg/L	Vinblastine	25	23
12	0.3125 mg/L	Vinblastine	25	25
13	0.1562 mg/L	Vinblastine	25	23
14	0.1562 mg/L	Vinblastine	25	24
15	Negative control	FETAX solution	25	22
16	Negative control	FETAX solution	25	24

VINBLASTINE ON ALBINO EMBRYOS
Disk 186 7/6/95




Figure 10

VINBLASTINE ON ALBINO EMBRYOS
Disk 198 9/6/95





Figure 11



MIMOSINE ON ALBINO EMBRYOS
Disk 186 7/6/95




Figure 13

Mimosine on Normal Embryos

June 7, 1995

Dish #	CONCENTRATION	TOXICANT	Number Survived			
			DAY 1	DAY 2	DAY3	DAY 4
1	Negative Control	FETAX solution	25	7	5	4
2	50 mg/L	Mimosine	25	11	9	8
3	25 mg/L	Mimosine	25	5	4	3
4	10 mg/L	Mimosine	25	9	8	7
5	5 mg/L	Mimosine	25	13	12	11
6	2.5 mg/l	Mimosine	25	21	17	16
7	Negative Control	FETAX solution	25	10	9	9
8	50 mg/L	Mimosine	25	7	7	7
9	25 mg/L	Mimosine	25	15	13	13
10	10 mg/L	Mimosine	25	9	6	6
11	5 mg/L	Mimosine	25	11	9	9
12	2.5 mg/L	Mimosine	25	8	8	8

Albizia on Normal Embryos

Albizia on Embryos

June 22, 1995

DISH #	Toxicant	Number Survived				
		Day 0	Day 1	Day 2	Day 3	Day 4
1	Negative Contro	25	25	25	25	23
2	Negative Contro	25	25	25	23	22
3	Negative Contro	25	25	24	23	23
4	Albizia	25	25	25	25	24
5	Albizia	25	25	24	24	22
6	Albizia	25	25	24	24	24

GLYCINE ON ALBINO EMBRYOS
DISK 188 7/12/95




Figure 14

GLUTAMATE ON ALBINO EMBRYOS
DISK 187 7/12/95




Figure 15

HOMOCYSTEIC ACID ON ALBINO EMBRYOS
DISK 188 7/14/95




Figure 16

ALBINO EMBRYOS VS ALPHA-CHACONINE AT LOW CONCENTRATIONS

October 31, 1995

All embryos at stages 1-8 (0+ hrs old).

Dishes 1-6 set up for testing on October 4, 1995.

- Dish 1: Negative control for dishes 1-6. 5 albino embryos incubated in 10mL of fetax
- Dish 2: 5 albino embryos incubated in 0.5mg/L a-chaconine
- Dish 3: 5 albino embryos incubated in 1.0mg/L a-chaconine
- Dish 4: 5 albino embryos incubated in 2.5mg/L a-chaconine
- Dish 5: 5 albino embryos incubated in 5.0mg/L a-chaconine
- Dish 6: 5 albino embryos incubated in 10.0mg/L a-chaconine

October 4, 1995

All embryos at stage 13 (24+ hrs old).

- Dish 1: Negative control for dishes 1-6. 5 albino embryos 10mL of fetax for 26hrs and 20uL di-8-Anepps
- Dish 2: 5 albino embryos incubated in 0.5mg/L a-chaconine for 26hrs and 20uL di-8-Anepps for 30min
- Dish 3: 5 albino embryos incubated in 1.0mg/L a-chaconine for 26hrs and 20uL di-8-Anepps for 30 min
- Dish 4: 5 albino embryos incubated in 2.5mg/L a-chaconine for 26hrs and 20uL di-8-Anepps for 30 min
- Dish 5: 5 albino embryos incubated in 5.0mg/L a-chaconine for 26hrs and 20uL di-8-Anepps for 30min
- Dish 6: 5 albino embryos incubated in 10.0mg/L a-chaconine for 26hrs and 20uL di-8-anepps for 30min

Photos taken of dishes 1-6 with 1000 ASA film, 5X photo eyepiece, 10X objective a B-filter, and a Nikon 35mm camera attached to a Nikon camerahead,

Dishes 7-13 set up for testins on October 5. 1994.

- Dish 7: Negative control for dishes 7-13. 5 albino embryos incubated in 10mL of fetax
- Dish 8: 5 albino embryos incubated in fetax for 26hrs then 0.25mg/L a-chaconine
- Dish 9: 5 albino embryos incubated in fetax for 26hrs then 0.5mg/L a-chaconine
- Dish 10: 5 albino embryos incubated in fetax for 26hrs then 1.0mg/L a-chaconine
- Dish 11: 5 albino embryos incubated in fetax for 26hrs then 2.5mg/L a-chaconine
- Dish 12: 5 albino embryos incubated in fetax for 26hrs then 5.0mg/L a-chaconine
- Dish 13: 5 albino embryos incubated in fetax for 26hrs then 10.0mg/L a-chaconine

1 October 5, 1995

All embryos are 48+ hrs old.

Dish 1: Negative control for dishes 1-6. 5 albino embryos incubated in 10mL of fetax for 51hrs and 20uL di-8-Anepps for 25hrs

Dish 2: 5 albino embryos incubated in 0.5 mg/L a-chaconine for 51hrs and 20uL di-8-Anepps for 25hrs

Dish 3: 5 albino embryos Incubated in 1.0 mg/L a-chaconine for 51hrs and 20uL di-8-Anepps for 25hrs

Dish 4: 5 albino embryos incubated in 2.5mg/L a-chaconine for 51hrs and 20uL di-8-Anepps for 25hrs

Dish 5: 5 albino embryos incubated in 5.0mg/L a-chaconine for 51hrs and 20uL di-8-Anepps for 25hrs

Dish 6: 5 albino embryos incubated in 10.0mg/L a-chaconine for 51hrs and 20uL di-8-Anepps for 25hrs

Dish 7: Negative control for dishes 7-13. 5 albino embryos incubated in 10mL of fetax for 51hrs and 20uL di-8-Anepps

Dish 8: 5 albino embryos incubated in fetax for 26hrs then 0.25 mg/L a-chaconine for 25hrs and 20uL di-8-Anepps for 30min

Dish 9: 5 albino embryos incubated in fetax for 26hrs then 0.5 mg/L a-chaconine for 25hrs and 20uL di-8-Anepps for 30 min

Dish 10: 5 albino embryos incubated in fetax for 26hrs then 1.0 mg/L a-chaconine for 25hrs and 20uL di-8-Anepps for 30 min

Dish 11: 5 albino embryos incubated in fetax for 26hrs then 2.5 mg/L a-chaconine for 25hrs and 20uL di-8-Anepps for 30 min

Dish 12: 5 albino embryos incubated in fetax for 26hrs then 5.0 mg/L a-chaconine for 25hrs and 20uL di-8-Anepps for 30 min

Dish 13: 5 albino embryos incubated in fetax for 26hrs then 10.0 mg/L a-chaconine for 25hrs and 20uL di-8-Anepps for 30 min

Photos taken of dishes 1-6 with 1000 ASA film, 5X photo eyepiece, 10X objective, a B-filter and a Nikon 35mm camera attached to a Nikon camerahead.

Dishes were set up for testing on October 6, 1995.

Dish 14: 5 albino embryos incubated in fetax for 52hrs and 0.25 mg/L a-chaconine

Dish 15: 5 albino embryos incubated in fetax for 52hrs and 0.5 mg/L a-chaconine

Dish 16: 5 albino embryos incubated in fetax for 52hrs and 1.0 mg/L a-chaconine

Dish 17: 5 albino embryos incubated in fetax for 52hrs and 2.5 mg/L a-chaconine

- Dish 18: 5 albino embryos incubated in fetax for 52hrs and
5.0 mg/L a-chaconine
Dish 19: 5 albino embryos incubated in fetax for 52hrs and
10.0 mg/L a-chaconine

October 6, 1995

All embryos are 72+ hrs old.

- Dish 7: Negative control for dishes 7-13. 5 albino embryos
incubated in 10mL of fetax for 72hrs and redyed with 20uL
di-8-Anepps for 30min
Dish 10: 5 albino embryos incubated in fetax for 26hrs then
1.0mg/L a-chaconine for 46 hrs and redyed with 20uL
di-8-Anepps for 30min
Dish 11: 5 albino embryos incubated in fetax for 26hrs then
2.5mg/L a-chaconine for 46hrs and redyed with 20uL di-8
Anepps for 30min

Dish 14: 5 albino embryos incubated in fetax for 52hrs then
0.25mg/L a-chaconine for 24hrs and 20uL di-8-Anepps for
30min
Dish 15: 5 albino embryos incubated in fetax for 52hrs and
0.5 mg/L a-chaconine for 24hrs and 20uL di-8-Anepps for
30 min
Dish 16: 5 albino embryos incubated in fetax for 52hrs and
1.0mg/L a-chaconine for 24hrs and 20uL di-8-Anepps for
30 min
Dish 17: 5 albino embryos incubated in fetax for 52hrs and
2.5mg/L a-chaconine for 24hrs and 20uL di-8-Anepps for
30min
Dish 18: 5 albino embryos incubated in fetax for 52hrs and
5.0mg/L a-chaconine for 24hrs and 20uL di-8-Anepps for
30 min
Dish 19: 5 albino embryos incubated in fetax for 52hrs and
10.0mg/l a-chaconine for 24hrs and 20uL di-8-Anepps for
30 min

Photos taken of dishes 1-6 with 1000 ASA film, 5X photo eyepiece,
10X objective, a B-filter, and a Nikon 35mm camera attached to a
Nikon camerahead.

ACRYLAMIDE on Embryos

October 31, 1995

DISH#	CONCENTRATION	DAY 0	Number Survived	
			DAY 1	DAY 2
1	Negative control	20	20	20
2	Negative control	20	20	19
3	10 mg/L acrylamide	20	19	19
4	10 mg/L acrylamide	20	20	19
5	5 mg/L acrylamide	20	20	19
6	5 mg/L acrylamide	20	19	19
7	2.5 mg/L acrylamide	20	20	20
8	2.5 mg/L acrylamide	20	17	17
9	1 mg/L acrylamide	20	19	19
10	1 mg/L acrylamide	20	20	19

ACRYLAMIDE ON ALBINO EMBRYOS
DISK 214 10/31/95




Figure 17

alpha-Chaconine Survival Experiment

CONCENTRATION	1st Day Embryos			
	Nov. 7, 1995	Nov. 8, 1995	Nov. 9, 1995	Nov. 10, 1995
Negative Control	6	6	6	6
0.1 mg/L a-Chac.	6	6	6	6
1 mg/L a-Chac.	6	5	5	5
2 mg/L a-Chac.	6	6	6	6
5 mg/L a-Chac.	6	4	0	0
set up Nov. 7, 1995				

CONCENTRATION	2nd Day Embryos		
	Nov. 8, 1995	Nov. 9, 1995	Nov. 10, 1995
Negative Control	6	6	6
0.1 mg/L a-Chac.	6	6	6
1 mg/L a-Chac.	6	6	6
2 mg/L a-Chac.	6	6	6
5 mg/L a-Chac.	6	0	0
set up Nov. 8, 1995			

CONCENTRATION	3rd Day Embryos	
	Nov. 9, 1995	Nov. 10, 1995
Negative Control	6	6
0.1 mg/L a-Chac.	6	6
1 mg/L a-Chac.	6	6
2 mg/L a-Chac.	6	6
5 mg/L a-Chac.	6	0
set up Nov. 9, 1995		

TCAOB & TCAB on Embryos (1% EtOH)

November 15, 1995		Number Survived				
JISH#	CONCENTRATION	DAY 0	DAY 1	DAY 2	DAY 3	DAY 5
1	Negative control	25	23	22	22	0
2	Negative control	25	23	23	22	0
3	Negative control	25	25	24	21	0
4	200 ug/L TCAOB	25	23	22	21	0
5	200 ug/L TCAOB	25	23	23	22	22
6	200 ug/L TCAOB	25	23	23	22	0
7	100 ug/L TCAOB	25	24	24	21	17
8	100 ug/L TCAOB	25	22	20	19	0
9	100 ug/L TCAOB	25	25	24	23	0
10	50 ug/L TCAOB	25	25	22	21	15
11	50 ug/L TCAOB	25	24	24	22	0
12	50 ug/L TCAOB	25	23	23	21	7
13	25 ug/L TCAOB	25	23	22	22	14
14	25 ug/L TCAOB	25	24	24	20	0
15	25 ug/L TCAOB	25	25	24	23	0
16	Negative control	25	24	24	24	0
17	Negative control	25	25	25	23	0
18	Negative control	25	23	23	23	21
19	200 ug/L TCAB	25	24	23	22	17
20	200 ug/L TCAB	25	23	23	22	19
21	200 ug/L TCAB	25	21	19	19	16
22	100 ug/L TCAB	25	22	22	20	0
23	100 ug/L TCAB	25	25	25	25	0
24	100 ug/L TCAB	25	21	20	20	0
25	50 ug/L TCAB	25	24	23	22	0
26	50 ug/L TCAB	25	25	24	24	22
27	50 ug/L TCAB	25	24	24	24	16
28	25 ug/L TCAB	25	24	23	17	0
29	25 ug/L TCAB	25	24	24	24	0
30	25 ug/L TCAB	25	24	24	24	0

1% EtOH was used to dissolve the TCAB & TCAOB.

ACRYLAMIDE on Embryos

November 15, 1995			Number Survived		
DISH#	CONCENTRATION	DAY 0	DAY 1	DAY 2	
1	Negative control	25	24	24	
2	Negative control	25	24	23	
3	10 mg/L acrylamide	25	22	21	
4	10 mg/L acrylamide	25	25	24	
5	5 mg/L acrylamide	25	23	22	
6	5 mg/L acrylamide	25	24	24	
7	2.5 mg/L acrylamide	25	24	23	
8	2.5 mg/L acrylamide	25	22	22	
9	1 mg/L acrylamide	25	25	25	
10	1 mg/L acrylamide	25	25	25	

TRIMETHYLTIN on Embryos

November 15, 1995

DISH#	CONCENTRATION	Number Survived			
		DAY 0	DAY 1	DAY 2	DAY 3
1	10 mg/L TMT	25	22	0	0
2	10 mg/L TMT	25	25	19	0
3	10 mg/L TMT	25	25	24	0

short trial run of TMT

TRIMETHYLTIN on Embryos

December 5, 1995		Number Survived				
ISH#	CONCENTRATION	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
1	Negative control	15	14	14	14	14
2	Negative control	15	14	14	14	14
3	Negative control	15	15	15	15	15
4	Negative control	15	14	14	13	13
5	1 mg/L TMT	15	15	15	1	1
6	1 mg/L TMT	15	15	14	1	1
7	1 mg/L TMT	15	15	15	1	1
8	1 mg/L TMT	15	15	14	1	1
9	10 mg/L TMT	15	15	0	0	0

* 1mg/L all deformed

TRIMETHYLTIN on Embryos

December 13, 1995		Number Survived					
DISH#	CONCENTRATION	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4	DAY 5
1	Negative control	10	10	10	10	10	1
2	1 mg/L TMT	10	10	10	10	10	
3	0.5 mg/L TMT	10	10	10	9	10	
4	0.2 mg/L TMT	10	10	10	10	10	1
5	0.1 mg/L TMT	10	10	10	10	10	1
6	0.05 mg/L TMT	10	10	10	10	10	1
7	0.01 mg/L TMT	10	10	10	10	10	1

* 1mg/L and 0.5 mg/L all deformed

TRIMETHYLTIN ON ALBINO EMBRYOS
DISK 214 12/13/95




Figure 18

TRIMETHYLTIN on Embryos

December 14, 1995

DISH#	CONCENTRATION	Number Survived				
		DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
1	Negative control	10	10	10	10	10
2	1 mg/L TMT	10	10	10	10	10*
3	0.5 mg/L TMT	10	10	10	9	8*
4	0.2 mg/L TMT	10	10	10	10	10
5	0.1 mg/L TMT	10	10	10	10	10
6	0.05 mg/L TMT	10	10	10	10	10
7	0.01 mg/L TMT	10	10	10	10	10

* 1mg/L and 0.5 mg/L all deformed embryos are 24 hrs. old

TRIMETHYLTIN on Embryos

December 15, 1995

DISH#	CONCENTRATION	DAY 0	Number Survived				DAY 3	DAY 4
			DAY 1	DAY 2				
1	Negative control	10	10	10		10	10	9
2	1 mg/L TMT	10	10	10		10	10	10*
3	0.5 mg/L TMT	10	10	10		10	10	10*
4	0.2 mg/L TMT	10	10	10		10	10	10
5	0.1 mg/L TMT	10	10	10		10	10	10
6	0.05 mg/L TMT	10	10	10		10	10	10
7	0.01 mg/L TMT	10	10	10		10	10	10

* 1mg/L and 0.5 mg/L all deformed
embryos are 48 hrs. old

TRIMETHYLTIN on Embryos

December 18, 1995

DISH#	CONCENTRATION	DAY 0	Number Survived				DAY 3	DAY 4
			DAY 1	DAY 2				
1	Negative control	25	25	25		25		
2	1 mg/L TMT	25	25	25			25*	
3	0.5 mg/L TMT	25	25	25			25*	
4	0.2 mg/L TMT	25	25	24		24		
5	0.1 mg/L TMT	25	25	25		25		
6	0.05 mg/L TMT	25	25	25		25		
7	0.01 mg/L TMT	25	25	25		25		
8	Negative control	25	25	22		22		
9	1 mg/L TMT	25	25	25			25*	
10	0.5 mg/L TMT	25	24	22			22*	
11	0.2 mg/L TMT	25	25	25		25		
12	0.1 mg/L TMT	25	25	25		25		
13	0.05 mg/L TMT	25	25	25		25		
14	0.01 mg/L TMT	25	25	25		25		

* 1mg/L and 0.5 mg/L all deformed

TRIMETHYLTIN ON ALBINO EMBRYOS
DISK 214 12/18/95




Figure 19

TCAOB & TCAB on Embryos (1% EtOH)

December 21, 1995		Number Survived		
DISH#	CONCENTRATION	DAY 0	DAY 1	DAY 2-4
1	Negative control	25	25	0
2	200 ug/L TCAOB	25	24	0
3	100 ug/L TCAOB	25	25	0
4	50 ug/L TCAOB	25	25	0
5	25 ug/L TCAOB	25	24	0
6	10 ug/L TCAOB	25	23	0
7	Negative control	25	25	0
8	200 ug/L TCAOB	25	24	0
9	100 ug/L TCAOB	25	25	0
10	50 ug/L TCAOB	25	25	0
11	25 ug/L TCAOB	25	24	0
12	10 ug/L TCAOB	25	24	0
13	Negative control	25	25	0
14	200 ug/L TCAB	25	24	0
15	100 ug/L TCAB	25	23	0
16	50 ug/L TCAB	25	25	0
17	25 ug/L TCAB	25	25	0
18	10 ug/L TCAB	25	25	0
19	Negative control	25	25	0
20	200 ug/L TCAB	25	24	0
21	100 ug/L TCAB	25	25	0
22	50 ug/L TCAB	25	24	0
23	25 ug/L TCAB	25	23	0
24	10 ug/L TCAB	25	25	0

1% EtOH was used to dissolve the TCAB & TCAOB.


[illegible][illegible]



















Photomicrograph 8




























































































Photomicrograph 45









Photomicrograph 48





























Page 141




Photomicrograph 60














Page 147




Photomicrograph 66














































Page 166



Photomicrograph 85

Page 167




Photomicrograph 86




Page 169



Photomicrograph 88




Page 171



Photomicrograph 90

Page 872

Page 172



Photomicrograph 91



CONCLUSIONS

I conclude that the hypothesis was supported by the results of this study. That is, it is possible to detect sub-lethal concentrations of neurotoxicants by image analysis of neural tissue using voltage-sensitive fluorescent dyes and by anterograde/retrograde tracing of injected tracers. This surprising results suggests an expansion of the scope of the work to include further testing of additional neurotoxicants and validation of these results and future results by an optics setup with a smaller working distance (ie. confocal microscope). Testing of the original subjects of the study, excitatory amino acids will probably require microinjection of the compound into the embryo/tadpole.

REFERENCES

- (1) Dumont, J.N., T.W. Schultz, M. Buchanan, G. Kao. (1983) Frog embryo teratogenesis assay: *Xenopus*-- A short-term assay applicable to complex environmental mixtures. In: Short-term bioassays in analysis of complex environmental mixtures: III. Plenum Press pp. 393-405.
- (2) American Society for Testing and Materials (1991) (Standard Guide for conducting the Frog Embryo Teratogenesis Assay: (*Xenopus*) E1439-91, Philadelphia, PA.
- (3) Fort, D.J., B. James, and J. Bantle. (1989) Evaluation of the developmental toxicity of five compounds with the Frog Embryo Teratogenesis Assay:*Xenopus*(FETAX) and a metabolic activation system. *J. Appl. Toxicol.* 9, 377-388.
- (4) Blankemeyer, J.T., B.K. Stringer, J.R. Rayburn, M. Friedman, and J.A. Bantle. (1992) Effect of Potato Glycoalkaloids of the Membrane Potential of Frog Embryos. *J. Agricultural and Food Chemistry* (ACS) 40, 2022-2026.
- (5) Stringer, B.K. and J.T. Blankemeyer. 1993 Effect of 6-Aminonicotinamide on Membrane Potential of Frog Embryos. *Bull. Environ. Contam. and Toxicol.* 51, 557-563.
- (6) Montana, V., D. L. Farkas, L. M. Loew. (1989) Dual-Wavelength Ratiometric Fluorescence Measurements of Membrane Potential. *Biochem.* 28, 4536-4539.
- (7) Grynkiewicz, G., M. Poenie, and R.Y. Tsien. (1985) A New Generation of Ca^{++} indicators with Greatly Improved Fluorescence Properties. *J. Biol. Chem.* 260, 3440-3450.
- (8) Blankemeyer, J.T., B.K. Stringer, J.A. Bantle, and M. Friedman (1994) Correlation of a Cellular Assay -CHAWQ - with FETAX. Second Symposium on Environmental Risk Assessment, J. Gorsuch, G. Lindeman, C. Ingersoll, and T. La Pointe, Eds., American Society for Testing and Materials, Special Technical Publication #1216-In Vitro Toxicology 2:146-158.
- (9) Grandin, N. and M. Charbonneau. (1988) Intracellular pH and the Increase in Protein Synthesis Accompanying Activation of *Xenopus* Eggs. *Biol. of the Cell* 67: 321-325.
- (10) Latt, S.H. and G. Stetten. (1976) Spectral Studies on 33258 Hoechst and Related Bisbenzamide Dyes Useful for Detection of Deoxyribonucleic Acid Synthesis. *J. Histochem. Cytochem.* 24, 24-33.

- (11) Niewkoop, P.D. and J. Faber. (1975) Normal tables of *Xenopus laevis* North Holland, Amsterdam
- (12) Edmisten, G.E. and Bantle, J.A. (1982) Use of *Xenopus laevis* larvae in 96-hour flow through toxicity test with naphthalene. *Bull. Environ. Contam. Toxicology*. 29, 392-399.
- (13) Blankemeyer, J.T. and C.H. Hefler (1990) Effect of naphthalene on sodium active transport in frog skin. *Bull. Environ. Contam. Toxicol.* 45, 627-632.
- (14) Taylor, D.H., C.W. Steele, and S. Strickler-Shaw (1990) Responses of Green Frog (*Rana clamitans*) to lead-polluted water. *Environ. Toxicol. and Chem.* 9, 87-93.
- (15) Little, E.E. (1990) Behavioral Toxicology: Stimulating challenges for a growing discipline. *Environ. Toxicol. and Chem.* 9, 1-2.
- (16) Little, E.E. and S.E. Finger (1990) Swimming behavior as an indicator of sublethal toxicity in fish. *Environ. Toxicol. and Chem.* 9, 13-19.
- (17) Little, E.E., Archeski, R.D., Flerov, B.A., Kozlovskaya, V.I. (1990) Behavioral Indicators of Sublethal Toxicity in Rainbow Trout. *Arch. Env. Contam. Toxicol.* 19, 380-385.
- (18) Kandel, E.R. and J.H. Schwartz (1982) Molecular biology of learning: Modulation of transmitter release *Science* 218, 433-444.
- (19) Blankemeyer, J.T. and M. Bowerman. (1992) Effect of Cyclic Organics on Active Transport of Sodium in Frog Skin. *Bull. Env. Cont. and Tox.* 50: 132-137.
- (20) Gulley, D., A. Boelter, and H. Bergman. (1991) Toxstat 3.3. University of Wyoming, Laramie, WY
- (21) Fort, D.J., E.L. Stover, S.L. Burks, R.A. Atherton, and J.T. Blankemeyer (1996) Utilizing Biomarker Techniques: Cellular membrane potential as a biomarker of Subchronic Toxicity *Environmental Toxicology and Risk Assessment: fifth volume ASTM*, Philadelphia, PA (in press)

BIBLIOGRAPHY

- (22) Stringer, B.K. and J.T. Blankemeyer (1995) Measurement of DNA Integrity and Structure in *Xenopus* Embryos in the Presence of Hydroxyurea, Actinomycin-D, and Triethylenemelamine using the fluorescent probe Hoechst 33258. *Teratogenicity, Carcinogenicity, And Mutagenicity* 15, 53-62.

(23) Blankemeyer, J.T., R. Atherton, and M. Friedman. (1995) Effect of Plant Glycoalkaloids on Short-Circuit Current of Frog Skin. *J. Agricultural and Food Chemistry* (ACS) 43, 636-640.

(24) Blankemeyer, J.T. (1995) #5,416,005 "A Method for Rapid Toxicity Testing of a Liquid Sample". U.S. patent (process), issued May 16, 1995.

(25) Blankemeyer, J.T. (1995) # 5,459,070, "Apparatus for Rapid Toxicity Testing of a Liquid Sample". U.S. patent (mechanism), issued October 17, 1995.

Acrylamide

(26) Costa, L.G. (1996) Biomarker Research in Neurotoxicology: The Role of Mechanistic Studies to Bridge the Gap Between the Laboratory and Epidemiology Investigations. *Environmental Health Perspectives* 104s1, 55-67.

(27) Crofton, K.M., S. Padill, H.A. Tilson, D.C. Anthony, J.H. Raymer, and R.C. Macphail. (1996) The Impact of Dose-Rate on the Neurotoxicity of Acrylamide; The Interaction of Administered Dose, Target Tissue Concentrations, Tissue-Damage, and Functional-Effects. *Toxicology and Applied Pharmacology* 139n1, 163-176.

(28) Driancourt, M.A., T. Gormon, L.P. Thanh, and O. Boomarov. (1996) Analysis by 2-Dimensional Electrophoresis of Proteins Secreted by Sheep Ovarian Follicles; Effects of the Fec(B) Gene, Follicle Size and Atresia. *J. Reproduction and Fertility* 107n1, 69-77.

(29) Hattis, D. (1996) The Challenge of Mechanism-Based Modeling in Risk Assessment for Neurobehavioral End-Points. *Environmental Health Perspectives* 104s2, 381-390.

(30) Lin, W.W., L.R. Johnson, M.A. Friedman, and M.B. Aboudonina. (1996) In-Vitro Studies of Acrylamide Neurotoxicity in Rat Pheochromocytoma (PC12) Cells. *Atla-Alternatives to Laboratory Animals* 24n3, 359-366.

(31) Oishi, Y., H. Yamamoto, M. Nagano, E. Miyamoto, and M. Futatsuka. (1996) The Effects of 2,5-Hexanedione and Acrylamide on Myosin Heavy-Chain Isoforms of Slow and Fast Skeletal-Muscles of the Rat. *Toxicology and Applied Pharmacology* 139n1, 15-21. *Perspectives* 104s1, 55-67.

Albizzia

(32) Patil, S.G., M. Hebbara, and S.B. Devarnavadagi. (1996) Screening of Multipurpose Trees for Saline Vertisols and their

Bio-Ameliorative Effects. *Annals of Arid Zone* 35n1, 57-60.

(33) Reza, M.A., A.N.K. Mamun, R. Islam, and O.I. Joarder. (1995) In-Vitro Regeneration of Plantlets from Hypocotyl Explants of *Albizzia Lebbeck*. *Blangladesh Journal of Botany* 24n2, 109-113.

(34) Sankhla, D., T.D. Davis, and N. Sankhla. (1996) In-Vitro Regeneration of Silktree (*Albizzia Julibrissin*) from Excised Roots. *Plant Cell Tissue and Organ Culture* 44n1, 83-86.

(35) Sankhla, D., N. Sankhla, and T.D. Davis. (1995) Promotion of In-Vitro Shoot Formation from Excised Roots of Silktree (*Albizzia Julibrissin*) by an Oxime Ether Derivative and other Ethylne Inhibitors. *Plant Cell Reports* 15n1-2, 143-146.

(36) Teklehaimanot, Z., and G. Animkwapong. (1996) The Potentials of *Albizzia-Zygia* (DC) Macbride for Soil Amelioration. *Applied Soil Ecology* 3n1, 59-68.

(37) Toky, O.P., and V. Srinivasu. (1995) Response of Sodium-Bicarbonate Sodidity on Survival, Seedling Growth and Plant Nutrients of 4 Multipurpose Arid Trees. *Annals of Arid Zone* 34n2, 115-120.

Colchicine

(38) Butta, N., A. Martinrequero, E. Urcelay, R. Parrilla, and M.S. Ayuso. (1996) Modulation of the Hepatic Alpha(1)-Adrenoceptor Responsiveness by Colchicine Dissociation of Free Cytosolic CA²⁺-Dependant and Independant Responses. *British Journal of Pharmacology* 118n7, 1797-1805.

(39) Cedillo, A., M. Mourelle, and P. Muriel. (1996) Effect of Colchicine and Trimethylcolchicinic Acid on CCL4-Induced Cirrhosis in the Rat. *Pharmacology and Toxicology* 79n5, 241-246.

(40) Devin, F., P. Garcia, V. Peyrott, B. Ridings, J.B. Saracco. (1996) RPE Cytoskelton Sensibility to Spindle Poisons. *J. Francais D Opthalmologie* 19n6-7, 423-430.

(41) Ekblad, E., H. Mulder, and F. Sundler. (1996) Vasoactive-Intestinal-Peptide Expression in Enteric Neurons is Up-Regulated by Both Colchicine and Axotomy. *Regulatory Peptides* 63n2-3, 113-121.

(42) Marczin, N., T. Jilling, A. Papapetropoulos, C. Go, and J.D. Catravas. (1996) Cytoskeleton-Dependant Activation of the Inducible Nitric-oxide Synthase in Cultured Aortic Smooth-Muscle Cells. *British Journal of Pharmacology* 118n5, 1085-1094.

(43) Ullian, M.E., L.G. Walsh, and T.A. Morinelli. (1996) Potentiation of Angiotensin-II Action by Corticosteroids in Vascular Tissue. Cardiovascular Research 32n2, 266-273.

Glutamic Acid

(44) Beausoleil, E., B. Larcheveque, L. Belec, M. Atfani, and W.D. Lubell. (1996) 5-TERT-Butylproline. J. Organic Chemistry 61n26, 9447-9454.

(45) Behbehani, M.M., and T.M.D. Gomez. (1996) Properties of a Projection Pathway from the Medial Preoptic Nucleus to the Midbrain Periaqueductal Gray of the Rat and its Role in the Regulation of Cardiovascular Function. Brain Research 740n1-2, 141-150.

(46) Fedele, E., M. Bisaglia, and M. Raiteri. (1997) D-Serine Modulates the NMDA Receptor Nitric-Oxide CGMP Pathway in the Rat Cerebellum During In-Vitro Microdialysis. Naunyn-Schmiedeberg's Archives of Pharmacology 355n1, 43-47.

(47) Garofalo, P., S. Colombo, M. Lanza, L. Revel, and F. Markovec. (1996) CR-2249, A New Putative Memory Enhancer - Behavioral-Studies on Learning and Memory in Rats and Mice. J. Pharmacy and Pharmacology 48n12, 1290-1297.

(48) Seltzner, Z., and L. Polgar. (1996) Rate-Determining Steps in HIV-1 Protease Catalysis; The Hydrolysis of the Most Specific Substrate. J. Biological Chemistry 271n50, 32180-32184.

(49) Sparks, S.E., G.B. Quistad, L.M. Cole, and J.E. Casida. (1996) Metaldehyde Molluscicide Action in Mice; Distribution, Metabolism, and Possible Relation to GABAergic System. Pesticide Biochemistry and Physiology 55n3, 226-236.

Glycine

(50) Bau, H.M., C. Villaume, J.P. Nicolas, and L. Mejean. (1997) Effect of Germination on Chemical-Composition, Biochemical-Constituents and Antinutritional Factors of Soya Bean (Glycine-Max) Seeds. J. Science of Food and Agriculture 73n1, 1-9.

(51) Dugas, W.A., S.A. Prior, and H.H. Rogers. (1997) Transpiration from Sorghum and Soybean Growing Under Ambient and Elevated CO₂ Concentrations. Agricultural and Forest Meteorology 83n1-2, 37-48.

(52) Farooque, M., L. Hillered, A. Holtz, and Y. Olsson. (1997)

Effect of 21-Aminosteroid on Extracellular Energy-Related Metabolites and Amino-Acids after Compression Injury of Rat Spinal-Cord. *Experimental Brain Research* 113n1, 1-4.

(53) Javitt, D.C., and M. Frusciante. (1997) Glycylododecylamide, A Phencyclidine Behavioral Antagonist, Blocks Cortical Glycine Uptake; Implications for Schizophrenia and Substance-Abuse. *Psychopharmacology* 129n1, 96-98.

(54) Kaur, S., and M.S. Starr. (1997) Differential-Effects of Intrastratial and Intranigral Injections of Glutamate Antagonists on Motor Behavior in the Reserpine-Treated Rat. *Nueroscience* 76n2, 345-354.

(55) Witkin, J.M., T.D. Steele, and L.G. Sharpe. (1997) Effects of Strychnine-Insensitive Glycine Receptor Ligands in Rats Discriminating Dizocilpine or Phencyclidine from Saline. *J. Pharmacology and Experimental Therapeutics* 280n1, 46-52.

Kainic Acid

(56) Araujo, M., and F. Wandosell. (1996) Differential Cellular-Response after Glutamate Analog Hippocampal Damage. *J. Nueroscience Research* 44n4, 397-409.

(57) Bernard, C., and H.V. Wheal. (1996) A Role for Synaptic and Network Plasticity in Controlling Epileptiform Activity in CA1 in the Kainic Acid-Lesioned Rat Hippocampus In-Vitro. *J. Physiology-London* 495n1, 127-142.

(58) Best, N., L.E. Sundstorm, J. Mitchell, and H.V. Wheal. (1996) Organotypic Hippocampal Slice Cultures Effects of Kainic Acid on Parvalbumin-Immunoreactive Nuerons and Expression of Heat-Shock Protein-72 Following the Induction of Tolerance. *European Journal of Nueroscience* 8n6, 1209-1219.

(59) Kent, S., S.D. Kernahan, and S. Levine. (1996) Effects of Excitatory Amino-Acids on the Hypothalamic-Pituitary-Adrenal Axis of the Neonatal Rat. *Developmental Brain Research* 94n1, 1-13.

(60) Quesada, O., J. Hirsch, Y. Benari, and C. Bernard. (1996) Redox Sites of NMDA Receptors can Modulate Epileptiform Activity in Hippocampal Slices from Kainic Acid-Treated Rats. *Nueroscience Letters* 212n3, 171-174.

(61) Rong, Y.Q., and M. Baudry. (1996) Seizure Activity Results in a Rapid Induction of Nuclear Factor-Kappa-B in Adult but not Juvenile Rat Limbic Structures. *Journal of Nuerochemistry* 67n2, 662-668.

Mimosine

(62) Breder, J., S. Ruller, E. Ruller, M. Schlaak, and J. Vanderbosch. (1996) Induction of Cell-Death by Cytokines in Cell Cycle-Synchronous Tumor-Cell Populations Restricted to G(1) and G(2). *Experimental Cell Research* 223n2, 259-263.

(63) Danna, J.A., J.G. Valdez, S.F. Peterson, and H.A. Crissman. (1995) Effects of Mimosine Blockage in CHO Cells; Implications for Regulation of S-Phase Radiation Delay. *J. Cellular Biochemistry* s21a, 342.

(64) Kulp, K.S., and P.R. Vulliet. (1996) Mimosine Blocks Cell-Cycle Progression by Chelating Iron in Asynchronous Human Breast-Cancer Cells. *Toxicology and Applied Pharmacology* 139n2, 356-364.

(65) Kulp, K.S., S.L. Green, and P.R. Vulliet. (1996) Iron Deprivation Inhibits Cyclin-Dependant Kinase-Activity and Decreases Cyclin-D CDK4 Protein-Levels in Asynchronous MDA-MB-453 Human Breast-Cancer Cells. *Experimental Cell Research* 229n1, 60-68.

(66) Puchala, R., S.G. Pierzynowski, T. Sahlu, and S.P. Hart. (1996) Effects of Mimosine Administered to a Perfused Area of Skin in Angora-Goats. *British Journal of Nutrition* 75n1, 69-79.

TriMethylTin

(67) Clerici, W.J. (1996) Effects of Superoxide-Dismutase and U74389G on Acute Trimethyltin-Induced Cochlear Dysfunction. *Toxicology and Applied Pharmacology* 136n2, 236-242.

(68) Cohn, J., and R.C. MacPhail. (1996) Acute Trimethyltin Exposure Produces Nonspecific Effects on Learning in Rats Working Under a Multiple Repeated Acquisition and Performance Schedule. *Neurotoxicology and Treatology* 18n1, 99-111.

(69) Fechter, L.D., and Y. Liu. (1995) Elevation of Intracellular Calcium Levels in Spiral Ganglion-Cells by Trimethyltin. *Hearing Research* 91n1-2, 101-109.

(70) Koczyk, D., M. Skup, M. Zaremba, and B. Oderfeldnowak. (1996) Trimethyltin-Induced Plastic Neuronal Changes in Rat Hippocampus are Accompanied by Astrocytic Trophic Activity. *ACTA Neurobiologiae Experimentals* 56n1, 237-241.

(71) Moser, V.C. (1996) Rat Strain-Related and Gender-Related Differences in Neurobehavioral Screening; Acute Trimethyltin Neurotoxicity. *J. Toxicology and Environmental Health* 47n6, 567-

586.

(72) Oortgiesen, M., E. Visser, H.P.M. Vijverberg, and W. Seinen. (1996) Differential-Effects of Organotin Compounds on Voltage-Gated Potassium Currents in Lymphocytes and Nueroblastoma-Cells. Naunyn-Schmiedebergs Archives of Pharmacology 353n2, 136-143. Vinblastine

(73) Sjblom, T., M. Parvinen, and J. Lahdetie (1995) Stage-specific DNA synthesis of Rat Spermatogenesis as an Indicator of Genotoxic Effects of Vinblastine, Mitomycin C, and ionizing Radiation on Rat Spermatogonia and Spermatocytes. Mutation Research- Fundamental and Molecular Mechanisms of Mutagenesis 331, 181-190.

MEETINGS ATTENDED (NONE) No Travel money

DISK #178

EFFECTS OF α -CHLORINE AND FOLIC ACID ON THE

BURNS

MEMBRANE POTENTIAL OF ALBINO EMBRYOS

3-31-95

GROUP 1 = BROODMATS OF #20 ♀ & #11 ♂

GROUP 2 = BROODMATS OF #21 ♀ & #12 ♂

SCAN NO	SAMPLE DESCRIPTION	INT 2A	% OF NEG. CONTROL	% OF MAX. RESPONSE
1	NEGATIVE CONTROL: GROUP 1	7.9380×10^4	$\bar{x} = 7.252 \times 10^4$	22.67
2	POSITIVE CONTROL: 50ng/L α -CHLORINE	35.021×10^4	482.92	100.00*
3	POSITIVE CONTROL: 40ng/L FOLIC ACID	13.093×10^4	180.54	37.39
4	POSITIVE CONTROL: 10ng/L α -CHLORINE	8.6494×10^4	119.27	24.70
5	POSITIVE CONTROL: 5ng/L α -CHLORINE	11.2300×10^4	154.85	32.07
6	POSITIVE CONTROL: 2.5ng/L α -CHLORINE	8.1901×10^4	112.94	23.39
7	NEGATIVE CONTROL: GROUP 2	3.9899×10^4	—	—
8	POSITIVE CONTROL: 50ng/L α -CHLORINE	3.0162×10^5	755.96	—
9	POSITIVE CONTROL: 40ng/L FOLIC ACID	4.4055×10^4	110.42	—
10	POSITIVE CONTROL: 10ng/L α -CHLORINE	5.0714×10^4	127.11	—
11	POSITIVE CONTROL: 5ng/L α -CHLORINE	5.7288×10^4	143.58	—
12	POSITIVE CONTROL: 2.5ng/L α -CHLORINE	4.8205×10^4	120.82	—
13	GROUP 1: 50ng/L α -C AND 2.5ng/L FA	1.1298×10^5	155.79	3.23
14	" " "	1.8445×10^5	254.34	5.27
15	NO SCAN	—	—	—
16	GROUP 1: 50ng/L α -C AND 5ng/L FA	1.874×10^5	258.41	5.35
17	" " "	1.5673×10^5	216.12	4.48
18	NO SCAN	—	—	—
19	GROUP 1: 50ng/L α -C AND 10ng/L FA	2.7332×10^5	376.90	7.80
20	" " "	1.3297×10^5	184.74	3.83
21	NO SCAN	—	—	—
22	GROUP 1: 50ng/L α -C AND 20ng/L FA	1.5132×10^5	208.67	4.32
23	" " "	9.749×10^4	134.43	27.84
24	NO SCAN	—	—	—
25	GROUP 1: 50ng/L α -C AND 40ng/L FA	1.13505×10^5	156.52	3.24
26	" " " "	1.2823×10^5	176.82	3.66
27	NO SCAN	—	—	—
28	NEGATIVE CONTROL: GROUP 1	6.4538×10^4	—	18.43
29	NEGATIVE CONTROL: GROUP 1	7.3632×10^4	—	21.03

NOTE: THE PERCENT OF MAXIMUM RESPONSE WAS CALCULATED INDIRECTLY.
SEE P. 75.

5-3-95

Naphthalene on African embryos

DISK #180

30 min. incubation, di-4 ANNEPS

SCAN	CONCENTRATION	Intercept STOPE	% CONTROL
1	Neg. control	4.52×10^3	*
2	50mg/L α -Chaconine	1.98×10^4	43.8% 438%
3	1.25 mg/L Naphthalene	3.99×10^3	88%
4	250 mg/L Naphthalene	6.13×10^3	13.6% 136%
5	5 mg/L "	6.52×10^3	14.4% 144%
6	10mg/L "	3.84×10^3	85%
7	15 mg/L "	7.73×10^3	17.1% 171%
8	30 mg/L "	9.01×10^3	19.9% 199%
9	Neg. control	8.33×10^3	—
10	50mg/L α -Chaconine	1.41×10^4	13.2% 312%

Made a graph + saved as Naph5395. IPG on DISK # ~~31~~ 194

5/9/95

Discarded all above data because exit monochromator was set at 525. Kept all data above on disk though.

Naphthalene on Albino embryos

DISK #180

— 30 min. incubation in di-4

SCAN	CONCENTRATION	Intercept
1A	Neg. Control	— No GOOD - Changed monochromator in time for 3rd Scan
2A	50mg/L α -Chaconine	— No GOOD - Changed monochromator
3A	1.25 mg/L Naphthalene	9.64×10^4
4A	2.50 mg/L Naph.	8.52×10^4
5A	5.0 mg/L Naph.	9.94×10^4
6A	10mg/L Naph.	9.02×10^4
7A	15 mg/L Naph.	8.22×10^4
8A	30mg/L Naph	1.01×10^5
9A	Neg. Control	1.05×10^5 } 1.06×10^5
10A	Neg. Control	1.07×10^5 }
11A	50mg/L α -Chaconine	4.26×10^5

Made graph + saved as NAPH5995. IPG on DISK #194

5-12-95 Friday

186

FETAX experiment with Naphthalene (30mg/L) on African embryos.

DISH #	CONCENTRATION	# survived			
		24 h.	48 h.	72 h.	96 h.
1	Neg. Control			24 (5 deformed)	
2	Neg. Control			21 (1 deformed)	
3	50mg/L α -Chac.			0	
4	50mg/L α -Chac.			0	
5	1.25mg/L Naphthalene			0	
6	1.25mg/L "			23 (2 deformed)	
7	2.5mg/L "			21	
8	2.5mg/L "			21	
9	5.0mg/L "			24	
10	5.0mg/L "			18 (4 deformed)	
11	10.0mg/L "			24	
12	10.0mg/L "			21 (1 deformed)	
13	15.0mg/L "			21	
14	15.0mg/L "			21 (2 deformed)	
15	30.0mg/L "			25 (3 deformed)	
16	30.0mg/L "			23	

Made spreadsheet
+ saved on
N4445-12.4
on disk 194

Embryos (25) were put into dishes at 1:30 pm Friday.

5/26/95 Friday

FETAX experiment with Kainic acid (50mg/L) on Albino embryos.

DISH #	CONCEN.	24 h.	48 h.	72 h.	96 h.
1	50mg/L Kainic acid	14 surv.			11
2	25mg/L Kainic acid	12 surv.			12

At 24h. - embryos were still growing, switched water (put new water in each dish.)

5/26/95 Friday

Kainic Acid on Albino embryos (50mg/L KA stock)
Disk #182 - 30 min. incub., di-4 ANEPPS

SCAN	CONCEN.	Intercept
1	NC	4.75×10^4
2	NC	4.63×10^4
3	NC	5.20×10^4
4	5mg/L KA	4.58×10^4
5	15mg/L KA	6.11×10^4
6	25mg/L KA	5.99×10^4
7	50mg/L KA	5.78×10^4
8	50mg/L α -Choc.	2.79×10^5
9	2.5mg/L KA	5.51×10^4

Graphed + saved as KA-52695. IAG on Disk #194

5/31/95

Kainic Acid on normal embryos (From Mendi) - 50mg/L stock
(FETAX experiment)

SURVIVED

DISH#	CONCENTRATION	0	24h	48h	72h	96h
1	NC (10ml FTX)	20	20	19	19	19
2	NC (10ml FTX)	20	19	19	18	18
3	NC (10ml FTX)	20	19	18	18	18
4	0.2ml KA (9.8ml FTX)	20	20	20	20	20
5	0.2ml KA "	20	19	19	19	19
6	0.2ml KA "	20	19	19	19	19
7	1ml KA (9ml FTX)	20	19	18	18	18
8	1ml KA "	20	20	20	20	20
9	1ml KA "	20	20	20	20	20
10	2ml KA (8ml FTX)	20	20	19	19	19
11	2ml KA "	20	20	19	19	19
12	2ml KA "	20	20	20	20	20
13	5ml KA (5ml FTX)	20	20	20	20	20
14	5ml KA "	20	17	17	16	16
15	5ml KA "	20	19	18	17	17
16	10ml KA (0ml FTX)	20	19	19	19	18
17	10ml KA "	20	20	20	20	20
18	10ml KA "	20	20	20	20	20
19	1ml α -Choc. (9ml FTX)	20	16	0	0	0
20	1ml α -Choc. "	20	12	0	0	0

put in 30%
formalin
on last
day

These embryos (previous page) had already started neuralating.

KA_531

Made into spreadsheet & saved as KA53195.wal on disk 194

FETAX experiment with normal embryos (from Mendi) using Kainic Acid. Done earlier on 5/31/95.

DISH#	CONCENTRATION	# SURVIVED				
		0	24h	48h	72h	96h
1	NC	25	25	24	24	24
2	NC	25	25	25	23	23
3	50mg/L KA	25	25	25	25	25
4	50mg/L KA	25	25	25	25	25
5	25mg/L KA	25	25	25	25	25
6	25mg/L KA	25	24	23	23	23
7	12.5mg/L KA	25	24	24	24	24
8	12.5mg/L KA	25	23	23	23	23

Made into spreadsheet & saved as KA53195.wal on disk 194

6/1/95

FETAX experiment with Colchicine (50mg/L stock) using African embryos. Started first part of test at 3:20pm and second part at 4:30pm.

DISH#	CONCEN.	0	24h	48h	72h	96h
1	NC	25	25	25	25	25
2	NC	25	24	23	23	23
3	0.2 ml Colchicine	25	25	25	25	25
4	0.2 ml "	25	25	24	24	24
5	1 ml "	25	25	22	22	22
6	1 ml "	25	25	25	25	25
7	2 ml "	25	25	24	24	24
8	2 ml "	25	25	25	25	25
9	5 ml "	25	25	23	23	23
10	5 ml "	25	25	24	24	24
11	10 ml "	25	25	24	24	23
12	10 ml "	25	25	25	25	25
13	10 mg/L Colch.	25	18	6	0	0

put in 306
formalin on
last day

Saved as
spreadsheet as
COL-6-1-95
on disk 194

6/1/95 continued

SECOND PART

DISH#	CONCEN.	0	24h	48h	72h	96h	
14	NC	25	25	25	25	25	
15	NC	25	25	25	25	25	Put in 3%
16	0.2 ml Colchicine	25	25	24	22	21	Formalin
17	0.2 ml "	25	25	25	25	25	on last
18	1 ml "	25	24	24	24	24	day
19	1 ml "	25	25	23	23	23	
20	2 ml "	25	25	24	24	24	
21	2 ml "	25	25	25	25	25	
22	5 ml "	25	25	25	25	25	
23	5 ml "	25	25	25	25	23	
24	10 ml "	25	25	25	25	25	
25	10 ml "	25	25	25	25	25	
26	(50mg/L) 1 ml d-Chac	25	24	9	0	0	

Made into
spreadsheet
+ saved as
COL-6-1
on disk 194

FETAX experiment with Kainic Acid + Colchicine using African embryos. Started this test at 4:10pm. Diluted the stocks from 50mg/L to 5mg/L by taking 25 mls of 50mg/L stock (KA + Colchicine), putting in 250 ml volumetric flask + bring up to line with FETAX solution.

DISH#	CONCEN.	0	24h	48h	72h	96h	
1	NC	25	24	24	24	24	
2	NC	25	25	25	25	24	
3	5mg/L KA (0.1 ml)	25	25	25	25	25	
4	5mg/L KA "	25	25	25	25	25	
5	2.5mg/L KA (0.5 ml)	25	25	25	25	25	
6	2.5mg/L KA "	25	25	24	24	24	
7	1mg/L KA (0.8 ml)	25	24	24	24	24	
8	1mg/L KA "	25	25	24	24	24	
9	0.5mg/L KA (1 ml)	25	25	23	23	22	
10	0.5mg/L KA "	25	25	25	25	25	
11	0.25mg/L KA (1.5 ml)	25	25	25	24	24	
12	0.25mg/L KA "	25	25	24	23	23	
13	0.125mg/L KA (1.75 ml)	25	24	23	23	22	
14	0.125mg/L KA "	25	24	24	24	24	

Put in 3%
Formalin
on last
day
Made into
spreadsheet
+ saved as
KA-6-1
on disk 194

6/1/95 continued

190

DISH#	CONCEN.	0	24h	48h	72h	96h	
15	(^{9.9m} FTX) 0.05mg/L KA	25	24	24	24	24	
16	" 0.05mg/L KA	25	25	23	23	23	
17	NC (^{10m} FTX)	25	24	23	23	23	
18	NC "	25	25	25	25	25	
19	5mg/L Colchicine	25	25	25	25	25	put in
20	5mg/L "	25	25	25	24	24	3%
21	2.5mg/L "	25	25	25	25	25	Formal
22	2.5mg/L "	25	25	25	24	24	on las
23	1mg/L "	25	25	24	24	24	day
24	1mg/L "	25	25	25	25	25	
25	0.5mg/L "	25	25	24	24	24	
26	0.5mg/L "	25	25	25	25	25	Made into
27	0.25mg/L "	25	25	25	24	24	spreadsheet
28	0.25mg/L	25 24 25	24 25	25	25	25	+ saved
29	0.125mg/L "	25	25	25	25	25	colchicine
30	0.125mg/L "	25	25	25	25	25	on D3K1
31	0.05mg/L "	25	25	24	24	23	
32	0.05mg/L "	25	25	25	25	25	

6/8/95

Colchicine (new supply) on albino embryos (50mg/L)
 DISK #183 - 30 min. incub. in di-4 ANEPPS

SCAN	CONCENTRATION	Intercepts
1,7,13	NC	7.81×10^4 , 9.6×10^4 , $8.57 \times 10^4 = 78.66$
2,8,14	5mg/L Colchicine	9.53×10^4 , 6.73×10^4 , $8.27 \times 10^4 = 78.18$
3,9,15	15mg/L Colchicine	8.57×10^4 , 6.57×10^4 , $6.95 \times 10^4 = 77.36$
4,10,16	25mg/L "	7.97×10^4 , 7.51×10^4 , $6.99 \times 10^4 = 77.49$
5,11,17	50mg/L "	5.15×10^4 , 7.07×10^4 , $7.16 \times 10^4 = 77.46$
6,12,18	50mg/L α -Chac.	3.75×10^5 , 3.97×10^5 , $3.09 \times 10^5 = 73.60$

graphed + saved as COL - 6895.1PG on DBK 194

6/8/95 continued

191

FETAX experiment with Colchizine (new-50mg/L stock)
on albino embryos

DISH#	CONCEN.	(#) SURVIVAL				
		0	24	48	72	96
1	NC	25	25	19	18	18
2	5mg/L Colchizine	25	25	22	21	21
3	15mg/L "	25	25	18	17	17
4	25mg/L "	25	25	21	19	19
5	50mg/L "	25	25	22	21	19
6	50mg/L α -Chaconine	25	0	0	0	0

* Put in 3% Formalin on last day
Made into spreadsheet + saved as COL-6-8.WRI on DISK 194

7/12/95

Glycine and Glutamate on albino embryos
(~8-9 hours old) - 50mg/L stock for each,
30 min. incubation in 20 μ l di-4, saved
on DISK #187.

SCAN	CONC.	% Control	Intercepts
1	NC		1.37×10^5 (ave. = 1.4×10^5)
2	PC- α -Chac. (50mg/L) ^{5/95}		8.38×10^5
3-5	50mg/L glycine (pH=8)	97.2	$1.35 \times 10^5, 1.32 \times 10^5, 1.64 \times 10^5 \Rightarrow 1.44$
6-8	25mg/L "	96.6	$1.42 \times 10^5, 1.28 \times 10^5, 1.64 \times 10^5 \Rightarrow 1.45$
9-11	10mg/L "	91.5	$1.56 \times 10^5, 1.43 \times 10^5, 1.60 \times 10^5 \Rightarrow 1.53$
12-14	5mg/L "	85.4	$2.07 \times 10^5, 1.49 \times 10^5, 1.37 \times 10^5 \Rightarrow 1.64$
15-17	2.5mg/L "	88.1	$1.65 \times 10^5, 1.67 \times 10^5, 1.46 \times 10^5 \Rightarrow 1.59$
18-20	1.25mg/L "	81.4	$1.62 \times 10^5, 1.89 \times 10^5, 1.67 \times 10^5 \Rightarrow 1.72$
21-23	NC	9	$1.27 \times 10^5, 1.59 \times 10^5, 1.44 \times 10^5 \Rightarrow 1.43$
24, 25	50mg/L glutamate (pH=8)	122.8	$1.16 \times 10^5, 1.11 \times 10^5 \Rightarrow 1.14$
27, 28	25mg/L "	119.7	$1.15 \times 10^5, 1.19 \times 10^5 \Rightarrow 1.17$
30, 31	10mg/L "	116.7	$1.16 \times 10^5, 1.23 \times 10^5 \Rightarrow 1.20$
33, 34	5mg/L "	102.2	$1.24 \times 10^5, 1.50 \times 10^5 \Rightarrow 1.37$
36, 37	2.5mg/L "	117.6	$1.23 \times 10^5, 1.15 \times 10^5 \Rightarrow 1.19$
39, 40	1.25mg/L "	107.7	$1.18 \times 10^5, 1.41 \times 10^5 \Rightarrow 1.30$
43, 45	NC		$1.18 \times 10^5, 1.24 \times 10^5 \Rightarrow 1.21$
46, 47	25mg/L mimosine (pH=7)		$1.62 \times 10^5, 1.40 \times 10^5 \Rightarrow 1.51$

Graphed +

Saved as Glycine.IPG + Glutamat.IPG on DISK 194

7/14/95

Homocysteine on albino embryos (~8-9 hours old) - 50 mg/L stock, 30 min. inc. in 20 μ l di-4, saved on DISK #188.

SCAN	CONC.	Intercepts	graphed + saved as HOMOCYST. I.P.C. on DISK 194
1-3	NC	1.11×10^5 , 1.49×10^5 , $1.31 \times 10^5 \Rightarrow 1.30 \times 10^5$	
4-6	50 mg/L homocysteine (pH=8)	1.40×10^5 , 1.20×10^5 , $1.22 \times 10^5 \Rightarrow 1.27 \times 10^5$	
7-9	25 mg/L "	1.14×10^5 , 1.35×10^5 , $1.22 \times 10^5 \Rightarrow 1.24 \times 10^5$	

8/7/95 Test #1 (check page 18 for data)
 FETAX experiment with α -Chaconine and Folic acid on normal / African embryos from Mendi + Jason. Embryos were starting to neuralate while setting up test. Folic acid stock was 100 mg/L and α -Chac. stock was 50 mg/L. Folic Acid, α -Chac. + Fetax solution was at ~6 pH. Started test around 4:00pm + covered dishes with foil after test was setup. (**note: embryos were mixed together from 3 pairs of frogs)

DISH#	Concentration	ml α -C	ml FA	ml FTX	Survival				
					0	24	48	72	96
1	NC	0	0	10	25	25	25	24	24
2	NC	0	0	10	25	25	25	24	24
3	NC	0	0	10	25	25	25	25	25
4	1 mg/L FA, 2.5 mg/L α -C	0	0.1	9.9	25	24	21	20	20
5	"	0	0.1	9.9	25	24	23	23	23
6	"	0	0.1	9.9	25	25	24	23	22
7	2.5 mg/L FA, 2.5 mg/L α -C	0	0.25	9.75	25	25	25	24	24
8	"	0	0.25	9.75	25	25	25	25	24
9	"	0	0.25	9.75	25	25	24	24	24
10	5 mg/L FA, 2.5 mg/L α -C	0	0.5	9.5	25	25	25	24	24
11	"	0	0.5	9.5	25	25	23	22	22
12	"	0	0.5	9.5	25	25	25	25	25
13	10 mg/L FA, 2.5 mg/L α -C	0	1	9	25	25	24	23	23
14	"	0	1	9	25	25	24	23	23
15	"	0	1	9	25	25	22	21	21
16	20 mg/L FA, 2.5 mg/L α -C	0	2	8	25	25	24	24	24
17	"	0	2	8	25	25	23	23	23
18	"	0	2	8	25	25	24	22	22

DBL#	Concentration	ml ± C	ml FA	ml ETX	0	24	48	72	96
19	50mg/LFA, 2.5mg/Lt-C	0	5	5	25	25	24	23	23
20	"	0	5	5	25	25	23	23	23
21	"	0	5	5	25	24	22	22	22
22	0mg/LFA, 2.5mg/Lt-C	0.5	0	9.5	25	25	17	16	15
23	"	0.5	0	9.5	25	25	20	20	14
24	"	0.5	0	9.5	25	24	10	10	5
25	1mg/LFA, 2.5mg/Lt-C	0.5	0.1	9.4	25	25	20	19	18
26	"	0.5	0.1	9.4	25	25	15	13	10
27	"	0.5	0.1	9.4	25	25	17	15	15
28	25mg/LFA, 2.5mg/Lt-C	0.5	0.25	9.25	25	25	20	17	15
29	"	0.5	0.25	9.25	25	23	19	18	16
30	"	0.5	0.25	9.25	25	25	14	12	7
31	5mg/LFA, 2.5mg/Lt-C	0.5	0.5	9	25	25	18	18	15
32	"	0.5	0.5	9	25	25	15	15	14
33	"	0.5	0.5	9	25	25	21	21	21
34	10mg/LFA, 2.5mg/Lt-C	0.5	1	8.5	25	24	16	14	13
35	"	0.5	1	8.5	25	25	12	12	10
36	"	0.5	1	8.5	25	25	17	15	14
37	20mg/LFA, 2.5mg/Lt-C	0.5	2	7.5	25	25	18	15	14
38	"	0.5	2	7.5	25	25	14	14	14
39	"	0.5	2	7.5	25	25	16	14	11
40	50mg/LFA, 2.5mg/Lt-C	0.5	5	4.5	25	24	20	19	18
41	"	0.5	5	4.5	25	25	20	18	17
42	"	0.5	5	4.5	25	25	16	13	12
43	0mg/LFA, 5mg/Lt-C	1	0	9	25	25	1	0	0
44	"	1	0	9	25	25	6	6	0
45	"	1	0	9	25	25	1	0	0
46	1mg/LFA, 5mg/Lt-C	1	0.1	8.9	25	24	1	1	0
47	"	1	0.1	8.9	25	25	11	8	4
48	"	1	0.1	8.9	25	25	0	0	0
49	25mg/LFA, 5mg/Lt-C	1	0.25	8.75	25	24	0	0	0
50	"	1	0.25	8.75	25	24	0	0	0
51	"	1	0.25	8.75	25	25	1	0	0
52	5mg/LFA, 5mg/Lt-C	1	0.5	8.5	25	25	0	0	0
53	"	1	0.5	8.5	25	25	0	0	0
54	"	1	0.5	8.5	25	23	1	1	0
55	10mg/LFA, 5mg/Lt-C	1	1	8	25	23	1	0	0
56	"	1	1	8	25	24	1	0	0
57	"	1	1	8	25	25	0	0	0

Wt#	Concentration	ml α -C	ml FA	ml FTL	0	24	48	72	96
58	20mg/LFA, 5mg/L α -C	1	2	7	25	24	7	2	1
59	"	1	2	7	25	24	1	1	0
60	"	1	2	7	25	25	3	2	1
61	50mg/LFA, 5mg/L α -C	1	5	4	25	25	1	1	0
62	"	1	5	4	25	23	4	1	0
63	"	1	5	4	25	25	4	2	0
64	0mg/LFA, 10mg/L α -C	2	0	8	25	0	0	0	0
65	"	2	0	8	25	0	0	0	0
66	"	2	0	8	25	0	0	0	0
67	1mg/LFA, 10mg/L α -C	2	0.1	7.9	25	0	0	0	0
68	"	2	0.1	7.9	25	0	0	0	0
69	"	2	0.1	7.9	25	0	0	0	0
70	2.5mg/LFA, 10mg/L α -C	2	0.25	7.75	25	0	0	0	0
71	"	2	0.25	7.75	25	0	0	0	0
72	"	2	0.25	7.75	25	0	0	0	0
73	5mg/LFA, 10mg/L α -C	2	0.5	7.5	25	0	0	0	0
74	"	2	0.5	7.5	25	0	0	0	0
75	"	2	0.5	7.5	25	0	0	0	0
76	10mg/LFA, 10mg/L α -C	2	1	7	25	0	0	0	0
77	"	2	1	7	25	2	0	0	0
78	"	2	1	7	25	0	0	0	0
79	20mg/LFA, 10mg/L α -C	2	2	6	25	0	0	0	0
80	"	2	2	6	25	0	0	0	0
81	"	2	2	6	25	0	0	0	0
82	50mg/LFA, 10mg/L α -C	2	5	3	25	4	0	0	0
83	"	2	5	3	25	7	0	0	0
84	"	2	5	3	25	7	0	0	0

Put in 3% Formalin on last day

Made into spreadsheets & saved as CHAC_FA.X, WQ1 }
 CHAC_FA2, WQ1 } DISK
 CHAC_FA3, WQ1 } 194
 CHAC_FA4, WQ1 }

Started scoring on 8/22/95, then will
 digitize whenever computer is free.
 Digitized. CB

Survival data graphed & saved on DISK 194. OAC1-87-IPG
 OAC2-87-IPG
 OAC3-87-IPG

8/17/95 (Data From 3/24/95) - Disk 172

α -Chaconine + Folic acid experiment on PT1. Took info from disk (#172) + put into this notebook because I couldn't find it in any other notebook. Used data + made a graph (saved on Disk 194) for Army. Saved as CHAC3_24.IPG.

SCAN#	CONCENTRATION	Intercept	
1	NC	4.76×10^4	} 4.62×10^4
2	NC	4.48×10^4	
4	5mg/L α -C	4.52×10^4	
5	10mg/L α -C	2.05×10^5	
6	50mg/L α -C	3.48×10^5	
8	10mg/L α -C, 5mg/L Folic Acid	2.17×10^5	} 2.73×10^5
13	10mg/L α -C, 5mg/L FA	3.28×10^5	
9	10mg/L α -C, 10mg/L FA	2.1×10^5	} 2.2×10^5
14	"	2.30×10^5	
10	10mg/L α -C, 20mg/L FA	3.78×10^4	} 3.45×10^5
15	"	3.12×10^5	
11	10mg/L α -C, 50mg/L FA	2.98×10^5	} 2.8×10^5
16	"	2.62×10^5	

8/21/95 TEST #2

FETAX experiment with α -Chaconine and Folic Acid on African embryos. Folic Acid stock was 100mg/L in fetax solution and α -Chaconine stock was 50mg/L (same as 8/7/95 experiment). All solutions were at pH 6.0-6.3. Started test @ 1:30pm + covered dishes with foil after test was setup.

DISH#	CONCENTRATION	ml α -C	ml FA	ml FTX	0	24	48	72	96
1	NC	0	0	10	25	25	25	25	19
2	NC	0	0	10	25	25	25	22	19
3	NC	0	0	10	25	25	25	25	19
4	1mg/L FA, 0 α -C	0	0.1	9.9	25	25	25	24	22
5	" "	0	0.1	9.9	25	25	24	23	22

SIS#	CONCENTRATION	ml dC	ml FA	ml FTX	0	24	48	72	96
6	2.5mg/LFA, 0 dC	0	0.25	9.75	25	25	25	25	25
7	" "	0	0.25	9.75	25	25	25	25	23
8	5mg/LFA, 0 dC	0	0.5	9.5	25	25	25	25	23
9	" "	0	0.5	9.5	25	25	25	24	24
10	10mg/LFA, 0 dC	0	1	9	25	25	24	24	23
11	" "	0	1	9	25	25	25	25	22
12	20mg/LFA, 0 dC	0	2	8	25	25	25	25	24
13	" "	0	2	8	25	25	24	24	19
14	50mg/LFA, 0 dC	0	5	5	25	25	25	22	22
15	" "	0	5	5	25	25	25	25	24
16	0FA, 2.5mg/L dC	0.5	0	9.5	25	25	24	23	22
17	" "	0.5	0	9.5	25	25	25	23	23 2
18	" "	0.5	0	9.5	25	25	25	24	24
19	1mg/LFA, 2.5mg/L dC	0.5	0.1	9.4	25	25	24	23	23
20	" "	0.5	0.1	9.4	25	25	25	25	25
21	" "	0.5	0.1	9.4	25	25	25	23	20
22	2.5mg/LFA, 2.5mg/L dC	0.5	0.25	9.25	25	25	25	25	24
23	" "	0.5	0.25	9.25	25	25	25	25	24
24	" "	0.5	0.25	9.25	25	25	25	25	25
25	5mg/LFA, 2.5mg/L dC	0.5	0.5	9	25	25	25	25	25
26	" "	0.5	0.5	9	25	25	25	24	24
27	" "	0.5	0.5	9	25	25	25	24	24
28	10mg/LFA, 2.5mg/L dC	0.5	1	8.5	25	25	25	25	23
29	" "	0.5	1	8.5	25	25	24	23	21
30	" "	0.5	1	8.5	25	25	25	24	23
31	20mg/LFA, 2.5mg/L dC	0.5	2	7.5	25	25	24	24	23
32	" "	0.5	2	7.5	25	25	24	24	23
33	" "	0.5	2	7.5	25	24	24	23	20
34	50mg/LFA, 2.5mg/L dC	0.5	5	4.5	25	25	25	24	21
35	" "	0.5	5	4.5	25	25	22	22	21
36	" "	0.5	5	4.5	25	25	25	24	24
37	0mg/LFA, 5mg/L dC	1	0	9	25	25	24	22	20
38	" "	1	0	9	25	25	23	21	19
39	" "	1	0	9	25	25	25	24	20
40	1mg/LFA, 5mg/L dC	1	0.1	8.9	25	25	23	21	18
41	" "	1	0.1	8.9	25	24	24	24	22
42	" "	1	0.1	8.9	25	24	23	21	19
43	2.5mg/LFA, 5mg/L dC	1	0.25	8.75	25	25	24	21	17
44	" "	1	0.25	8.75	25	25	24	23	22

DSH	CONCENTRATION	ml dC	ml FA	ml FTX	0	24	48	72	96
45	2.5mg/LFA, 5mg/LdC	1	0.25	8.75	25	25	22	20	16
46	5mg/LFA, 5mg/LdC	1	6.5	8.5	25	25	23	23	20
47	" "	1	0.5	8.5	25	25	25	23	21
48	" "	1	0.5	8.5	25	25	24	23	16
49	10mg/LFA, 5mg/LdC	1	1	8	25	25	21	20	17
50	" "	1	1	8	25	25	23	20	16
51	" "	1	1	8	25	25	22	17	10
52	20mg/LFA, 5mg/LdC	1	2	7	25	25	22	22	20
53	" "	1	2	7	25	24	24	20	14
54	" "	1	2	7	25	25	22	22	20
55	50mg/LFA, 5mg/LdC	1	5	4	25	25	25	24	23
56	" "	1	5	4	25	25	23	23	21
57	" "	1	5	4	25	25	24	22	18
58	0FA, 10mg/LdC	2	0	8	25	18	5	3	0
59	" "	2	0	8	25	3	0	0	0
60	1mg/LFA, 10mg/LdC	2	0.1	87.9	25	7	0	0	0
61	" "	2	0.1	7.9	25	7	0	0	0
62	2.5mg/LFA, 10mg/LdC	2	0.25	7.75	25	2	0	0	0
63	" "	2	0.25	7.75	25	5	1	0	0
64	5mg/LFA, 10mg/LdC	2	0.5	7.5	25	9	0	0	0
65	" "	2	0.5	7.5	25	9	1	1	0
66	10mg/LFA, 10mg/LdC	2	1	7	25	4	0	0	0
67	" "	2	1	7	25	7	0	0	0
68	20mg/LFA, 10mg/LdC	2	2	6	25	5	0	0	0
69	" "	2	2	6	25	5	0	0	0
70	50mg/LFA, 10mg/LdC	2	5	3	25	14	7	5	0
71	" "	2	5	3	25	13	1	1	0

Put in 3% formalin on Day 4 (96 hour).
 Digitized + scored. Didn't like this data too much.
 (the malformation data)

Test #2 Survival data is on page 32.

Spreadsheets saved as ACFA82A.wal
 ACFA82B.wal
 ACFA82C.wal
 ACFA82D.wal } DTSK
 194

8/29/95 TEST #3

(Check page 17 for data)

FETAX experiment with α -Chaconine and Folic acid on African embryos. Folic Acid Stock was 100mg/L in Fetax solution and α -Chaconine stock was 50mg/L in Fetax solution. All solutions were at pH 6.0-6.3. Started test at 11:30am & covered dish with foil.

ASH	CONCENTRATION	ml α -C	ml FA	ml FTX	0	24	48	72	96
1	NC	0	0	10	25	25	25	25	25
2	NC	0	0	10	25	23	21	20	1
3	NC	0	0	10	25	25	23	22	2
4	0 α -C, 1mg/L FA	0	0.1	9.9	25	25	25	25	2
5	"	0	0.1	9.9	25	24	21	21	2
6	"	0	0.1	9.9	25	23	23	22	2
7	0 α -C, 2.5mg/L FA	0	0.25	9.75	25	25	22	22	2
8	"	0	0.25	9.75	25	24	23	22	2
9	"	0	0.25	9.75	25	25	23	23	2
10	0 α -C, 5mg/L FA	0	0.5	9.5	25	23	22	21	21
11	"	0	0.5	9.5	25	25	25	25	2
12	"	0	0.5	9.5	25	23	23	22	2
13	0 α -C, 10mg/L FA	0	1	9	25	24	24	24	24
14	"	0	1	9	25	24	22	22	22
15	"	0	1	9	25	25	25	25	25
16	0 α -C, 20mg/L FA	0	2	8	25	23	23	23	23
17	"	0	2	8	25	24.5	24.5	24.5	25
18	"	0	2	8	25	25	25	25	25
19	0 α -C, 50mg/L FA	0	5	5	25	24	21	21	21
20	"	0	5	5	25	25	25	25	25
21	"	0	5	5	25	25	24	24	24
22	2.5mg/L α -C, 0 FA	0.5	0	9.5	25	24	22	22	20
23	"	0.5	0	9.5	25	24	23	21	20
24	"	0.5	0	9.5	25	23	22	22	22
25	2.5mg/L α -C, 1mg/L FA	0.5	0.1	9.4	25	24	22	22	21
26	"	0.5	0.1	9.4	25	24	24	24	24
27	"	0.5	0.1	9.4	25	23	19	19	19
28	2.5mg/L α -C, 2.5mg/L FA	0.5	0.25	9.25	25	24	22	22	22
29	"	0.5	0.25	9.25	25	24	24	22	22
30	"	0.5	0.25	9.25	25	24	24	23	23

DISA	CONCENTRATION	ml dC	ml FA	ml FTX	0	24	48	72	96
31	2.5mg/LdC, 5mg/LFA	0.5	0.5	9	25	24	22	22	22
32	"	0.5	0.5	9	25	24	22	22	22
33	"	0.5	0.5	9	25	23	22	22	22
34	2.5mg/LdC, 10mg/LFA	0.5	1	8.5	25	25	24	24	24
35	"	0.5	1	8.5	25	23	23	23	23
36	"	0.5	1	8.5	25	23	22	21	21
37	2.5mg/LdC, 20mg/LFA	0.5	2	7.5	25	23	23	23	22
38	"	0.5	2	7.5	25	25	23	21	20
39	"	0.5	2	7.5	25	24	21	20	20
40	2.5mg/LdC, 50mg/LFA	0.5	5	4.5	25	24	23	22	22
41	"	0.5	5	4.5	25	24	23	22	22
42	"	0.5	5	4.5	25	24	24	24	24
43	5mg/LdC, 0FA	1	0	9	25	24	15	9	7
44	"	1	0	9	25	24	17	13	13
45	"	1	0	9	25	25	20	18	18
46	5mg/LdC, 1mg/LFA	1	0.1	8.9	25	25	22	14	14
47	"	1	0.1	8.9	25	25	24	17	13
48	"	1	0.1	8.9	25	25	23	23	23
49	5mg/LdC, 2.5mg/LFA	1	0.25	8.75	25	24	21	20	20
50	"	1	0.25	8.75	25	24	20	13	11
51	"	1	0.25	8.75	25	23	22	16	15
52	5mg/LdC, 5mg/LFA	1	0.5	8.5	25	25	23	15	13
53	"	1	0.5	8.5	25	25	19	14	14
54	"	1	0.5	8.5	25	24	21	18	17
55	5mg/LdC, 10mg/LFA	1	1	8	25	25	16	15	11
56	"	1	1	8	25	24	17	13	13
57	"	1	1	8	25	24	21	16	16
58	5mg/LdC, 20mg/LFA	1	2	7	25	23	17	17	17
59	"	1	2	7	25	23	20	16	16
60	"	1	2	7	25	21	17	14	14
61	5mg/LdC, 50mg/LFA	1	5	4	25	24	21	21	21
62	"	1	5	4	25	25	23	22	22
63	"	1	5	4	25	25	21	19	18
64	10mg/LdC, 0FA	2	0	8	25	6	0	0	0
65	"	2	0	8	25	11	0	0	0
66	"	2	0	8	25	16	0	0	0
67	10mg/LdC, 1mg/LFA	2	0.1	7.9	25	1	0	0	0
68	"	2	0.1	7.9	25	0	0	0	0
69	"	2	0.1	7.9	25	19	0	0	0

SS#	CONCENTRATION	ml dC	ml FA	ml FX	0	24	48	72	96
70	10mg/L dC, 2.5mg/L FA	2	0.25	7.75	25	1	0	0	0
71	"	2	0.25	7.75	25	3	0	0	0
72	"	2	0.25	7.75	25	12	0	0	0
73	10mg/L dC, 5mg/L FA	2	0.5	7.5	25	4	0	0	0
74	"	2	0.5	7.5	25	11	0	0	0
75	"	2	0.5	7.5	25	19	0	0	0
76	10mg/L dC, 10mg/L FA	2	1	7	25	9	0	0	0
77	"	2	1	7	25	7	0	0	0
78	"	2	1	7	25	13	0	0	0
79	10mg/L dC, 20mg/L FA	2	2	6	25	4	0	0	0
80	"	2	2	6	25	12	0	0	0
81	"	2	2	6	25	20	1	0	0
82	10mg/L dC, 50mg/L FA	2	5	3	25	21	14	8	7
83	"	2	5	3	25	22	2	2	0
84	"	2	5	3	25	23	0	0	0

Put in 3% formalin on last day (9/2/95)

Digitized + Scored also. Made into spreadsheets +
 Saved on DBK 194 as AC-FA-1.WQ1 AC-FA-3.WQ1
 AC-FA-2.WQ1 AC-FA-4.WQ1

9/6/95

PTI experiment with Vinblastine on albino
 embryos (50mg/L Vinblastine stock.)

DBK #198 - 30 min. incubation, 20ul di-4

SCAN	CONCENTRATION	intercepts	Avg
1-4	NC	5.96E4, 5.13E4, 6.49E4, 5.44E4	(5.76E4)
5-8	50mg/L Vinblastine	5.91E4, 5.24E4, 5.43E4, 5.56E4	(5.54E4)
9-12	25mg/L Vinblastine	5.72E4, 5.72E4, 5.82E4, 5.60E4	(5.72E4)
13-16	10mg/L "	4.66E4, 5.07E4, 5.20E4, 5.55E4	(5.12E4)
17-20	6.25mg/L "	5.36E4, 5.46E4, 5.94E4, 6.20E4	(5.79E4)
21-24	3.125mg/L "	5.43E4, 4.95E4, 5.87E4, 5.27E4	(5.38E4)
25	50mg/L dChaconine	4.79E4	

concentration	% of Control	Conc	% of Contr
50mg/L Vinblastine	96.2	3.125mg/L	93.4
25mg/L "	99.3		
10mg/L "	88.9		
6.25mg/L "	101		

graphed (using inverse)
 on DBK 198 - Vinb 9.6.IPL

9/19/95

DISK 194

graphs saved as OACFAS29.IPG Data saved as OAC1829.GP etc...
ZACFAS29.IPG
SACFAS29.IPG
IACFAS29.IPGCalculating % survival with α -Chaconne + Foliz
Acid data from test #3 (8/29/95) - % Survival

DAY 1	0mg/L α C	2.5mg/L α C	5mg/L α C	10mg/L α C
0mg/L FA	97.3%	94.67%	97.3%	440%
1mg/L FA	96%	94.67%	100%	26.67%
2.5mg/L FA	98.67%	96%	94.67%	21.3%
5mg/L FA	94.67%	94.67%	98.67%	45.3%
10mg/L FA	97.3%	94.67%	97.3%	38.67%
20mg/L FA	97.3%	96%	89.3%	48%
50mg/L FA	98.67%	96%	98.67%	88%
DAY 2				
0 FA	92%	89.3%	69.3%	0%
1 "	92%	86.67%	92%	0%
2.5 "	90.67%	93.3%	84%	0%
5 "	93.3%	88%	84%	6%
10 "	94.67%	92%	72%	0%
20 "	97.3%	89.3%	72%	1.3%
50 "	93.3%	93.3%	86.67%	21.3%
DAY 3				
0 FA	89.3%	86.67%	53.3%	0%
1 "	90.67%	86.67%	72%	0%
2.5 "	89.3%	89.3%	65.3%	0%
5 "	90.67%	88%	62.67%	0%
10 "	94.67%	90.67%	58.67%	0%
20 "	97.3%	85.3%	62.67%	0%
50 "	93.3%	90.67%	82.67%	13.3%
DAY 4				
0 FA	86.67%	82.67%	50.67%	0%
1 "	89.3%	85.3%	66.67%	0%
2.5 "	89.3%	89.3%	61.3%	0%
5 "	90.67%	88%	58.67%	0%
10 "	94.67%	90.67%	53.3%	0%
20 "	97.3%	82.67%	62.67%	0%
50 "	93.3%	90.67%	81.3%	9.3%

* LOOK at 11/28/95 for info on more graphs than these 2 experiments. 202

graphs saved as: OACFA87.IPG
2ACFA87.IPG
3ACFA87.IPG
10ACFA87.IPG

data saved as:
OAC187.GP
OAC287.GP etc...

9/19/95 continued

Calculating % survival w/ α -Chac + Folic Acid
data from test #1 (8/7/95)

DAY 1	0mg/L α C	2.5mg/L α C	5mg/L α C	10mg/L α C
0mg/L FA	100%	98.7%	97.3%	0%
1mg/L FA	97.3%	100%	98.7%	0%
2.5mg/L FA	100%	97.3%	97.3%	0%
5mg/L FA	100%	100%	97.3%	0%
10mg/L FA	100%	98.7%	96%	2.7%
20mg/L FA	100%	100%	97.3%	0%
50mg/L FA	98.7%	98.7%	97.3%	24%

DAY 2				
0 FA	100%	62.7%	10.7%	0%
1 "	90.7%	69.3%	16%	0%
2.5 "	98.7%	70.7%	1.3%	0%
5 "	97.3%	72%	1.3%	0%
10 "	93.3%	60%	2.7%	0%
20 "	94.7%	64%	14.7%	0%
50 "	92%	74.7%	12%	0%

DAY 3				
0 FA	97.3%	61.3%	8%	0%
1 "	88%	62.7%	12%	0%
2.5 "	97.3%	62.7%	0%	0%
5 "	94.7%	72%	1.3%	0%
10 "	89.3%	54.7%	0%	0%
20 "	92%	57.3%	6.7%	0%
50 "	90.7%	66.7%	5.3%	0%

DAY 4				
0 FA	97.3%	45.3%	0%	0%
1 "	86.7%	57.3%	5.3%	0%
2.5 "	96%	50.7%	0%	0%
5 "	94.7%	66.7%	0%	0%
10 "	89.3%	49.3%	0%	0%
20 "	92%	52%	2.7%	0%
50 "	90.7%	62.7%	0%	0%

9/20/95

α -Chaconne experiment. Combined 3 α -Chac stocks together (each 50mg/L) to make 1 big α -Chac stock (50mg/L), then from that stock I made a 5mg/L stock of α -Chac.

Dishes 1-8: added 20ul di-4 + mc. for 30 min. 1 hour.

DISH	Concentration	ml α C	ml Ftx	DAY 0	DAY 1	
				#	* all data in misty's book (page 7) NOT RUN	
1	NC	0	10	25	added 20ul di-4	saved as SCAN1 DBK198
9	NC	0	10	25	* dyed + looked (20ul) at under scope	
17	NC	0	10	25		
2	50mg/L α Chac	10 (50 stock)	0	25	added 20ul di-4	saved as SCAN7. DBK198
10	50mg/L	10 (")	0	25	* dyed (20ul) + looked at under scope	(1.58E3) 25.8%
3	10mg/L	2 (50 stock)	8	25	added 20ul di-4	saved as SCAN6. DBK198
11	10mg/L	2 (")	8	25	* dyed (20ul) + looked at under scope	(1.21E3) 19%
4	5mg/L	10 (5 stock)	0	25	added 20ul di-4	saved as SCAN5. DBK198
12	5mg/L	10 (")	0	25	* dyed + looked at	(1.28E3) 206.4%
18	5mg/L	10 (")	0	25		
5	1mg/L	2 (5 stock)	98	25	added 20ul di-4	saved as SCAN4. DBK198
13	1mg/L	2 (")	98	25	* dyed + looked at	(1.27E3) 204.8%
19	1mg/L	2 (")	98	25		
6	0.5mg/L	1 (5 stock)	9	25	added 20ul di-4	saved as SCAN3. DBK198
14	0.5mg/L	1 (")	9	25	* dyed + looked at	(1.59E3) 256.4%
20	0.5mg/L	1 (")	9	25		
7	0.1mg/L	0.2 or 200ul	9.8	25	added 20ul di-4	saved as SCAN2 DBK198
15	0.1mg/L	200ul	9.8	25	* dyed + looked at	(911.26) 146.9%
21	0.1mg/L	200ul	9.8	25		
8	0.05mg/L	100ul	9.9	25	added 20ul di-4	saved as SCAN1 DBK198
16	0.05mg/L	100ul	9.9	25	* dyed + looked at	(620.13) 100%
22	0.05mg/L	100ul	9.9	25		

Graded + saved on Disk 198 as AC9_20.1

10/11/95

Catallo experiment with TCAB + TCAOB.

TCAB is orange color and TCAOB is yellow color.

Will be doing a FETAX experiment with African embryos. Weighed out 10mg of each + dissolved each in 20 ml of DMSO. Made 20mg/L stock of each toxicant + also made NC stock of 4% DMSO.

Albino Embryos vs. Alpha-Chac (Low Concentrations)

3:00pm

10.3.95 - Embryos approx 6 hrs old at 2:00 pm
when test started (Stg. 1-8)

Dish 1: NC for dishes 1-6

Dish 2: 0.5 mg/L α -chac for 26 hrs and di-8
for 30 min

Dish 3: 1.0 mg/L α -chac for 26 hrs and di-8
for 30 min

Dish 4: 2.5 mg/L α -chac for 26 hrs and di-8
for 30 min

Dish 5: 5.0 mg/L α -chac for 26 hrs and di-8
for 30 min

Dish 6: 10.0 mg/L α -chac for 26 hrs and di-8
for 30 min

Note: α -chac at pH 6.5

10.4.95 - Embryos divided from NC of 10.3.95
and placed in test dish (Stg. 13)

Dish 7: NC for dishes 7-13

Dish 8: inc in ~~7.5~~ fetax for 26 hrs and ~~2.5~~ 0.25 mg/L
 α -chac for 25.5 hrs and di-8 for 30 min

Dish 9: inc in fetax for 26 hrs and 0.50 mg/L
 α -chac for 25.5 hrs and di-8 for 30 min

Dish 10: inc in fetax for 26 hrs and 1.0 mg/L α -chac
for 25.5 hrs and di-8 for 30 min

Dish 11: inc in fetax for 26 hrs and 2.5 mg/L α -chac
for 25.5 hrs and di-8 for 30 min

Dish 12: inc in fetax for 26 hrs and 5.0 mg/L α -chac
for 25.5 hrs and di-8 for 30 min

Dish 13: inc in fetax for 26 hrs and 10.0 mg/L α -chac
for 25.5 hrs and di-8 for 30 min

PHOTOS: 1000 ASA Film, 5X photo exp. piece,
10X objective, B filter, red filter

- picture 1 - Dish 1, 2 sec.
- * picture 2 - Dish 1, 5 sec., same as picture 1
- picture 3 - Dish 1, 2 sec., different embryo from 1 & 2
- picture 4 - Dish 1, 2 sec., same embryo as 3.
- picture 5 - Dish 2, 2 sec., different embryo
- picture 6 - Dish 2, 5 sec., same as 5.
- picture 7 - Dish 2, 2 sec., different embryo
- * picture 8 - Dish 2, 5 sec., same as 7.
- picture 9 - Dish 3, 2 sec., different
- * picture 10 - Dish 3, 5 sec., same as 9
- picture 11 - Dish 3, 2 sec., different embryo
- picture 12 - Dish 3, 5 sec., same as 11
- picture 13 - Dish 4, 2 sec., different
- picture 14 - Dish 4, 5 sec., same as 13
- picture 15 - Dish 4, 2 sec., different embryo
- * picture 16 - Dish 4, 5 sec., same as 15
- picture 17 - Dish 5, 2 sec., different, mottled
- * picture 18 - Dish 5, 5 sec., same as 17, mottled
- picture 19 - Dish 5, 2 sec., different embryo, mottled
- picture 20 - Dish 5, 5 sec., same as 19, mottled
- picture 21 - Dish 6, 2 sec., different, mottled surface
- picture 22 - Dish 6, 5 sec., same as 21, mottled surface
- picture 23 - Dish 6, 2 sec., different embryo, mottled
- * picture 24 - Dish 6, 5 sec., same as 23, mottled

Albino Embryos vs α -Chac (Low concentrations)

10.5.9

Day 2 of Experiment Started on 10.4.95

4:30pm

Photos: 1000 ASA, 10X objective, 5X photo eye piece,
B-filter, red filter

Dish 1-6 incubated for 51 hrs in α -Chac +
25.5 hrs in di-8.

Holding V	Picture 1 - Dish 1, 1 sec.	Freakin' embryo	
	Picture 2 - " , 2 sec.	same as 1	
	Picture 3 - Dish 2, 1 sec.	different embryo	
	Picture 4 - Dish 2, 2 sec.	same embryo as 3	
	Picture 5 - Dish 3, 1 sec.	different embryo	
	Picture 6 - " , 2 sec.	same as 5	
	Picture 7 - Dish 4, 1 sec.	different embryo	
	Picture 8 - " , 2 sec.	same as 7	
	Picture 9 - Dish 5, 1 sec.	different embryo	
	Picture 10 - " , 2 sec.	same as 9	
	Picture 11 - Dish 6, 1 sec.	different embryo	
	Picture 12 - " , 2 sec.	same as 11	
	Picture 13 - Dish 8, 1 sec.	different embryo, not very bright	"
	Picture 14 - " , 2 sec.	same as 13	"
	Picture 15 - Dish 8, 1 sec.	different embryo	"
	Picture 16 - " , 2 sec.	same as 15	"
	Picture 17 - Dish 10, 1 sec.	different embryo, a little brighter	"
	Picture 18 - " , 2 sec.	same as 17	"
	Picture 19 - Dish 11, 1 sec.	different embryo	"
	Picture 20 - " , 2 sec.	same as 19	"
	Picture 21 - Dish 12, 1 sec.	different embryo, brighter than previous	"
	Picture 22 - " , 2 sec.	same as 21	"
	Picture 23 - Dish 13, 1 sec.	different, swollen, nonunfolding, some degrading	"
	Picture 24 - Dish 13, 2 sec.	same as 23	"
	Picture 25 - Dish 7, 2 sec.	different embryo \rightarrow no fluorescence	
	Dish 3, 2 sec.	different embryo	

Albino Embryos vs α -Chac (Low Concentration)

10.6.95

Day 3:

4:00pm

Dish 14 - 72+ hr old embryos inc in fetax for 48 hrs
and 0.25 α -chac for 24 hr and di-8 for 30 min

Dish 15 - 72+ hr old embryos inc in fetax for 48 hrs
and 0.50 mg/L α -chac for 24 hr and
di-8 for 30 min

Dish 16 - 72+ hr old embryos inc in fetax for 48 hrs
and 1.0 mg/L α -chac for 24 hr and di-8 for
30 min

Dish 17 - 72+ hr old embryos inc in fetax for 48 hrs
and 2.5 mg/L α -chac for 24 hr and di-8
for 30 min

Dish 18 - 72+ hr old embryos inc in fetax for 48 hrs
and 5.0 mg/L α -chac for 24 hr and
di-8 for 30 min

Dish 19 - 72+ hr old embryos inc in fetax for 48 hrs
and 10.0 mg/L α -chac. for 24 hr and
di-8 for 30 min

Dish 7 - redyed with di-8 for 30 min

Dish 10 - redyed with di-8 for 30 min

Dish 11 - redyed with di-8 for 30 min

Photos: 1000 ASA, 10x objective, 5x photoeye piece,
B-filter, red filter, photos taken in well plate

Picture 2 - Dish 7, 1 sec., embryo unfolded

Picture 3 - " 2 sec., same as 2

Picture 4 - Dish 10, 1 sec., embryo unfolded

Picture 5 - " 2 sec., same as 4

Picture 6 - Dish 11, 1 sec., embryo unfolded

Picture 7 - " 2 sec., same as 6

- ~~nothing~~
 picture 8 - Dish 14, 1 sec, embryo unfolded, "sickly", ^{possibly} dead
 picture 9 - Dish 14, 1 sec, " " " "
 * picture 10 - Dish 14, 2 sec, same embryo as 9
 picture 11 - Dish 15, 1 sec, embryo unfolded, normal looking
 * picture 12 - Dish 15, 2 sec, same embryo as 11, ^{not very bright}
 picture 13 - Dish 16, 1 sec, normal unfolded embryo, not as bright
 * picture 14 - Dish 16, 2 sec, same as 13.
 picture 15 - Dish 17, 1 sec, unfolded but degraded, ^{maybe} losing dye
 * picture 16 - Dish 17, 2 sec, same as 15
 picture 17 - Dish 18, 1 sec, broken up + degraded
 * picture 18 - Dish 18, 2 sec, same as 17
 picture 19 - Dish 19, 1 sec, degraded (all)
 * picture 20 - Dish 19, 2 sec, same as 19
 picture 21 - Dish 14, 5 sec, unfolded, normal
 picture 22 - Dish 15, 5 sec, unfolded, normal
 picture 23 - Dish 16, 5 sec, unfolded, normal
 picture 24 - Dish 17, 5 sec, unfolded, normal

FETAX. (10/12/95)

10/12/95

Set up FETAX experiment. Stocks were also made on this day. Experiment was set up at 4:30pm using 24 hour plus embryos, around stages 22-28.

DISH	CONC.	(4% DMSO) ml toxicant	(4% DMSO) ml FTX	SURVIVAL				
				DAY 0	DAY 24	DAY 48	DAY 72	OF 9
1	NC (4% DMSO FTX)	0	10	25	21			
2	NC L ")	0	10	25	25			
3	10mg/L TCADB (w/4% DMSO)	5 TCADB	5	25	20			
4	"	5	5	25	22			
5	5mg/L TCADB (")	2.5	7.5	25	23			
6	"	2.5	7.5	25	20			
7	2.5mg/L TCADB (")	1.25	8.75	25	25			
8	"	1.25	8.75	25	19			
9	1mg/L TCADB (")	0.5	9.5	25	21			
10	"	0.5	9.5	25	22			
11	0.5mg/L TCADB (")	0.25	9.75	25	23			
12	"	0.25	9.75	25	21			
13	0.25mg/L TCADB (")	0.125	9.875	25	24			
14	"	0.125	9.875	25	24	17		
15	0.1mg/L TCADB (")	0.05	9.95	25	24			
16	"	0.05	9.95	25	25			
17	NC (4% DMSO FTX)	0	10	25	24			
18	NC (")	0	10	25	23			
19	10mg/L TCAB (w/4% DMSO)	5 TCAB	5	25	21			
20	"	5	5	25	19			
21	5mg/L TCAB (")	2.5	7.5	25	25			
22	"	2.5	7.5	25	20			
23	2.5mg/L TCAB (")	1.25	8.75	25	22			
24	"	1.25	8.75	25	24			
25	1mg/L TCAB (")	0.5	9.5	25	23			
26	"	0.5	9.5	25	25			
27	0.5mg/L TCAB (")	0.25	9.75	25	25			
28	"	0.25	9.75	25	20			

CONCEN	(4% DMSO) ml toxicant	(4% DMSO) ml FTX	SURVIVAL				
			DAY 0	DAY 24	DAY 48	DAY 72	DAY 96
0.25mg/L TCABL")	0.125	9.875	25	25			
"	0.125	9.875	25	24			
0.1mg/L TCABL")	0.05	9.95	25	24			
"	0.05	9.95	25	24			

saved spreadsheet
as TCAB1012.
on DISK 21

Not renewed because DMSO seems to be
killing all the embryos. On 48 hr. day,
they were all "chewed up" looking.

10/17/95 DATA From 7/14/95

α -Chac + Folic Acid. Could not find this
data in anyones notebook so I'm entering
it in mine. Scans on DISK 188

SCAN	CONC	Intercepts	% Control
11	NC	1.11×10^5	
2	NC	1.49×10^5	
3	NC	1.31×10^5	
32	NC	1.20×10^5	
22	505mg/L α Chac	7.16×10^5	178.8% 559.4%
23	10mg/L α Chac	4.11×10^5	321.1%
24	5mg/L α Chac	1.39×10^5	108.6%
25	5mg/L α C, 5mg/L FA	1.22×10^5	95.3%
26	5mg/L α C, 10mg/L FA	1.22×10^5	95.3%
27	5mg/L α C, 20mg/L FA	1.083×10^5	80.5%
33	10mg/L α C, 20mg/L FA	1.25×10^5	97.7%

graph & data
saved on
DISK 188
as ACFA7.14.IFF

10/20/95

Weighed out 10mg each of TCAB & TCAB.
Put each in a 50ml beaker & added 10ml
of DMSO (Fluka - 41650) to each toxicant. Put
on stirrer and let stir over the weekend.

10/25/95

Made a 50mg/L stock of α -Chaconine (from Mendel-
new). Then put 20 embryos in different
concentrations: NC, 50mg/L α C, 10mg/L, 5mg/L, 1mg/L

after scanned on computer. Saved on C:\.

10/26/95

Took neuralating embryos (albino) ~24 hrs. old (~stage 13-15) and put them into these dilutions of α -Chac (made 10/25/95): NC, 0.1mg/L α C, 1mg/L α C, 2mg/L α C + 5mg/L α Chac. Seven (7) embryos were put into each dish.

From a 50mg/L stock

α Chaconine :

		ml α C	ml FTX
50mg/L	=>	1ml	4ml
2mg/L	=>	0.4ml	9.6ml
1mg/L	=>	0.2ml	9.8ml
0.1mg/L	=>	0.02ml or 20ul	9.98ml

10/27/95

Took unfolded embryos (stage 26-27) from 10/25/95 (layed and put them into another dilution set. These embryos have been in FETAX solution since 10/25/95. Put 7 embryos in each dish (same as 10/26/95 setup).

No Results on this test.

10/31/95

Made 10mg/L Acrylamide stock solution for FETAX experiment. Set up the following dishes: (pH=6.85) @ 1:30 pm.

DISH	CONCEN.	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
1	NC	20	20	20	20	20
2	NC	20	20	19	19	19
3	10mg/L	20	19	19	19	19

CONCEN	DAY0	DAY1	DAY2	DAY3	DAY4
10mg/L	20	20	19	19	19
5mg/L	20	20	19	19	19
5mg/L	20	19	19	19	14
2.5mg/L	20	20	20	20	20
2.5mg/L	20	17	17	17	17
1mg/L	20	19	19	18	18
1mg/L	20	20	19	19	19

saved spreadsheet
as ACRY1031.wk
on disk 214.

↑
H₂O not changed
↑
fresh water
↑
fresh H₂O
↑
put in 3% Formalin

Set up dishes for PT1 experiment using Acrylamide + Tomatine (50mg/L) - pH = 6.3. Used 20ul di-4, inc. for 30min. Albinos. Saved on disk #205.

SCAN	CONCEN	Intercept	% Control
1	NC	2.02 E4	NC = 2.11 E4 ave.
2	50mg/L Tomatine	6.41 E5	3038%
3	25mg/L Tomatine	6.49 E5	3075.8%
4	10mg/L Tomatine	4.16 E5	1971.6%
5	5mg/L Tomatine	3.94 E5	1867.3%
6	NC	2.20 E4	
7	NC	3.39 E4	786
8	10mg/L Acrylamide	2.69 E4	79.8% 79.8%
9	5mg/L "	1.59 E4	46.9% 47%
10	2.5mg/L "	3.34 E4	98.8%
11	1mg/L "	2.91 E4	85.8% 86.1%
12	NC	3.37 E4	83.9%
13	10mg/L Acrylamide	2.83 E4	83.7%
14	5mg/L Acrylamide	2.76 E4	81.9% 81.7%
15	2.5mg/L "	2.42 E4	71.8% 71.6%
16	1mg/L "	2.73 E4	81.0% 80.8%

saved as ACRY1031.1PG
on disk 214

used 2.75 E4 for NC for Acrylamide
3.38

11/7/95

Set up albinos and put them in α -Chaconne solutions, 50mg/L (made 10/25/95): NC, 0.1, 1, 2, 5mg/L. put 6 embryos in each dish. Same as 10/26/95 exp.

11/8/95

213

Set up another dilution set of albino embryos from 11/7/95. NC, 5, 2, 1, .1 mg/L of α -Chaconine

	ml α C	ml FTY
5mg/L \Rightarrow	1 ml	9 ml
2mg/L \Rightarrow	0.4 ml	9.6 ml
1mg/L \Rightarrow	0.2 ml	9.8 ml
0.1mg/L \Rightarrow	20 μ l	9.98 ml

Put 6 embryos in each dish at stage 26-27.

From 11/7/95 setup:

5mg/L	-	4 alive
2mg/L	-	6 alive
1mg/L	-	5 alive
0.1mg/L	-	6 alive

11/9/95

Set up another dilution set of albinos from 11/7/95. NC, 5, 2, 1 + 0.1mg/L α Chac. Put 6 embryos in each dish.

From 11/7/95 Setup:

5 mg/L	-	0 alive
2 "	-	6 "
1 "	-	5 "
0.1 "	-	6 "

From 11/8/95 setup:

5mg/L	-	0 alive
2 "	-	6 "
1 "	-	6 "
0.1 "	-	6 "

Injected embryo from 11/9/95 NC with Hamilton syringe & needle (into the brain). Found that the needle is too large to inject with the Fluoro-Gold into the brain area of the embryo. Couldn't keep the embryo from moving as we pushed the needle into it. (Had the embryo under anesthesia.) Embryo did live after trying to inject it.

214

Saved
spreadsheet
as AC11-7.10Q1
on Disk 214

11/10/95

From 11/7/95:

5mg/L α Chac - Oaline
2mg/L " - 6 "
1mg/L " - 5 "
0.1mg/L " - 6 "

From 11/8/95:

- Oaline
- 6 "
- 6 "
- 6 "

From 11/9/95

- Oaline
- 6 "
- 6 "
- 6 "

11/13/95

Setup Tomatine experiment (50mg/L^{stock} made 10/30/95)

SCAN	CONCEN.	ml toxiant	ml FTX	Intercept	% Contr. ave.
1	NC	0	10	1.38E5	=> 1.27E5
2	50mg/L tomatine	10	0	1.07E6	842.5%
3	25mg/L "	5	5	1.12E6	881.9%
4	10mg/L "	2	8	9.44E5	743.3%
5	5mg/L "	1	9	8.48E5	667.7%
6	50mg/L α Chac(PC)	10	0	1.04E6	
7	NC	0	10	1.27E5	
8	50mg/L tomatine	10	0	8.71E5	685.8%
9	25 "	5	5	8.79E5	692.1%
10	10 "	2	8	7.64E5	601.6%
11	5 "	1	9	7.20E5	566.9%
12	NC	0	10	1.16E5	
13	50mg/L tomatine	10	0	7.88E5	620.5%
14	25 "	5	5	8.13E5	640.2%
15	10 "	2	8	6.89E5	542.5%
16	5 "	1	9	4.57E5	359.8%

Saved on Disk 2056

Used 20 μ l di-4 and approx. 80 embryos in each dish.

Saved data on Disk 206 plus graphed, too.

11/10/95

Used 48 hr+ old albino embryos for injection with Fluoro-Gold. Used the Swivel micromanipulator with both types of dissecting scopes. Placed embryo in the a well slide + tested it out. Used the 31G needles + the 5cc glass syringe. Very little success due to the large syringe (air bubbles). Made a wax mold to put the embryo into to keep it from sliding away from the syringe. We had a lot of trouble focusing on the embryo. We feel that the needle was too large to inject into the embryo. Embryos lived with visible side effects (brain damage, swimming irregular).

11/14/95

24 hr+ old embryos used for injection of Fluoro-Gold. We used the 36 gauge needle with the 1cc plastic syringe (worked better but needle hole too large). When injected with needle, the embryos busted. Kept for observation. Tried both dissecting scopes again. The American Optical (grey) was better for a general injection (did not give us a real close look) but the other (black) was better for closer viewing. We ordered some small needles + a smaller syringe + repeating dispenser from Alltech.

FETAX experiment with TCAB + TCAOB. Took 1ml of the EtOH solution (10mg TCAOB + TCAB in 10ml EtOH) and put into a 500ml vol. Flask. ~~Added~~ Then added 4ml of EtOH + then filled to the line with FETAX. Other attempts at mixed with FETAX failed - it all came out of solution. (Summary = 1ml sol. + 4ml EtOH + 495ml FETAX). Solution is still not good. TCAOB + TCAB have still precipitated out.

11/14/95 continued:

Next, I will try taking 10 ml (100 μ l) of the TCAOB + the TCAB solutions + putting them into FETAX. Add 4.9 ml of EtOH with this so we have a 1% solution still (of EtOH). This solution is a 2mg/L w/ 1% EtOH (TCAOB). The TCAB is also a 2mg/L solution w/ 1% EtOH. I put these solutions on the hot plates + put on low for overnight.

11/15/95

Set up FETAX experiment with Acrylamide. Used the Acrylamide stock (10mg/L - made 10/30/95). Embryos used were albinos at stage 26-27, approx. 48hr + old. Setup at 10:00 am.

DISH	CONCEN.	11/15/95 DAY 0	11/16/95 DAY 1	11/17/95 DAY 2	11/18/95 DAY 3	11/19/95 DAY 4	DAY 5
1	NC	25	24	24	21		0
2	NC	25	24	23	22		0
3	10mg/L Acrylamide	25	22	21	20		0
4	10mg/L "	25	25	24	24		1.7
5	5mg/L "	25	23	22	22		22
6	5mg/L "	25	24	24	24		0
7	2.5mg/L "	25	24	23	23		16
8	2.5mg/L "	25	22	22	21		15
9	1mg/L "	25	25	25	23		23
10	1mg/L "	25	25	25	25		25

renewed not renewed

Saved spreadsheet as ACRY 11/15/95 on Disk 2/4

Also setup a FETAX experiment with TCAOB + TCAB. (200 μ g/L w/ 1% EtOH). TCAOB pH = 6.8. TCAB pH = 6.6. Used embryos that were albinos at stage 26-27, approx. 48+hr. old. NC was made to be 1% EtOH FTX. The stock solutions of TCAOB + TCAB were of 1% EtOH also. Set up @ 12:00 pm.

217

CONCEN.	11/15/95 DAY 0	11/16 DAY 1	11/17 DAY 2	11/18 DAY 3	11/19 DAY 4	11/20 DAY 5
NC (1% EtOH)	25	23	22	22		0
NC (")	25	23	23	22		0
NC (")	25	25	24	21		0
200 µg/L TCAOB (10ml)	25	23	22	21		0
"	25	23	23	22		22
"	25	23	23	22		0
100 µg/L TCAOB (5ml)	25	24	24	21		17
"	25	22	20	19		0+5
"	25	25	24	23		0
50 µg/L TCAOB (2.5ml)	25	25	22	21		15
"	25	24	24	22		0
"	25	23	23	21		7
25 µg/L TCAOB (1.25ml)	25	23	22	22		14
"	25	24	24	20		0
"	25	25	24	23		0
NC (1% EtOH)	25	24	24	24		0
NC (")	25	25	25	23		0
NC (")	25	23	23	23		21
200 µg/L TCAB	25	24	23	22		17
"	25	23	23	22		19
"	25	21	19	19		16
100 µg/L TCAB	25	22	22	20		0
"	25	25	25	25		0
"	25	21	20	20		0
50 µg/L TCAB	25	24	23	22		0
"	25	25	24	24		22
"	25	24	24	24		16
25 µg/L TCAB	25	24	23	17		0
"	25	24	24	24		0
"	25	24	24	24		0

renewed not renewed

↑ saved this spreadsheet on 07/15/95
TCAB 11/15 was on 07/16/95

Made up 10 mg/L of Trimethyltin (TMT) in FETAX.
(hydroxide)

Put TMT (10 mg/L) in 3 dishes w/ 25 embryos in each. Same embryos as previous experiment.

11/16 DAY 1 - 22, 25, 25,

DAY 3 - 0, 0, 0

11/17 DAY 2 - 0, 19, 24

↑ saved spreadsheet on 07/15/95
TMT 11/15 was on 07/16/95

11/20/95

2-Chaconine and Folic Acid experiment on the PT1.
 Used the α Chac. stock from 10/25/95 (50mg/L) and
 new Folic Acid (100mg/L). Used 20ul di-4 in each
 dish. D3K 207. Albinos

	CONCEN	ml α C	ml FA	Intercept
	NC	0	0	2.8E5
	NC	0	0	3.77E5
	NC	0	0	2.63E5
	PC (50mg/L α C)	10	0	1.23E6
5	1mg/L FA	0	0.1	3.41E5
6	2.5mg/L FA	0	0.25	3.47E5
7	5mg/L FA	0	0.5	3.9E5
8	10mg/L FA	0	1	3.08E5
9	0FA, 2.5mg/L α C	0.5	0	2.86E5
10	1mg/L FA, 2.5mg/L α C	0.5	0.1	2.70E5
11	2.5mg/L FA, 2.5 "	0.5	0.25	2.63E5
12	5mg/L FA, 2.5 "	0.5	0.5	2.65E5
13	10mg/L FA, 2.5 "	0.5	1	2.5E5
14	0FA, 5mg/L α C	1	0	3.02E5
15	1mg/L FA, 5mg/L α C	1	0.1	2.65E5
16	2.5mg/L FA, 5 "	1	0.25	2.63E5
17	5mg/L FA, 5 "	1	0.5	2.87E5
18	10mg/L FA, 5 "	1	1	3.3E5
19	0FA, 10mg/L α C	2	0	3.8E5
20	1mg/L FA, 10 "	2	0.1	3.35E5
21	2.5mg/L FA, 10 "	2	0.25	3.28E5
22	5mg/L FA, 10 "	2	0.5	3.54E5
23	10mg/L FA, 10 "	2	1	3.75E5
24	1mg/L TMT			5.05E5
25	200mg/L TCAB			3.65E5
26	200mg/L TCAB			4.45E5

Did not like this experiment

Setup TMT test (10mg/L)

	DAY 0	DAY 1	DAY 2	DAY 3
TMT 1 -	25	25	25	0
TMT 2 -	25	24	24	0

11/21/95

2-Chaconine and Folic Acid experiment on the PIT1
 Made new α -Chac. stock today (50mg/L) & new
 Folic Acid stock (100mg/L). Used 20 μ l di-4, in
 each dish. Saved on Disk 207. Used 55 embryos
 for each run. Albino 5

CONCEN.	Intercept
NC	3.3E5
NC	3.8E5
NC	2.75E5
PC (10mg/L α C)	9.36E5
5FA 1mg/L FA,	3.26E5
6a 2.5FA,	3.44E5
7a 5FA,	3.78E5
8a 10FA,	3.77E5
9a 0FA, 25mg/L α C	2.36E5
10a 1FA "	4.32E5
11a 2.5FA "	3.68E5
12a 5FA "	3.33E5
13a 10FA "	2.38E5
14a 0FA, 5mg/L α C	2.46E5
15a 1FA "	3.68E5
16a 2.5FA "	4.2E5
17a 5FA "	2.57E5
18a 10FA "	3.47E5
19a 0FA, 10mg/L α C	6.84E5
20a 1FA "	6.26E5
21a 2.5FA "	1.04E6
22a 5FA "	8.71E5
23a 10FA "	7.96E5
24a PC (50mg/L α C)	1.59E6

11/28/95

Made different graphs for the α -Chac / FA data
 From 8/7/95 + 8/29/95. Saved on disk 194 as
 (Combined the data) Combo0AC, IPG (Cathy, ZPG, Cathy1, IPG,
 Cathy 2, ZPG are individuals), Combo2AC, IPG, Combo5AC,
 + Combo1AC \Rightarrow Combos of all graphs of DAYS 1-4.

11/28/95 continued

Saved data sets as: DISK 194

Cathy 0.GP	{	0 mg/L of Chaconine	{	Graph: Combo OAC.IPG
Cathy 1.GP				
Cathy 2.GP				
Cathy 3.GP				
		Days 1, 2, 3 + 4		
		Combined 8/7/95 + 8/29/95		

Cathy 4.GP	{	Day 1	{	2.5 mg/L of Chaconine	{	Graph Combo 2A	
Cathy 5.GP							Day 2
Cathy 6.GP							Day 3
Cathy 7.GP							Day 4
				Combined data			

Cathy 8.GP	{	Day 1	{	5 mg/L of Chac.	{	Graph: Combo 5AC.IPG	
Cathy 9.GP							Day 2
Cathy 10.GP							Day 3
Cathy 11.GP							Day 4
				Combined data			

Cathy 12.GP	{	Day 1	{	10 mg/L of Chac	{	Graph: Combo 1AC.IPG	
Cathy 13.GP							Day 2
Cathy 14.GP							Day 3
Cathy 15.GP							Day 4
				Combined data			

From page 8 + page 14 in this book.

Do not like this data

221

29/95 D3K194

Calculating % survival with d-chaconine +
Folic Acid data from test #2 (8/21/95) -
% Survival. Data on page 11!

DAY	0 mg/L dC	2.5 mg/L dC	5 mg/L dC	10 mg/L dC
0 mg/L FA	100%	100%	100%	42% (2 dishes)
1 mg/L FA	(2 dishes) 100%	100%	97.3%	28% "
2.5 mg/L FA	↓ 100%	100%	100%	14% "
5 mg/L FA	100%	100%	100%	36% "
10 mg/L FA	100%	100%	100%	22% "
20 mg/L FA	100%	98.67%	98.67%	20% "
50 mg/L FA	100%	100%	100%	54% "

DAY 2				(2 dishes)
0 mg/L FA	100%	98.67%	96%	10%
1 mg/L FA	(2 dishes) 98%	98.67%	93.3%	6%
2.5 mg/L FA	↓ 100%	100%	93.3%	2%
5 mg/L FA	100%	100%	96%	2%
10 mg/L FA	98%	98.67%	90.67%	0%
20 mg/L FA	98%	96%	90.67%	0%
50 mg/L FA	100%	96%	96%	16%

DAY 3				(2 dishes)
0 mg/L FA	96%	93.3%	89.3%	6%
1 mg/L FA	(2 dishes) 94%	94.67%	88%	0%
2.5 mg/L FA	↓ 100%	97.3%	85.3%	0%
5 mg/L FA	98%	96%	92%	2%
10 mg/L FA	98%	96%	76%	0%
20 mg/L FA	98%	94.67%	85.3%	0%
50 mg/L FA	94%	93.3%	92%	12%

DAY 4				(2 dishes)
0 mg/L FA	76%	90.67%	78.67%	0%
1 mg/L FA	(2 dishes) 88%	90.67%	78.67%	0%
2.5 mg/L FA	↓ 96%	97.3%	73.3%	0%
5 mg/L FA	94%	97.3%	76%	0%
10 mg/L FA	90%	89.3%	57.3%	0%
20 mg/L FA	88%	88%	72%	0%
50 mg/L FA	92%	88%	82.67%	0%

11/30/95 TEST #4 222

FETAX experiment with α -Chacemine + Folic acid on Albino embryos. Folic Acid stock was 100mg/L in FETAX solution + α -Chacemine stock was 50mg/L in FETAX solution made 11/30/95. All solutions were at pH 6.5-6.8. Started test at 2:30pm + covered dishes with Foil.

WELL	CONCENTRATION (mg/L)	0	24	48	72	96
1	0mg/L FA, 0mg/L α Chac	25	25	25	25	25
2	"	25	25	25	25	25
3	"	25	25	25	25	25
4	0.1mg/L FA, 0mg/L α C	25	25	25	25	25
5	"	25	25	25	25	25
6	"	25	25	25	25	25
7	0.25mg/L FA, 0mg/L α C	25	25	25	24	24
8	"	25	25	25	25	25
9	"	25	25	25	25	25
10	0.5mg/L FA, 0mg/L α C	25	25	25	25	25
11	"	25	25	25	25	25
12	"	25	25	25	25	25
13	1mg/L FA, 0mg/L α C	25	25	25	25	25
14	"	25	25	25	25	25
15	"	25	25	25	25	25
16	2mg/L FA, 0mg/L α C	25	25	25	25	25
17	"	25	25	25	25	25
18	"	25	25	25	25	25
19	5mg/L FA, 0mg/L α C	25	25	25	25	25
20	"	25	25	25	25	25
21	"	25	25	25	25	25
22	0mg/L FA, 2.5mg/L α C	25	24	22	14	11
23	"	25	25	25	19	11
24	"	25	25	25	20	1
25	1mg/L FA, 2.5mg/L α C	25	25	24	19	13
26	"	25	25	24	21	0
27	"	25	25	24	21	17
28	2.5mg/L FA, 2.5mg/L α C	25	25	23	22	23
29	"	25	25	25	22	23
30	"	25	25	24	18	15

DISH	CONCENTRATION	0	24	48	72	96
31	5mg/L FA, 2.5mg/L dC	25	25	25	17	8
32	"	25	25	25	18	14
33	"	25	25	24	21	19
34	10mg/L FA, 2.5mg/L dC	25	25	25	23	22
35	"	25	25	25	23	21
36	"	25	25	23	22	19
37	20mg/L FA, 2.5mg/L dC	25	25	25	22	16
38	"	25	25	24	23	23
39	"	25	25	24	22	19
40	50mg/L FA, 2.5mg/L dC	25	25	24	24	24
41	"	25	25	25	25	24
42	"	25	25	25	25	25
43	OFA, 5mg/L dC	25	22	9	0	0
44	"	25	22	9	0	0
45	"	25	23	13	0	0
46	1mg/L FA, 5mg/L dC	25	25	16	1	0
47	"	25	22	9	0	0
48	"	25	23	8	1	0
49	2.5mg/L FA, 5mg/L dC	25	24	11	0	0
50	"	25	20	6	0	0
51	"	25	21	8	0	0
52	5mg/L FA, 5mg/L dC	25	19	7	0	0
53	"	25	25	6	0	0
54	"	25	24	5	0	0
55	10mg/L FA, 5mg/L dC	25	24	6	0	0
56	"	25	22	9	0	0
57	"	25	21	11	0	0
58	20mg/L FA, 5mg/L dC	25	24	12	0	0
59	"	25	25	14	1	0
60	"	25	25	14	4	0
61	50mg/L FA, 5mg/L dC	25	25	21	6	2
62	"	25	25	20	1	0
63	"	25	25	23	4	0
64	OFA, 10mg/L dC	25	0	0	0	0
65	"	25	0	0	0	0
66	"	25	0	0	0	0
67	1mg/L FA, 10mg/L dC	25	0	0	0	0
68	"	25	0	0	0	0

DISK	CONCENTRATION	0	24	48	72	96
		25				
69	1mg/L FA, 10mg/L dC	25	0	0	0	0
70	2.5mg/L FA, 10mg/L dC	25	0	0	0	0
71	"	25	0	0	0	0
72	"	25	0	0	0	0
73	5mg/L FA, 10mg/L dC	25	0	0	0	0
74	"	25	0	0	0	0
75	"	25	0	0	0	0
76	10mg/L FA, 10mg/L dC	25	0	0	0	0
77	"	25	0	0	0	0
78	"	25	0	0	0	0
79	20mg/L FA, 10mg/L dC	25	0	0	0	0
80	"	25	0	0	0	0
81	"	25	0	0	0	0
82	50mg/L FA, 10mg/L dC	25	10	0	0	0
83	"	25	16	1	0	0
84	"	25	12	0	0	0

Put in 3% Formalin on last day.

Spreadsheets saved as AC11_30.WQ1 - Day 1
 AC11_30A.WQ1 - Day 2
 AC11_30B.WQ1 - Day 3
 AC11_30C.WQ1 - Day 4

ON DISK #194

Saved data sets as: DISK194

11-30A.GP	} 0mg/L α Chaconine Days 1, 2, 3, 4	} Graph: DAC1130.IPG
11-30B.GP		
11-30C.GP		
11-30D.GP		

11-30E.GP	} 2.5mg/L α Chaconine Days 1, 2, 3, 4	} Graph: 2AC1130.IPG
11-30F.GP		
11-30G.GP		
11-30H.GP		

30I.GP	}	5mg L & Choc	}	Graph: 5AC1130.JPG
30J.GP				
30K.GP				
30L.GP				

30M.GP	}	10mg/L & Choc	}	Graph: 10AC1130.JPG
30N.GP				
30O.GP				
30P.GP				

Days 1-4
Day 3 & 4 are the same

12/5/95

Took all survival data from TESTS 1, 3 & 4
and graphed them. Saved on Disk 209.209
Graphs are saved as: ~~AVG~~ AVG01.JPG (average of all 3 tests - Day 1)

AVG02.JPG (ave of all 3 tests - Day 2)
AVG03.JPG
AVG04.JPG

All the data was saved on Disk 209, also.
All the data was transformed (Y/A $A=.75$) & then averaged. Each transformed data set was saved & then each set was saved again after being averaged.

Made tables in WordPerfect 5.1 on Disk 207.209.
Saved as TESTS134.WPM.

Test #5 was also put in tables in WP 5.1. The new filename is TEST1345.WPM.

On 12/2/95 - Included test 5 in all the graphs.
Now saved as: AVG01_A.JPG (average of tests 1, 3, 4, 5 - Day 1)
Disk 209 {
AVG02_A.JPG
AVG03_A.JPG
AVG04_A.JPG

2/5/95

Calculating % survival w/ α Chal + Folic Acid
data from TEST #4 (11/30/95) - % SURVIVAL

DAY 1	0mg/L α C	2.5mg/L α C	5mg/L α C	10mg/L α C
0mg/L FA	100%	98.67%	89.3%	0%
1 "	100%	100%	93.3%	0%
2.5 "	100%	100%	86.67%	0%
5 "	100%	100%	90.67%	0%
10 "	100%	100%	89.3%	0%
20 "	100%	100%	98.67%	0%
50 "	100%	100%	100%	50.67

DAY 2	0mg/L FA	2.5mg/L α C	5mg/L α C	10mg/L α C
0mg/L FA	100%	96%	42.67%	0%
1 "	100%	96%	44%	0%
2.5 "	100%	96%	33.3%	0%
5 "	100%	98.67%	24%	0%
10 "	100%	97.3%	34.67%	0%
20 "	100%	97.3%	53.3%	0%
50 "	100%	98.67%	85.3%	1.33%

DAY 3	0mg/L FA	2.5mg/L α C	5mg/L α C	10mg/L α C
0mg/L FA	100%	70.67%	0%	0%
1 "	100%	81.3%	2.67%	0%
2.5 "	98.67%	84%	0%	0%
5 "	100%	74.67%	0%	0%
10 "	100%	90.67%	0%	0%
20 "	100%	89.3%	6.67%	0%
50 "	100%	98.67%	14.67%	0%

DAY 4	0mg/L FA	2.5mg/L α C	5mg/L α C	10mg/L α C
0mg/L FA	100%	30.67%	0%	0%
1 "	100%	40%	0%	0%
2.5 "	98.67%	78.67%	0%	0%
5 "	100%	54.67%	0%	0%
10 "	100%	82.67%	0%	0%
20 "	100%	77.3%	0%	0%
50 "	100%	97.3%	2.67%	0%

12/5/95 continued

Set up a small test with TNT using Stovers embryos.

sawed spreadsheet
on disk 214

CONCEN.	0	24	48	72	96
NC	15	14	14	14	14
NC	15	14	14	14	14
NC	15	15	15	15	15
NC	15	14	14	13	13
1mg/L TNT	15	15	15	15*	14*
1mg/L TNT	15	15	14	14*	13*
1mg/L TNT	15	15	15	15*	15*
1mg/L TNT	15	15	14	14*	13*
10mg/L TNT (PC)	15	15	0	0	0

* deformed

12/8/95

DISK 208 α Chac vs Folic Acid - PTL run
α C-Stock (50mg/L) - 12/8/95 pH 6.3 - Used Africans

SAN	CONCEN	ml α C	ml FA	Intercept
1	NC	0	0	1.95E5
2	PC (50mg/L)	10	0	1.166E6
3	1mg/L FA	0	.1	2.85E5
4	2.5 FA	0	.25	4.17E5
5	5	0	.5	3.3E5
6	10	0	1	3.3E5
7	DFA, 2.5 α C	.5	0	4.4E5
8	2.5 FA, "	.5	.1	2.84E5
9	5 FA, "	.5	.25	2.82E5
10	10 FA, "	.5	.5	1.94E5
11	10 FA, "	.5	1	1.36E5
12	NC	0	0	2.2E5
13	NC	0	0	4.03E5
14	PC (10mg/L)	2	0	9.58E5
15	0 FA, 5 α C	1	0	5.62E5
16	1 " , "	1	.1	6.13E5
17	2.5 " , "	1	.25	5.68E5
18	5 " , "	1	.5	7.66E5
19	10 " , "	1	1	7.51E5

CONCEN	ml α C	ml FA	Intercept
0FA, 10 α C	2	0	1.06E6
1 " "	2	.1	8.05E5
2.5 " "	2	.25	1.20E6
5 " "	2	.5	8.85E5
20 " "	2	1	8.9E5
NC	0	0	

continued on page 42. Scans 25-33

12/8/95 TEST #5 (Africans)

FETAX experiment with α -Chac + Folic Acid on Normal embryos. Folic Acid stock was 100mg/L in FETAX solution + α -Chaconine stock was 50mg/L in FETAX solution made 12/8/95. All solutions were 6.3-6.4. Started test at 3:30pm. Covered dishes with foil.

ASH	CONCENTRATION (mg/L)	0	24	48	72	96
1	NC	25	25	25	25	25
2	NC	25	25	25	25	25
3	NC	25	25	25	25	25
4	0mg/LFA, 0mg/L α C	25	25	24	24	24
5	"	25	25	25	25	25
6	"	25	25	25	25	25
7	2.5mg/LFA, 0mg/L α C	25	25	25	25	25
8	"	25	25	25	25	25
9	"	25	25	25	25	25
10	5mg/LFA, 0mg/L α C	25	25	25	25	25
11	"	25	25	25	25	25
12	"	25	25	25	25	25
13	10mg/LFA, 0mg/L α C	25	25	25	25	25
14	"	25	25	25	25	25
15	"	25	25	25	25	25
16	20mg/LFA, 0mg/L α C	25	25	25	25	25
17	"	25	25	25	25	25
18	"	25	25	25	25	25
19	50mg/LFA, 0mg/L α C	25	25	25	25	25
20	"	25	25	25	25	25

CONCEN (mg/L)

0

24

48

72

96

50mg/L FA, 0mg/L dC

25

25

25

25

25

0mg/L FA, 2.5mg/L dC

25

25

3

3

0

"

25

25

13

6

3

"

25

25

3

0

0

1mg/L FA, 2.5mg/L dC

25

25

14

6

2

"

25

25

15

6

0

"

25

25

10

1

1

2.5mg/L FA, 2.5mg/L dC

25

25

16

11

2

"

25

25

19

16

10

"

25

25

24

5

1

5mg/L FA, 2.5mg/L dC

25

25

18

0

0

"

25

25

21

10

3

"

25

25

9

1

1

10mg/L FA, 2.5mg/L dC

25

25

20

10

0

"

25

25

22

14

5

"

25

24

17

14

1

20mg/L FA, 2.5mg/L dC

25

25

24

10

0

"

25

25

21

13

5

"

25

25

23

9

0

50mg/L FA, 2.5mg/L dC

25

25

24

22

21

"

25

25

24

23

23

"

25

25

24

24

24

0FA, 5mg/L dC

25

23

0

0

0

"

25

23

0

0

0

"

25

24

0

0

0

1mg/L FA, 5mg/L dC

25

25

0

0

0

"

25

25

0

0

0

"

25

25

0

0

0

2.5mg/L FA, 5mg/L dC

25

25

0

0

0

"

25

25

0

0

0

"

25

24

0

0

0

5mg/L FA, 5mg/L dC

25

24

0

0

0

"

25

25

0

0

0

"

25

23

0

0

0

10mg/L FA, 5mg/L dC

25

25

0

0

0

"

25

25

0

0

0

"

25

25

0

0

0

20mg/L FA, 5mg/L dC

25

25

0

0

0

"

25

25

0

0

0

	CONCEN (mg/L)	0	24	48	72	96
60	20mg/L FA, 5mg/L αC	25	25	0	0	0
61	50mg/L FA, 5mg/L αC	25	25	0	0	0
62	"	25 24	24	0	0	0
63	"	25	25	2	0	0
64	0 FA, 10mg/L αC	25	0	0	0	0
65	"	25	0	0	0	0
66	"	25	3	0	0	0
67	1mg/L FA, 10mg/L αC	25	8	0	0	0
68	"	25	0	0	0	0
69	"	25	0	0	0	0
70	2.5mg/L FA, 10mg/L αC	25	0	0	0	0
71	"	25	0	0	0	0
72	"	25	0	0	0	0
73	5mg/L FA, 10mg/L αC	25	0	0	0	0
74	"	25	0	0	0	0
75	"	25	0	0	0	0
76	10mg/L FA, 10mg/L αC	25	13	0	0	0
77	"	25	15	0	0	0
78	"	25	0	0	0	0
79	20mg/L FA, 10mg/L αC	25	1	0	0	0
80	"	25	20	0	0	0
81	"	25	0	0	0	0
82	50mg/L FA, 10mg/L αC	25	20	0	0	0
83	"	25	13	0	0	0
84	"	25	15	0	0	0

Saved spreadsheets on Disk 208 as:

AC-FA1.WQ1

AC-FA2.WQ1

AC-FA3.WQ1

AC-FA4.WQ1

Put in 3% Formalin on last day.

Continued From page 39.

DAY	CONCEN	ml α C	ml FA	Intercept
25	20mg/LFA, 0 α C	0	82	3.26E5
26	50mg/LFA, 0 α C	50	5	4.72E5
27	20 " , 2.5mg/L α C	0.5	2	2.61E5
28	50 " , " "	.5	5	5.35E5
29	20 " , 5 α C	1	2	5.86E5
30	50 " , " "	1	5	4.63E5
31	20 " , 10 α C	2	2	1.21E6
32	50 " , " "	2	5	4.18E5
33	NC	0	0	6.33E5

12/12/95

Combined all data of all 4 α Chac/FA trials (tests 1, 3, 4, 5) + made graphs.

Disk 209 saved as AVG-D1-A.JPG

AVG-D2-A.JPG

AVG-D3-A.JPG

AVG-D3-A.JPG

The data was saved as:

DAY 1	0mg/L α C \rightarrow D1-OAC.GP	data was Averaged + saved as:
	2.5mg/L α C \rightarrow D1-2AC.GP	
	5mg/L α C \rightarrow D1-5AC.	
	10mg/L α C \rightarrow D1-1AC.	
	D2-OAC.	AVD1-OAC.GP
	D2-2AC.	AVD1-2AC
	D2-5AC.	AVD1-5AC
	D2-1AC.	AVD1-1AC
	D3-OAC.	AVD2-OAC
	\downarrow	AVD2-2AC
	etc.	\downarrow
		etc.

Look at page 36 for more info.

12/12/95

Calculating % survival w/ aChac + Foliz
Acid data from 12/8/95 TEST #5

DAY 1	0mg/L aC	2.5mg/L aC	5.0mg/L aC	10mg/L
0mg/L FA	100%	100%	93.3%	4%
1 "	100%	100%	100%	10.7%
2.5 "	100%	100%	98.7%	0%
5 "	100%	100%	96%	0%
10 "	100%	98.7%	100%	24%
20 "	100%	100%	100%	28%
50 "	100%	100%	98.7%	64

DAY 2	0mg/L FA	2.5mg/L aC	5.0mg/L aC	10mg/L
0mg/L FA	100%	25.3%	0%	0%
1 "	98.7%	52%	0%	0%
2.5 "	100%	78.7%	0%	0%
5 "	100%	64%	1.3%	0%
10 "	100%	78.7%	0%	0%
20 "	100%	90.7%	0%	0%
50 "	100%	97.3%	2.7%	0%

DAY 3	0mg/L FA	2.5mg/L aC	5.0mg/L aC	10mg/L
0mg/L FA	100%	12%	0%	0%
1 "	98.7%	17.3%	0%	0%
2.5 "	100%	42.7%	0%	0%
5 "	100%	14.7%	0%	0%
10 "	100%	50.7%	0%	0%
20 "	100%	42.7%	0%	0%
50 "	100%	92%	0%	0%

DAY 4	0mg/L FA	2.5mg/L aC	5.0mg/L aC	10mg/L
0mg/L FA	100%	4%	0%	0%
1 "	98.7%	4%	0%	0%
2.5 "	100%	17.3%	0%	0%
5 "	100%	5.3%	0%	0%
10 "	100%	8%	0%	0%
20 "	100%	6.7%	0%	0%
50 "	100%	10.7%	0%	0%

12/13/95

DISK 210 - Albinos

Ran TMT experiment on PT1. Used 10mg/L stock of TMT made 11/15/95. pH = 6.4.

	CONCEN.	ml TMT	mt.	
	NC	0	9.31E5	} 1.02 E6
	NC	0	1.11E6	
	1mg/L TMT	1	9.81E5	96.2%
	"	1	1.00E6	98.0%
	0.5mg/L TMT	.5	9.14E5	89.6%
	"	.5	9.54E5	93.5%
	0.2mg/L TMT	.2 or 200ul	8.62E5	84.5%
	"	.2 "	9.82E5	96.3%
	0.1 mg/L TMT	.1 or 100ul	9.45E5	92.6%
	"	.1 "	9.93E5	97.4%
	0.05mg/L TMT	.05 or 50ul	1.03E6	101.0%
	"	.05 or 50ul	1.05E6	103.0%
	0.01mg/L TMT	.01 or 10ul	9.99E5	97.9%
	"	.01 or 10ul	9.87E5	96.8%

graph saved as TMT12-13.IPG on DISK 214

Set up FETAX test using TMT (11/15/95 - 10mg/L stock)
Test started at 9:30 am. ~ Stages 8-9.

DISH	CONCEN	DAY0	DAY1	DAY2	DAY3	DAY4	DAY5
1	NC	10	10	10	10	10	10
2	1mg/L TMT	10	10	10	10	10	10*
3	0.5 mg/L "	10	10	10	10	10	10*
4	0.2 "	10	10	10	10	10	10
5	0.1 "	10	10	10	10	10	10
6	0.05 "	10	10	10	10	10	10
7	0.01 "	10	10	10	10	10	10

↑ saved as
TMT12-13.wal
DISK 214

12/14/95

Set up another FETAX test using TMT (same as above)
Test started at 8:30 am, ~ Stages 17-27.
Same embryos from 12/13/95.

3% form

DISH	CONCEN.	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	10	10	10	10	10

12/17/95 Continued

24	CONCEN.	DAY0	DAY1	DAY2	DAY3	DAY4
1	1mg/L TMT	10	10	10	10	10 *
2	.5 "	10	10	10	9	8 *
3	.2 "	10	10	10	10	10
4	.1 "	10	10	10	10	10
5	.05 "	10	10	10	10	10
6	.01 "	10	10	10	10	10
7	same as TMT 12-14. WAI on D13K 214					↑ 3% formalin

12/14/95

SYSTAT PROBIT~~Create data in Lotus~~~~Import from Lotus (Survival Files) i.e. DAYONEVR~~~~Create PROBIT Column~~

1. Go into SYSTAT
2. Go to File, Import/Export, Import, File, ESC.
Type file name (B:\DAYONEVR.WKS), ENTER
3. Save, ESC - type Filename^{↑ type (LOTUS)}
4. Double, ESC
5. GO!
6. ESC, ESC, ESC
7. Data, Edit, ENTER
8. ESC, type "USE "DAYONEVR"
9. ESC
10. Create new column named PROBIT. ENTER
11. ESC, Save as TEMP, ENTER.
12. QUIT (type)
13. Data!, ENTER
14. type LET PROBIT=ASN(SQR(NUMBER/25)) ENTER
15. Save (type) DAYONEVR ENTER
16. Yes
17. Run
18. QUIT
19. Edit! (check for data)
20. ESC & "Save DAYONEVR"

12/15/95

Set up another FETAX test using TMT using same embryos from 12/13/95, ~ stages 27-31. Test started @ 11:00am.

	CONCEN	DAY0	DAY1	DAY2	DAY3	DAY4
	NC	10	10	10	10	9
	1mg/L TMT	10	10	10	10	10 *
	0.5 "	10	10	10	10	10 *
	0.2 "	10	10	10	10	10
	0.1 "	10	10	10	10	10
	0.05 "	10	10	10	10	10
	0.01 "	10	10	10	10	10

Saved as TMT 12-15.wal on Disk 214 ↑ 3% formalin

* All concentrations of 0.5mg/L + 1mg/L => deformed. Not renewed, just recorded.

12/18/95

Saved as
TMT 12-18.wal
Disk 214

Digitized 225
on disk
saved as
TMT 12-18. PRN

Set up FETAX experiment with TMT and albino embryos. pH of TMT = 6.7, → 3% FORMALIN ON DAY 4 ITB

DISH	CONCEN	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	25	25	25	25	24
2	1mg/L TMT	25	25	25	25	0-18 def
3	.5 "	25	25	25	25	2-18 all def
4	.2 "	25	25	24	24	2-19 2?
5	.1 "	25	25	25	25	24 23
6	.05 "	25	25	25	25	25 23
7	.01 "	25	25	25	25	25 22
8	NC	25	25	22	22	25 21
9	1mg/L TMT	25	25	25	25	0
10	.5 "	25	24	22	22	14
11	.2 "	25	25	25	25	18 25
12	.1 "	25	25	25	25	24 24
13	.05 "	25	25	25	25	12 5
14	.01 "	25	25	25	25	24

12/18/95 (con't)

Setup PT1 experiment w/ TMT using albino embryos. Saved on D31K 210.

CAN	CONCEN	Intercept	
1A	NC	4.98 E5	} 5.20 5.08 E5
2A	NC	5.18 E5	
3A	PC (50mg/L AC - 11/15/95)	8.88 E5	174.8% 170.
4A	PC (10mg/L TMT - 11/15/95)	4.99 E5	98.2% 96.
5A	1mg/L TMT	4.83 E5	95.1% 92.
6A	.5 "	4.98 E5	98.0% 95
7A	.2 "	4.38 E5	86.2% 84.
8A	.1 "	4.46 E5	87.8% 85
9A	.05 "	4.97 E5	97.8% 95
10A	.01 "	5.91 E5	113.7% 116.3%
11A	NC	5.16 E5	101.6%
12A	NC	5.46 E5	107.5%

used all 4 NC's.

saved graph
as TMT12-18.IPG
on D31K 214

12/19/95

400 Speed slide film.

Incubated embryos from 12/18/95 in dilutions of TMT (NC, 1mg/L, .5, .2, .1, .05, .01 mg/L TMT) on 12/18/95. Put in 40 ul di-4 for 2 hours. (In 20 ul di-4 for ~45 min.)

PIZ	1	-	2 sec, NC	} Same embryo
PIZ	2	-	5 sec, NC	
PIZ	3	-	10 sec, NC	
PIZ	4	-	20 sec, NC	
PIZ	5	-	2 sec, NC	} Same embryo
PIZ	6	-	5 sec, NC	
PIZ	7	-	10 sec, NC	
PIZ	8	-	20 sec, NC	

pic 9 - 2 sec, 1 mg/L TNT	} same embryo
pic 10 - 5	
pic 11 - 10 sec, 1 mg/L TNT	
pic 12 - 20 sec, 1 mg/L TNT	
pic 13 - 20 sec, 1 mg/L TNT	} same embryo
pic 14 - 5 sec, .5 mg/L TNT	
pic 15 - 5 sec, .5 mg/L TNT	
pic 16 - 10 sec, .5 mg/L TNT	
pic 17 - 20 sec, .5 mg/L TNT	} different embryo
pic 18 - 2 sec, .2 mg/L TNT	
pic 19 - 5 sec, .2 mg/L TNT	} same embryo
pic 20 - 10 sec, .2 mg/L TNT	
pic 21 - 20 sec, .2 mg/L TNT	
pic 22 - 2 sec, .1 mg/L TNT	} same embryo
pic 23 - 5 sec, .1 mg/L TNT	
pic 24 - 10 sec, .1 mg/L TNT	different embryo

Did not turn out → (all)

12/20/95

Take photos of embryos (albinos) in TNT experiment (from 12/19/95.) Used P1600 Film (Kodak Ektachrome) from Helt Photography. These embryos have been in di-4 for 24 hours. Same embryos from 12/19/95. Shot 1 sec photos because moving too much.

pic 1 - 1 sec, neg control	} same embryo	(TOOK out ~ 6 ml H ₂ O from dish)
pic 2 - 2 sec, "		
pic 3 - 5 sec, "		
pic 4 - 1 sec, 1 mg/L TNT	} different embryo	(TOOK out ~ 6 ml H ₂ O from dish)
pic 5 - 1 sec, "		
pic 6 - 1 sec, "		
pic 7 - 1 sec, 0.5 mg/L TNT	} different embryo	TOOK out ~ 7 ml H ₂ O from dish
pic 8 - 1 sec, "		
pic 9 - 1 sec, "		
pic 10 - 1 sec, 0.2 mg/L TNT	} same embryo	TOOK out ~ 7 ml H ₂ O from dish
pic 11 - 1 sec, "		
pic 12 - 1 sec, "		

* All photos on 12/20/95 were taken when the embryo's eye was focused.

pic 13 - 1 sec,	.1 mg/L TNT	- different embryo	} took out ~ 7 ml H ₂ O from this dish
pic 14 - 1 sec,	"	} same embryo	
pic 15 - 1 sec,	"	} same embryo	
pic 16 - 1 sec,	.05 mg/L TNT	} same embryo	} took out ~ 7 ml H ₂ O from this dish
pic 17 - 1 sec,	"		
pic 18 - 1 sec,	"	- different embryo	} same dishes pizs 1-3
pic 19 - 1 sec,	.01 mg/L TNT NC	} same embryo	
pic 20 - 1 sec,	NC		
pic 21 - 1 sec,	NC	- different embryo	

(continued pg 52) →

Pictures 1-21 embryos have been in FETAX for 24+ hours. before taking the photos.

In TNT for 24 hours then in FETAX for the second 24+ hours. (Embryos from 12/18/95)

the next set of embryos are still embryos laid on 12/18/95 but have been in TNT for 48 hours+. They've been in 40 ul di-4 for 2 hours

* page 52 for pictures

12/21/95

Setup FETAX experiment using TCAOB + TCAB on albino embryos. Set up @ 2:00 pm. Both stock solutions were 200 ug/L in 1% ETOH.

DISH	CONCEN.	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC (1% ETOH)	25	25 or	0		
2	200 ug/L TCAOB	25	24	0		
3	100 ug/L TCAOB	25	25	0		
4	50 ug/L TCAOB	25	25	0		
5	25 ug/L TCAOB	25	24	0		
6	10 ug/L TCAOB	25	23	0		

saved spreadsheet
as TCAB1221.wq1
on disk 214 -

Set up FETAX experiment using 3 dehydrated tomatoes (Tomatoes 1345-4 green, Tomatoes BEBC cherry red + tomatoes BEBC cherry green). All stock solutions were 1 gram / 500 ml of fetax. Started test at 5:30 pm.

VIAL	CONCEN	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	25	25			
2	2g/L BEBC cherry red	25	0	0		
3	1g/L "	25	0	0		
4	.5g/L "	25	0	0		
5	.25g/L "	25	0	0		
6	NC	25	25			
7	2g/L BEBC cherry green	25	0	0		
8	1g/L "	25	0	0		

CONCEN.	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
5g/L BEBC Cherry green	25	0	0		
25g/L " "	25	0	0		
NC	25	23			
2g/L 1345-4 green	25	0	0		
1g/L	25	0	0		
5g/L	25	0	0		
25g/L ↓	25	5	2	0	0

12-22-95 Made up fresh X-check from MFS stock
 Adg pH to ~ 3 and stirred w/heat. Chery 24h
 embryos, incubated with 40μL D1-4 AND FTX.

DISH []	FTX	STOCK	25 EMBRYOS/DISH
1 0	10 ML		
2 1 μg/L TMT 9		1 ML	TMT STOCK @ 10 μg/L
3 0.5 μg/L 9.5		0.5	
4 0.25 μg/L 9.75		0.25	
5 0.1 μg/L 9.9		0.1	
6 0	10		
7 5 μg/L 9		1 ML	X-C stock 12-22-95 50 μg/L
8 10	8	2	
9 2.5	9.5	0.5	
10 1	9.75 9.75	0.25	
11 0.5	9.9	0.1	

Then I setup the camera with P1600 slide film,
 using Nikon back + 5X Photolens. I used a combination
 of 10X + 5X objectives. Embryos were incubated
 for 4 hrs in 20 μL D14 stock

P.T.X. #	[]	OBJ	TIME	LIGHT
1	0 (1)	10X	1/30 S	INC.
2	0	"	1 S	FL B/580 BARRIER
3	0	"	2 S	FL
4	0	5X	1 S	"
5	0	"	2 S	"
6	1 μg/L TMT (2)	10X	1/30 S	INC @ 5.5
7	"	"	1 S	FL B/580 * made into 4x6
8	"	"	2 S	" "
9	"	5X	1 S	" " (Cont'd) on CN P 52

From 12/20/95 241

pic 22 -	1 sec, NC	in TNT for 1 hr 45 min.	same embryo
pic 23 -	NC		
pic 24 -	NC		
pic 25 -	1 mg/L TNT		same embryo
pic 26 -	"		
pic 27 -	"		
pic 28 -	5 mg/L TNT		same embryo
pic 29 -	"		
pic 30 -	"		
pic 31 -	2 mg/L TNT		same embryo
pic 32 -	"		
pic 33 -	"		
pic 34 -	1 mg/L TNT		same embryo
pic 35 -	"		
pic 36 -	"		
pic 37 -	0.05 mg/L TNT		different embryo

Pix did not turn out! However there are some IMAGES ON NEGATIVES. Had some pictures made.

Count & from	PSI	TMT / X-C	2ND	P1600	EXPT/24
PIX []	OBS	TIME	COND		
10	0.5 mg/L TNT 10X	1/30S	INCANDESCENT		
	(dish 3)				
11	"	"	1 S	FL B/580	* made into 4x6
12	"	"	2 S	" "	
13	"	5 X	1 S	" "	
14	0.25 TNT (4)	10 X	1/30 S	INC.	
15	"	"	1 S	FL B/580	* made into 4x6
16	"	"	2 S	" "	
17	"	5 X	1 S	" "	
18	0.1 TNT (5)	10 X	1/30 S	INC	
19	"	"	1 S	FL B/580	* made into 4x6
20	2.5 mg/L X-C	10 X	1/30 S	INC	Exposed 3 hr to X-C + D14
21	"	"	1 S	FL B/580	
22	"	"	2 S	FL " "	- moved (?)
23					
24	2.5 mg/L X-C	5 X	1 S	FL " "	

Continued →

12-24-95

242

CON 24 h EXPT TMT/X-C USING P/600 film

PIX		OBJ	TIME	SOURCE
25	1 mg/LX-C (dish 10)	10	1/30S	ENC
26	ON-PT	1	1S	FE
27	"	"	2S	FL MOVED
28	0.5 mg/LX-C	SX	1S	
29	dish 11	10X	1/30S	LT
30	"	"	1S	FL B/580
31	"	"	2S	" "
32	NC (10)	SX	1S	" "
33		10X	1/30S	LT
34		10X	1S	FL B/580
35		"	2S	"
		SX	1S	"

* made
mto
4x6

12-27-95

Set up chicken EXPT by making up chicken Ringers' solution, used recipe in Prosser

NaCl 150

NaHCO₃ 20

KCl 5

CaCl₂ 5Mg Cl₂ 2

Glucose 12

Saved on PTI computer
under Lotus as chickenWarmed this to 37°C Set up diskette #212
for chicken data. Protocol + Procedure is on diskette1-2-96 X-C vs FA. Came up with scheme
to analyze FA data by regressing FA onto
Percent survival. Do this by using DAYONE VR on
Disk 209 to SORT by AC, then FA, then TRIAL, then DIS4
OUT PUT this as PRN FILE with JUST AC=0 (Row 2-85)

1/9/96

Most of the slides from 12-24-95 (pages 51, 52, 53)
turned out.

1/10/96

243

Experiment using albinos, α -Chaconine + SBFI dye. Counted out 80 embryos in each dish that contained 10 ml of FETAX solution. There are 19 dishes. After added 80 embryos to each dish, I made up the SBFI, by adding 100 μ l DMSO to each of 4 vials of SBFI. I waited until the SBFI was dissolved, then added 20 μ l from a vial to each dish of embryos. Set the timer for 4 hours + let sit in the SBFI. Each dish is labeled accordingly:

PC (50mg/L), 3-10mg/L α C, 3-NC, 3-0.1mg/L, 3-1mg/L, 3-2.5mg/L, 3-5mg/L α C.

We also made 2 dishes: 1-NC + 1-50mg/L α C using di-4 ANEPPS to test the toxicity of the α Chac. The α -Chac. was made 1/9/96 in 50mg/L concentration. After being incubated for 4 hours in SBFI, the water was switched out to the concentrations and incubated another 30 min. Saved data on Disk 211. Ran in u-cuvette on PT1. Left the emission wavelength @ 620 nm. Then changed to 505 nm for next set.

LAN	concen.	ml α C	ml FTX	Intercept.
1	NC (di-4)	0	10	3.10E5
2	50mg/L α C (di-4)	10	0	1.04E6
3	NC (SBFI)	0	10	1.27E6
4	50mg/L α C ↓	10	0	1.02E6
5	0.1mg/L α C	20 μ l	9.98 ml	EX1=300 1.28E6
6	1mg/L α C	.2 ml	9.8	EX2=400 1.14E6
7	2.5mg/L α C	.5	9.5	1.23E6
8	5 mg/L α C	1	9	1.28E6
9	10 mg/L α C	2	8	1.26E6
10	NC	0	10	5.51E5
11	0.1mg/L α C	20 μ l	9.98	4.75E5
12	1mg/L α C	.2	9.8	4.81E5
13	2.5mg/L α C	.5	9.5	4.96E5
14	5 mg/L α C	1	9	4.90E5

SCAN	CONCEN	ml dC	ml EFX		Intercept
15	10mg/L dC	2	8	-505nm	?
16	NC	0	10	505nm	4.98E5
17	.1mg/L dC	20ul	9.98		5.35E5
18	1 mg/L dC	.2	9.8		5.96E5
19	2.5 mg/L dC	.5	9.5		4.81E5
20	5 mg/L dC	1	9		5.19E5
21	10 mg/L dC	2	8		4.57E5

* 505nm looks to be the best position for the emission monochromator.

1/11/96

1-5-96

From ~~12-27-95~~ 1-5-96, chicken data: intercepts for each scan, 1A + 2A. Disk 213. Day 10
Spreadsheet data on Disk 220. Page 88 - modifications

SCAN	DYE	2A intercept	1A intercept
1A1	Di-4	2.65E4	-609.32
1A2		1.21E4	-658.45
1A3		3.86E4	-456.18
1A4		2.95E4	-524.20
1B1		3.79E4	-599.98
1B2		3.15E4	-526.79
1B3		4.29E4	-544.66
1B4		4.94E4	-494.92
1C1		9.29E3	-685.82
1C2		5.95E4	-438.62
1C3		4.17E4	-464.81
1C4		2.07E4	-543.12
1A1		3.10E4	-436.51
1A2		1.97E4	-536.64
1A3		1.29E4	-457.57
1A4		2.50E4	-381.00
1B1		4.41E4	-357.03

1/11/96 continued

AN	DYE	2A int.	1A int.
IB2	Di-4	1.00E5	-110.34
IB3		1.03E4	-511.00
IB4		4.18E4	-426.98
IC1		4.92E4	-395.87
IC2		4.55E4	-321.69
IC3		2.58E4	-326.25
IC4		3.36E4	-445.08
IA1		6.07E4	2.05E3
IA2		2.00E4	-658.80
IA3		2.89E4	-626.22
IA4		1.19E4	-560.31
IB1		3.15E4	-549.52
IB2		1.21E4	-705.21
IB3		4.04E4	-507.39
IB4		5.45E4	-448.69
IC1	BCECF	2.56E4	-670.53
IC2		2.90E4	-559.50
IC3		1.40E4	-629.95
IC4			
IA1		1.34E5	4.21E3
IA2		1.54E5	4.33E3
IA3		1.52E5	4.19E3
IA4		1.19E5	4.05E3
IB1		1.13E5	4.20E3
IB2		1.22E5	4.10E3
IB3		8.49E4	3.88E3
IB4		7.05E4	3.47E3
IB5C1		1.03E5	3.74E3
IC2		8.69E4	3.87E3
IC3		9.98E4	3.49E3
IC4		1.06E5	4.13E3
IA1	V	1.40E5	4.03E3
IA2		6.10E4	3.23E3
IA3		8.61E4	3.53E3
IA4		1.07E5	3.88E3
IB1		1.19E5	3.99E3
IB2		1.00E5	3.86E3

1/11/96 continued

SAAN	DYE	2A int.	1A int.
II B3	BCECF	$1.27E5$	$3.77E3$
II B4		$1.12E5$	$3.75E3$
II C1		$9.20E4$	$3.90E3$
II C2		$7.93E4$	$3.55E3$
II C3		$2.33E5$	$4.70E3$
II C4		$1.18E5$	$4.27E3$
II A1		$1.13E5$	$3.68E3$
II A2		$1.21E5$	$3.71E3$
II A3		$1.22E5$	$4.04E3$
II A4		$7.43E4$	$3.54E3$
II B1		$4.89E4$	$3.22E3$
II B2		$1.52E5$	$3.90E3$
II B3		$1.21E5$	$4.21E3$
II B4		$1.21E5$	$3.400E3$
II C1		$1.64E5$	$3.74E3$
II C2		$1.48E5$	$3.67E3$
II C3	V	$7.01E4$	$3.42E3$

IAI	SNAFL		
IA2		$1.60E6$	$6.22E5$
IA3		$1.82E6$	$6.26E5$
IA4		$1.88E6$	$8.91E5$
IB1		$1.04E6$	$3.85E5$
IB2		$1.76E6$	$7.12E5$
IB3		$1.54E6$	$5.85E5$
IB4		$1.84E6$	$6.08E5$
IC1		$1.32E6$	$3.57E5$
IC2		$2.09E6$	$8.16E5$
IC3		$1.61E6$	$5.94E5$
IC4		$7.49E5$	$2.16E5$
IIA1		$1.43E6$	$5.43E5$
IIA2		$2.00E6$	$9.40E5$
IIA3		$1.35E6$	$4.18E5$
IIA4		$1.25E6$	$3.80E5$
II B1		$1.87E6$	$8.31E5$
II B2		$9.86E5$	$3.51E5$
II B3		$1.08E6$	$3.81E5$
II B4		$1.00E6$	$2.47E5$

1/11/96 continued

SCAN	DYE	2A int.	1A int.
II B4	5NAFL	1.63E6	6.20E5
II C1		1.50E6	4.31E5
II C2		1.55E6	6.43E5
II C3		1.82E6	8.34E5
II C4		1.85E6	8.37E5
II A1		1.09E6	3.80E5
II A2		2.00E6	1.02E6
II A3		2.67E6	1.14E6
II A4		1.78E6	6.21E5
II B1		1.47E6	4.68E5
II B2		1.78E6	8.43E5
II B3		1.72E6	6.43E5
II B4		1.08E6	3.41E5
II C1		2.07E6	1.86E6
II C2		1.77E6	8.50E5
II C3		1.74E6	5.94E5

SCAN	DYE	2A int.	1A int.
II A1	FLUO	1.04E5	3.57E3
II A2		1.62E5	3.78E3
II A3		4.62E4	3.59E3
II A4		2.31E4	3.13E3
II B1		5.62E4	3.23E3
II B2		4.74E4	2.94E3
II B3		9.31E4	3.27E3
II B4		6.99E4	3.14E3
II C1		1.71E5	3.62E3
II C2		5.39E4	3.31E3
II C3		2.17E4	2.83E3
II C4		5.61E4	3.58E3
II A1		5.91E4	3.32E3
II A2		4.85E4	3.08E3
II A3		1.07E5	3.43E3
II A4		1.32E5	3.58E3
II B1		3.86E4	3.22E3
II B2		2.55E4	2.92E3
II B3		6.09E4	3.00E3
II B4		5.16E4	3.11E3

SCAN	DYE FLUD	2A int.	1A int.
TIC1		7.39E4	3.24E3
TIC2		2.17E5	3.84E3
TIC3		2.56E5	4.19E3
TIC4		3.49E4	3.58E3
IIA1		1.54E4	2.78E3
IIA2		6.27E4	3.31E3
IIA3		1.05E5	3.71E3
IIA4		9.95E4	3.49E3
IIIB1		1.46E5	3.41E3
IIIB2		1.78E5	4.02E3
IIIB3		3.80E4	3.47E3
IIIB4		1.63E4	2.92E3
TIC1		8.53E4	3.21E3
TIC2		7.32E4 ^{7.33E4}	3.07E3
TIC3		5.27E4	3.41E3

IAI	SBFI	7.63E3	8.34E4
IA2		8.82E3	1.03E5
IA3		7.13E3	7.00E4
IA4		1.06E5 ^{8.34}	8.31E4
IIIB1		8.08E3	8.97E4
IIIB2		8.20E3	8.36E4
IIIB3		5.00E3	6.53E4
IIIB4		5.99E3	7.41E4
IC1		7.35E3	1.01E5
IC2		1.78E4	1.15E5
IC3		7.16E3	7.15E4
IC4		8.30E3	9.34E4
IIA1		8.26E3	1.07E5
IIA2		6.84E3	6.92E4
IIA3		7.45E3	8.63E4
IIA4		1.45E4	1.99E5
IIIB1		7.85E3	7.21E4
IIIB2		7.31E3	7.06E4
IIIB3		8.59E3	8.51E4
IIIB4		8.25E3	9.98E4
IC1		7.24E3	7.10E4

1/11/96 continued

SCAN	DYE	2A int	1A int
IC2	SBFI	1.51E4	1.56E5
IC3		1.32E4	1.52E5
IC4		1.46E4	1.01E5
IA1		6.13E3	6.56E4
IA2		9.64E3	8.89E4
IA3		9.94E3	9.87E4
IA4		7.11E3	6.92E4
IB1		8.31E3	1.05E5
IB2		1.14E4	1.88E5
IB3		2.49E4	1.38E5
IB4		6.42E3	6.84E4
IC1		9.55E3	1.03E5
IC2		1.32E4	1.33E5
IC3		6.71E3	7.02E4
IA1	PBFI	7.29E3	1.21E5
IA2		6.31E3	9.76E4
IA3		1.45E4	1.12E5
IA4		7.16E3	7.17E4
IB1		7.05E3	1.07E5
IB2		1.15E4	1.68E5
IB3		7.22E3	1.29E5
IB4		6.50E3	1.09E5
IC1		9.94E3	2.55E5
IC2		2.15E4	1.39E5
IC3		6.85E3	7.20E4
IC4		8.34E3	1.17E5
IA1		8.67E3	1.62E5
IA2		7.06E3	7.84E4
IA3		5.01E3	8.59E4
IA4		1.07E4	2.03E5
IB1		2.05E4	1.42E5
IB2		7.65E3	8.18E4
IB3		1.28E4	2.14E5
IB4		1.02E4	2.19E5
IC1		6.67E3	7.93E4
IC2		1.43E4	2.54E5
IC3		1.18E4	2.25E5

1/11/96 continued

250

SCAN	DYE	2A mt.	1A mt.
IC4	PBFI	3.97E4	2.53E5
IA1		6.69E3	7.02E4
IA2		1.50E4	1.60E5
IA3		1.25E4	1.61E5
IA4		5.86E3	8.13E4
IB1		1.73E4	3.24E5
IB2		1.31E4	2.00E5
IB3		1.93E4	1.50E5
IB4		7.42E3	7.66E4
IC1		1.46E4	1.97E5
IC2		1.50E4	2.09E5
IC3	↓	1.89 1.09E4	1.59E5

1/16/96

Ran chicken experiment. Check on Disk 215 under ROCHPROT. WPM + TIME, WPM. All scans are on Disk 215 also. Day 20. Spreadsheet data on Disk 220. Page 88 - modifications

SCAN	DYE	2A mt.	1A mt.
IA1	di-4	3.59E5	4.44E3
IA2		1.86E5	2.74E3
IA3		4.54E5	4.81E3
IA4		8.25E5	7.58E3
IB1		4.26E5	4.51E3
IB2		1.93E5	7.41E3
IB3		4.13E5	4.66E3
IB4		4.72E5	4.33E3
IC1		2.87E5	4.46E3
IC2		6.67E5	6.81E3
IC3	→	4.24E5	5.45E3
IC4	→	3.04E5	4.51E3
IA1	→	1.78E5	4.38E3
IA2		3.54E5	3.70E3
IA3		2.86E5	3.05E3
IA4		3.04E5	3.73E3
IB1		3.27E5	1.10E3

11/10/96 condn

251

DYE

D-4

2A mt.

1A mt.

IB3 di-4

6.95E5

6.85E3

1.73E5

3.12E3

8.36E5

7.81E3

6.29E5

4.97E3

1.06E6

7.25E3

3.86E5

7.15E3

4.17E5

3.08E3

6.57E5

5.98E3

7.26E5

5.60E3

4.24E5

3.28E3

9.44E5

7.58E3

1.50E5

1.71E3

6.65E5

5.05E3

5.68E5

4.94E3

8.91E5

6.35E3

9.94E5

6.92E3

6.35E5

4.76E3

BCECF

2A mt.

1A mt.

2.55E5

3.51E5

4.63E5

7.34E5

7.17E5

1.23E6

8.35E5

1.35E6

4.99E5

9.76E5

6.92E5

1.09E6

3.05E5

5.62E5

1.53E5

2.50E5

2.74E5

4.35E5

7.60E5

1.21E6

7.34E5

1.01E6

5.56E5

9.46E5

5.70E5

9.54E5

1.87E5

2.80E5

2.40E5

3.46E5

4.74E5

7.34E5

7.31E5

1.20E6

5.72E5

9.06E5

6.38E5

1.06E6

Dye

2A

1A

BLECF

6.39E5

9.51E5

3.10E5

4.93E5

1.74E5

3.76E5

3.46E5

6.01E5

7.14E5

1.13E6

6.20E5

9.15E5

5.72E5

1.07E6

5.58E5

1.02E6

4.30E5

7.88E5

1.81E5

2.46E5

3.82E5

5.93E5

7.51E5

1.26E6

5.88E5

8.89E5

5.41E5

9.25E5

6.98E5

1.13E6

3.88E5

7.27E5

SNAFL

4.35E5

1.77E5

6.05E5

2.97E5

4.79E5

2.01E5

2.03E6

6.57E5

9.56E5

2.62E5

1.94E6

6.53E5

1.77E6

4.75E5

5.04E5

9.77E4

1.58E6

4.64E5

1.16E6

3.49E5

1.81E6

6.15E5

1.39E6

4.12E5

2.35E6

8.98E5

1.76E6

4.37E5

9.51E5

1.14E5

1.88E6

6.35E5

1.93E6

8.35E5

5.55E5

9.74E4

1.70E6

5.22E5

2.34E6

8.81E5

1.54E6

3.57E5

1.01E6

2.39E5

DYE

2A

1A

253

BSNAFL

1.81E6 5.61E5

2.22E6 9.85E5

9.53E5 3.11E5

1.88E6 5.78E5

2.49E6 9.92E5

1.83E6 4.77E5

1.09E6 2.17E5

1.50E6 5.00E5

2.30E6 1.06E6

3.15E5 6.23E4

1.88E6 6.36E5

2.40E6 1.01E6

1.58E6 4.25E5

FLUO

9.45E4 6.28E3

1.64E5 6.68E3

9.30E4 7.53E3

6.33E4 7.42E3

1.03E5 6.34E3

9.63E4 6.13E3

1.38E5 6.22E3

7.24E4 4.84E3

1.13E5 7.33E3

1.40E5 8.28E3

1.23E5 7.37E3

1.81E5 6.34E3

1.15E5 6.55E3

1.72E5 6.26E3

5.81E4 5.09E3

1.46E5 6.28E3

1.16E5 7.03E3

7.48E4 1.12E4

1.66E5 7.46E3

1.40E5 6.74E3

1.78E5 6.28E3

1.06E5 5.02E3

1.45E5 5.61E3

1.02E5 6.91E3

6.11E4 5.79E3

1/16/96 cont

254

IAN	DYE	2A	1A
IIA2	FLVD	1.45E5	6.83E3
IIA3		1.24E5	6.78E3
IIA4		1.69E5	6.59E3
IIB1		9.55E4	4.79E3
IIB2		1.58E5	6.14E3
IIB3		1.38E5	7.25E3
IIB4		1.16E5	6.54E3
IIC1		1.63E5	6.53E3
IIC2		1.20E5	5.85E3
IIC3	↓	1.27E5	6.03E3
IIC4		2.21	
IIA1	SBFI	1.50E5	8.68E4
IIA2		1.43E5	9.24E4
IIA3		3.07E5	1.32E5
IIA4		2.00E5	9.76E4
IIB1		1.86E5	1.04E5
IIB2		1.63E5	9.71E4
IIB3		1.40E5	8.03E4
IIB4		1.79E5	9.35E4
IIC1		2.11E5	1.13E5
IIC2		4.41E5	1.38E5
IIC3		1.51E5	8.18E4
IIC4		1.24E5	8.21E4
IIA1		1.44E5	9.28E4
IIA2		1.27E5	7.83E4
IIA3		1.34E5	8.30E4
IIA4		1.36E5	9.15E4
IIA5B1		2.62E5	1.27E5
II B2		1.42E5	8.18E4
II B3		1.33E5	8.29E4
II B4		1.29E5	8.64E4
IIC1		1.16E5	7.40E4
IIC2		1.21E5	7.76E4
IIC3		1.73E5	1.03E5
II C4		2.01E5	9.46E4
IIA1		1.48E5	8.33E4
IIA2		1.28E5	8.39E4
IIA3		1.33E5	8.66E4
IIA4	↓	1.26E5	7.83E4

1/16/96 Cont

255

	DYE	2A	1A
IB1	SBFI	1.22E5	7.58E4
IB2		1.28E5	7.97E4
IB3		1.80E5	1.00E5
IB4		1.49E5	9.84E4
IC1		1.54E5	8.98E4
IC2		1.30E5	8.47E4
IC3		1.40E5	8.02E4
IA1	PBF1	1.51E5	9.51E4
IA2		1.56E5	1.05E5
IA3		2.42E5	1.20E5
IA4		3.62E5	2.01E5
IB1		1.58E5	1.17E5
IB2		2.10E5	1.66E5
IB3		1.40E5	9.02E4
IB4		1.36E5	8.76E4
IC1		1.47E5	9.67E4
IC2		3.92E5	1.72E5
IC3		2.88E5	1.19E5
IC4		1.87E5	1.33E5
IIA1		1.62E5	1.31E5
IIA2		1.22E5	8.57E4
IIA3		1.42E5	9.51E4
IIA4		1.42E5	9.66E4
IB1		2.92E5	1.44E5
IB2		1.95E5	8.46E4
IB3		1.50E5	9.82E4
IB4		2.21E5	1.67E5
IC1		1.47E5	8.73E4
IC2		9.70E4	6.97E4
IC3		1.7E5	1.06E5
IC4		5.25E5	1.62E5
IIIA1		2.31E5	1.12E5
IIIA2		1.69E5	1.12E5
IIIA3		1.65E5	1.16E5
IIIA4		1.43E5	8.43E4
IIIB1		1.37E5	9.76E4
IIIB2		1.59E5	1.11E5
IIIB3		2.74E5	1.23E5

1/16/96 cont

256

	DIE	2A	1A
B4	PBE1	2.46E5	1.58E5
B1	↓	3.49E5	2.59E5
B2	↓	1.81E5	1.31E5
B3	↓	1.42E5	9.34E4

1/18/96

Ran short PT1 experiment with Tomatine
(stock 50 mg/L - 1/18/96). Saved on Disk 214

SCAN	CONCEN.	Intercept	% Control
1	NC	1.81E5	(1.825) NC
2	25mg/L	7.99E5	437.8%
3	50mg/L	7.50E5	410.9%
4	NC	1.84E5	
5	25mg/L	9.41E5	515.6%
6	50mg/L	7.68E5	420.8%

Used nanject to inject embryos (5) but broke
3 of them. Made up 4% Fluoro-Gold in
Fetax. Put in refrigerator + covered w/ foil.
Embryos were layed today. Used 23 ^(nL) per
"beep". Used dissecting scope + Bausch +
Lomb light source.

1/19/96

Ran PTI experiment with α -Chaconine vs. Folic Acid + Tomatine. α -Chac Stock was made 1/9/96 + Tomatine stock was made 1/18/96. Both stock were 50mg/L. Folic Acid stock was made 1/19/96 100mg/L. All pH's were between 6.2-6.8. Albino embryos were used. Scans 1-17 used di-4 from 11-21-95. Scans 18-4 used di-4 from 1/19/96. Disk 214

AN	CONCEN.	ml FA	ml aC	Intercept	% Control
1A	NC	0	0	2.08E5	1.94E5 100%
2A	NC	0	0	2.03E5	
3A	NC	0	0	1.71E5	
4A	20mg/L FA, 0aC	2	0	1.97E5	
5A	30mg/L FA, 0aC	3	0	2.21E5	101.5
6A	"	3	0	2.29E5	113.9
7A	"	3	0	2.46E5	118.0
8A	40mg/L FA, 0aC	4	0	1.63E5	126.8
9A	"	4	0	3.04E5	84.0
10A	"	4	0	1.96E5	156.7
11A	20mg/L FA, 2.5aC	2	.5	2.14E5	101.0
12A	30mg/L FA, 2.5aC	3	.5	2.00E5	110.3
13A	"	3	.5	1.65E5	103.1
14A	"	3	.5	1.57E5	85.1
15A	40mg/L FA, 2.5aC	4	.5	1.91E5	80.9
16A	"	4	.5	2.15E5	98.5
17A	"	4	.5	1.69E5	110.8
18A	NC (1/19/96 di-4)	0	0	2.12E5	87.1
19A	20mg/L FA, 5aC	2	1	1.86E5	109.3
20A	30mg/L FA, 5aC	3	1	2.53E5	95.9
21A	"	3	1	2.45E5	130.4
22A	"	3	1	2.32E5	126.3
23A	40mg/L FA, 5aC	4	1	2.11E5	119.6
24A	"	4	1	2.38E5	168.8
25A	"	4	1	2.58E5	122.7
26A	20mg/L FA, 10aC	2	2	3.10E5	132.9
27A	30mg/L FA, 10aC	3	2	2.97E5	159.8
28A	"	3	2	2.97E5	153.1
29A	"	3	2	7.96E5	153.1
					410.3

1/19/96 con't.

258

	CONCENT.	ml FA	ml aC	Intercept	% Control
30A	40mg/L FA, 10aC	4	2	5.77E5	297.4
31A	"	4	2	6.78E5	349.5
32A	"	4	2	4.32E5	222.7
33A	50mg/L aC (PC)	0	10	1.07E6	551.5
34A	NC	0	0	2.75E5 use 2.44E5	
35A	10 mg/L tomatine	2 ml tomatine		6.85E5	280.7
36A	25 "	5 ml tomatine		8.18E5	335.2
37A	50 "	10 ml tomatine		1.02E6	418.0
38A	NC			2.50E5	102.5
39A	10 mg/L tomatine	2 ml tomatine		8.45E5	346.3
40A	25 "	5 ml "		7.58E5	310.7
41A	50 "	10 ml "		9.32E5	382.0
42A	NC			2.07E5	
43A	10mg/L tomatine	2 ml Tomatine		9.46E5	387.8
44A	25mg/L tomatine	5 ml "		6.31E5	258.6
45A	50mg/L tomatine	10 ml "		7.70E5	315.6

aC data + graphs saved on disk 214 as 2ACI-19.GP, 5ACI-19.GP, 10ACI-19.GP, ACI-19.IPG

1/23/96

Set up FETAX experiment using T-BEBC cherry red, T-BEBC cherry green & T-1345-4 green tomatoe. All stocks were 2g/L made 12-21-95. Another stock was made up for the smaller concentrations (200mg/L).

From the 2g/L stock:

2g/L	-	10 ml stock	0 ml FTX
1g/L	-	5 ml stock	5 ml "
0.5g/L	-	2.5 ml stock	7.5 ml "
0.25g/L	-	1.25 ml stock	8.75 ml "

From the 200mg/L stock:

200mg/L	-	10 ml stock	0 ml FTX
100mg/L	-	5 ml "	5 ml "
50mg/L	-	2.5 ml "	7.5 ml "
25mg/L	-	1.25 ml "	8.75 ml "
10mg/L	-	0.5 ml "	9.5 ml "
5mg/L	-	0.25 ml "	9.75 ml "
1mg/L	-	0.1 ml "	9.9 ml "

1/23/96 Con 4

259

DISH	CONCENT.	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	25	25	25	25	24
2	2g/L cherry red	25	23	3	2	1
3	1g/L "	25	25	19	16	16
4	0.5g/L "	25	24	22	22	21
5	0.25g/L "	25	25	25	25	2+25
6	NC	25	25	25	24	21
7	2g/L cherry green	25	25	23	23	23
8	1g/L "	25	25	24	24	23
9	0.5g/L "	25	25	24	24	23
10	0.25g/L "	25	24	22	22	22
11	NC	25	25	25	25	23
12	2g/L 1345-4 green	25	22	9	5	2
13	1g/L "	25	24	21	21	21
14	0.5g/L "	25	24	22	22	22
15	0.25g/L "	25	24	23	23	22
16	NC	25	25	21	21	19
17	200mg/L NC	25	25	19	18	15
18	NC	25	25	24	24	23
19	200mg/L cherry red	25	25	22 24	22	21
20	200mg/L "	25	24	24	22	22
21	200mg/L "	25	24	23	23	22
22	100mg/L "	25	25	23	23	23
23	"	25	25	24	24	23
24	"	25	25	22	22	22
25	50mg/L Cherry red	25	25	25	25	25
26	"	25	25	23 25	25	23
27	"	25	24	24 24	23	21
28	25mg/L cherry red	25	25	25	25	25
29	"	25	25	25	25	25
30	"	25	25	22 23	23	22
31	10mg/L Cherry red	25	25	24	24	23
32	"	25	25	24	24	24
33	"	25	25	25	25	22
34	5mg/L cherry red	25	25	24	24	24
35	"	25	25	24	22	22
36	"	25	25	24	24	24
37	1mg/L Cherry red	25	24	24	24	24
38	"	25	25	24	23	22
39	"	25	25	25	23	23

1/23/96 Con't

260

	CONCENT.	DAY0	DAY1	DAY2	DAY3	DAY4
50	200mg/L cherry green	25	25	21	20	20
51	"	25	25	22	22	21
52	"	25	25	18	18	16
53	100mg/L cherry green	25	25	21	21	21
54	"	25	24	21	19	18
55	"	25	25	23	23	23
56	50mg/L cherry green	25	25	24	24	22
57	"	25	25	22	22	22
58	"	25	25	24	23	23
59	25mg/L cherry green	25	25	24	24	23
60	"	25	25	20	20	19
61	"	25	25	23	23	23
62	10mg/L cherry green	25	25	25	25	23
63	"	25	25	24	24	24
64	"	25	25	23	23	20
65	5mg/L cherry green	25	25	25	24	24
66	"	25	25	23	23	23
67	X	25	25	25	25	24
68	1mg/L cherry green	25	25	24	24	23
69	"	25	25	25	25	24
70	"	25	25	24	24	22
71	200mg/L 1345-4 green	25	24	24	24	22
72	"	25	25	25	25	23
73	"	25	25	23	22	20
74	100mg/L 1345-4 green	25	25	24	24	24
75	"	25	25	24	24	22
76	"	25	25	23	23	21
77	50mg/L 1345-4 green	25	25	24	22	22
78	"	25	25	23	23	23
79	"	25	25	25	24	24
80	25mg/L 1345-4 green	25	25	22	22	22
81	"	25	25	25	25	25
82	"	25	25	25	23	23
83	10mg/L 1345-4 green	25	25	25	25	25
84	"	25	25	23	23	22
85	"	25	25	22	22	21
86	5mg/L 1345-4 green	25	25	25	24	22
87	"	25	24	23	23	22
88	"	25	23	22	22	20

1/23/96 Con't

261

DISH	CONCENT.	DAY0	DAY1	DAY2	DAY3	DAY4
79	1mg/L 1345-4green	25	25	23	22	21
80	"	25	25	23	23	22
81	"	25	25	24	22	21

↑

Spread sheet saved as TOMIN123.WQ1 (high conc.)
 TOM1_23.WQ1 (low conc.)
 DISK 214

1/25/96

PT1 experiment with aChac + foliz acid
 using albino embryos. aChac stock is
 50mg/L made 1/25/96 + foliz acid stock is
 100mg/L made 1/25/96. All pH's are between
 6.6 - 6.8. DISK 216.

SCAN	CONCENT.	ml FA	ml aChac	Intercept	% Control
1	NC	0	0	1.42E5	1.60E5
2	NC	0	0	1.49E5	
3	NC	0	0	1.88E5	
4	PL (50mg/L aC)	0	10	3.83E5	239.4
5	5mg/L FA, 0aC	.5	0	1.32E5	82.5
6	"	.5	0	1.70E5	106.3
7	10mg/L FA, 0aC	1	0	1.50E5	93.8
8	"	1	0	1.63E5	101.9
9	20mg/L FA, 0aC	2	0	1.86E5	116.3
10	"	2	0	1.57E5	98.1
11	30mg/L FA, 0aC	3	0	1.73E5	108.1
12	"	3	0	1.40E5	87.5
13	40mg/L FA, 0aC	4	0	1.74E5	108.8
14	"	4	0	2.09E5	130.6
15	5 FA, 2.5aC	.5	.5	1.74E5	108.8
16	"	.5	.5	1.56E5	97.5
17	10 FA, 2.5aC	1	.5	1.79E5	111.9
18	"	1	.5	1.30E5	81.3
19	20 FA, 2.5aC	2	.5	1.56E5	97.5
20	"	2	.5	1.79E5	111.9
21	30 FA, 2.5aC	3	.5	1.33E5	83.1
22	"	3	.5	1.59E5	99.4
23	40 FA, 2.5aC	4	.5	1.32E5	82.5

N	CONCENT.	ml FA	ml aChac	Intercept	% Control
35	40FA, 2.5aC	4	.5	1.60E5	100%
36	5FA, 5aC	.5	1	1.65E5	103.1
37	"	.5	1	1.50E5	93.8
38	10FA, 5aC	1	1	1.72E5	107.5
39	"	1	1	1.59E5	99.4
40	20FA, 5aC	2	1	1.66E5	103.8
41	"	2	1	1.53E5	95.6
42	30FA, 5aC	3	1	1.77E5	110.6
43	"	3	1	1.53E5	95.6
44	40FA, 5aC	4	1	1.52E5	95.0
45	"	4	1	1.99E5	124.4
46	5FA, 10aC	.5	2	1.82E5	113.8
47	"	.5	2	3.32E5	207.5
48	10FA, 10aC	1	2	2.87E5	179.4
49	"	1	2	2.66E5	166.3
50	20FA, 10aC	2	2	2.38E5	148.8
51	"	2	2	3.56E5	222.5
52	30FA, 10aC	3	2	1.53E5	95.6
53	"	3	2	2.15E5	134.4
54	40FA, 10aC	4	2	2.15E5	134.4
55	"	4	2	1.87E5	116.9
56	2.5mg/L aC	0	.5	1.61E5	100.6
57	5 mg/L aC	0	1	1.61E5	100.6
58	10 mg/L aC	0	2	6.06E5	375.8

Check disk 216 For saved data in "inplot"
 2 AC1-25.GP, 5 AC1-25.GP, 10 AC1-25.GP, AC1-25.IPG. Averaged data →
 saved as AVG2AC.GP, AVG5AC.GP, AVG10AC.GP, AVAC1-25.IPG. Disk 216.

1/26/96

Ran Chicken experiment. Disk 217, DAY 30.

Spreadsheet data - Disk 220, Page 88 - modifications

Di-4

SCAN	2A DYE	1A	2A BCECF	1A	2A FLUO	1A
IA1	6.51E5	-1.13E4 ✓	2.75E5	2.40E5 ✓	2.25E5	1.40E3 ✓
IA2	-1.13E4	8.33E5 -1.1E4 ✓	9.78E5	1.16E6 ✓	5.17E5	1.31E4 ✓
IA3	8.33E5	1.94E6 2.14.57 ✓	1.12E6	1.06E6 ✓	2.67E5	2.20E3 ✓
IA4	-1.1E4	1.17E6 -5.61E3 ✓	1.43E6	1.57E6 ✓	1.01E5	3.16E3 ✓
IB1	9.14E5	-1.02E4 ✓	7.28E5	6.47E5 ✓	3.93E5	5.78E3 ✓

SCAN	2A DYE	1A	2A BCELF	1A	2A FLUO	1A
IB3	7.04E5	-9.32E3✓	7.22E5	7.22E5✓	3.22E5	2.17E3✓
IB4	1.11E6	-8.96E3✓	3.06E5	2.81E5✓	2.27E5	938.07✓
IC1	5.38E5	-1.23E4✓	8.66E5	8.00E5✓	3.26E5	1.45E3✓
IC2	1.18E6	-6.00E3✓	4.90E5	5.57E5✓	4.15E5	3.24E3✓
IC3	1.06E6	-8.84E3✓	9.13E5	9.66E5✓	8.92E4	866.18✓
IC4	1.09E6	-8.04E3✓	6.88E5	5.75E5✓	2.33E5	1.66E3✓
IIA1	6.01E5	-1.27E4✓	7.82E5	7.06E5✓	3.66E5	2.00E3✓
IIA2	1.14E6	-8.75E3✓	6.55E5	5.72E5✓	5.56E5	5.03E3✓
IIA3	1.64E6	-2.80E3✓	4.33E5	3.79E5✓	2.57E5	1.72E3✓
IIA4	1.32E6	-6.55E3✓	1.04E6	9.91E5✓	6.37E5	5.42E3✓
IB1	1.16E6	-6.72E3✓	1.56E6	1.71E6✓	1.22E5	3.60E3✓
IB2	1.35E6	-6.43E3✓	1.55E6	1.79E6✓	9.28E4	3.45E3✓
IB3	1.67E6	-2.64E3✓	1.38E6	1.45E6✓	4.41E5	5.39E3✓
IB4	8.48E5	-1.05E4✓	1.42E6	1.43E6✓	2.31E5	3.03E3✓
IC1	1.48E6	-5.03E3✓	6.41E5	4.82E5✓	4.24E5	3.84E3✓
IC2	8.80E5	-1.03E4✓	5.48E5	5.19E5✓	1.53E5	1.94E3✓
IC3	7.72E5	-8.99E3✓	8.50E5	9.24E5✓	7.36E5	6.05E3✓
IC4	1.01E6	-8.01E3✓	8.31E5	8.59E5✓	1.57E5	3.39E3✓
IIA1	1.52E6	-4.03E3✓	1.38E6	1.45E6✓	1.03E5	3.94E3✓
IIA2	9.57E5	-6.16E3✓	6.38E5	6.10E5✓	2.36E5	2.99E3✓
IIA3	1.49E6	-2.62E3✓	6.21E5	5.36E5✓	2.97E5	2.97E3✓
IIA4	1.18E6	-4.04E3✓	4.01E5	3.61E5✓	4.48E5	4.67E3✓
IB1	1.10E6	-2.44E3✓	1.90E5	1.84E5✓	2.84E5	2.94E3✓
IB2	1.09E6	-2.67E3✓	5.66E5	5.94E5✓	4.99E5	4.00E3✓
IB3	1.68E6	5.75E3✓	7.18E5	7.85E5✓	2.77E5	3.86E3✓
IB4	1.29E6	1.25E3✓	8.18E5	8.63E5✓	7.42E5	2.73E3✓
IC1	2.38E6	1.37E4✓	7.23E5	6.66E5✓	4.54E5	4.42E3✓
IC2	1.74E6	4.88E3✓	9.27E5	8.39E5✓	2.91E5	3.09E3✓
IC3	1.40E6	2.14E3✓	4.96E5	4.48E5✓	5.90E5	3.95E3✓
IIA1	1.09E6	-7.12E3✓	2.09E5	1.95E5✓	2.09E5	1.83E3✓
IIA2	1.46E6	-2.36E3✓	5.94E5	6.86E5✓	5.22E5	4.69E3✓
IIA3	2.18E6	6.17E3✓	6.01E5	6.20E5✓	2.55E5	4.96E3✓
IIA4	1.62E6	-988.89✓	9.61E5	1.00E6✓	1.09E5	3.51E3✓
IB1	1.29E6	-4.03E3✓	9.99E5	9.82E5✓	2.78E5	2.04E3✓
IB2	1.21E6	-4.47E3✓	6.69E5	6.88E5✓	3.12E5	3.03E3✓
IB3	1.07E6	-5.91E3✓	4.96E5	3.95E5✓	5.27E5	4.62E3✓
IB4	9.80E5	-7.40E3✓	4.52E5	4.10E5✓	4.58E5	2.88E3✓
IC1	1.07E6	-4.03E3✓	2.57E5	3.83E5✓	5.17E5	4.23E3✓
IC2	1.43E6	-1.64E3✓	8.19E5	8.08E5✓	3.44E5	4.65E3✓

SCAN

2A DYE

1A

2A BDEF

1A

264 2A FLUD

11A

IC3	1.42E6 - 2.48E3✓	1.12E6	1.19E6✓	9.93E4	3.17E3✓
IC4	8.05E5 - 7.14E3✓	6.94E5	6.39E5✓	3.76E5	3.72E3✓
IA1	9.55E5 - 9.48E3✓	7.27E5	6.46E5✓	1.85E5	3.85E3✓
IA2	1.14E6 - 8.03E3✓	7.37E5	7.20E5✓	4.74E5	5.02E3✓

SCAN

2A SBF1

1A

2A PBF1

1A

IA1	7.74E4	7.60E4✓	1.16E5	1.68E5✓
IA2	3.35E5	2.11E5✓	1.55E5	2.09E5✓
IA3	5.46E5	2.11E5✓	6.69E5	5.44E5✓
IA4	1.46E5	6.22E4✓	2.13E5	9.86E4✓
IB1	1.67E5	8.51E4✓	1.85E5	1.40E5✓
IB2	2.02E5	1.63E5✓	1.85E5	2.69E5✓
IB3	1.16E5	3.67E4✓	1.71E5	1.90E5✓
IB4	9.89E4	6.06E4✓	1.09E5	1.45E5✓
IC1	1.81E5	1.60E5✓	2.13E5	2.71E5✓
IC2	4.49E5	3.30E5✓	1.16E6	6.25E5✓
IC3	1.65E5	6.36E4✓	2.31E5	1.59E5✓
IC4	1.67E5	1.48E5✓	1.94E5	3.18E5✓
IIA1	8.61E4	6.13E4✓	1.47E5	2.65E5✓
IIA2	7.11E4	3.22E4✓	1.64E5	1.84E5✓
IIA3	5.02E4	2.28E4✓	9.56E4	1.45E5✓
IIA4	1.70E5	1.25E5✓	2.45E5	4.61E5✓
IIB1	3.30E5	2.28E5✓	3.89E5	3.96E5✓
IIB2	1.75E5	7.57E4✓	1.90E5	9.38E4✓
IIB3	1.57E5	2.35.63✓	2.07E5	3.58E5✓
IIB4	1.97E5	9.07E4✓	1.56E5	1.85E5✓
IC1	1.60E5	6.39E4✓	1.03E5	1.29E5✓
IC2	7.77E4	7.44E4✓	1.37E5	2.16E5✓
IC3	3.22E5	2.75E5✓	1.65E5	2.18E5✓
IC4	3.14E5	1.61E5✓	4.07E5	3.25E5✓
IIIA1	1.89E5	8.38E4✓	1.78E5	1.12E5✓
IIIA2	1.18E5	5.62E4✓	1.78E5	3.10E5✓
IIIA3	1.62E5	1.78E5✓	1.82E5	2.53E5✓
IIIA4	1.64E5	1.17E5✓	1.89E5	2.57E5✓
IIIB1	9.69E4	7.62E4✓	1.03E5	1.51E5✓
IIIB2	1.20E5	9.26E4✓	1.66E5	2.84E5✓
IIIB3	2.46E5	1.66E5✓	4.68E5	3.47E5✓
IIIB4	1.71E5	7.07E4✓	1.74E5	1.12E5✓
IIIC1	1.53E5	1.01E5✓	1.94E5	3.02E5✓

	2A	SPFL	1A	2A	PBFL	1A
TC2	1.31E5	1.13E5✓		1.86E5	4.05E5✓	
TC3	8.16E4	3.48E4✓		2.13E5	2.57E5✓	
TA1	1.21E5	1.04E5✓		8.48E4	1.26E5✓	
TA2	1.82E5	1.42E5✓		2.62E5	3.28E5✓	
TA3	3.43E5	1.77E5✓		4.70E5	5.49E5✓	
TA4	2.40E5	8.60E4✓		3.37E5	2.41E5✓	
TA5	1.21E5	1.25E5✓		1.66E5	2.18E5✓	
TA6	1.71E5	1.44E5✓		1.93E5	3.26E5✓	
TA7	1.38E5	6.83E4✓		1.87E5	2.59E5✓	
TA8	8.67E4	8.45E4✓		2.10E5	2.51E5✓	
TC1	2.47E5	2.79E5✓		1.55E5	2.46E5✓	
TC2	2.67E5	1.51E5✓		5.34E5	3.48E5✓	
TC3	2.37E5	9.26E4✓		2.82E5	1.21E5✓	
TC4	2.32E5	2.02E5✓		2.34E5	4.17E5✓	
TA1	1.94E5	1.31E5✓		1.19E5	2.43E5✓	
TA2	1.55E5	9.53E4✓		1.66E5	1.88E5✓	

1/30/96

Set up FETAX test with high Folic Acid concentrations + 10mg/L α -Chac. α -Chac stock (50mg/L) was made 1/30/96 + Folic acid stock (100mg/L) was made 1/30/96. pH's were from 6.0 - 6.7.

DSH	Concentr.	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	25				
2	20mg/L FA, 10mg/L α C	25	0			
3	30 FA, 10 α C	25	0			
4	40 FA, 10 α C	25	0			
5	50 FA, 10 α C	25	0			
6	NC	25				
7	20 FA, 10 α C	25	0			
8	30 FA, 10 α C	25	0			
9	40 FA, 10 α C	25	0			
10	50 FA, 10 α C	25	0			

test aborted -
embryos not
healthy

2/6/96

Ran chicken experiment. Disk 218. Day 40.
Spreadsheet data - Disk 220. Page 88 has modifications

	1A	D1-4	2A	1A	BCECF	2A	1A	SNAFL	2A
A1	5.32E3	7.88E5	✓	2.33E5	5.22E5	✓	7.59E5	6.70E5	✓
A2	1.23E4	1.67E6	✓	4.73E5	9.52E5	✓	7.90E5	7.48E5	✓
A3	1.35E4	1.78E6	✓	3.35E5	6.71E5	✓	1.22E6	1.08E6	✓
A4	1.23E4	1.70E6	✓	7.17E5	1.25E6	✓	7.92E5	6.39E5	✓
B1	1.03E4	1.49E6	✓	4.99E5	1.12E6	✓	1.07E6	1.07E6	✓
B2	1.41E4	1.84E6	✓	5.86E5	1.12E6	✓	8.44E5	8.72E5	✓
B3	1.98E4	2.36E6	✓	5.01E5	9.66E5	✓	8.55E5	8.01E5	✓
B4	5.97E3	1.10E6	✓	9.77E4	2.07E5	✓	5.14E5	5.04E5	✓
C1	1.14E4	1.66E6	✓	5.15E5	9.66E5	✓	1.39E6	1.18E6	✓
C2	1.61E4	2.03E6	✓	6.62E5	1.23E6	✓	1.81E6	1.64E6	✓
C3	1.96E4	2.27E6	✓	7.91E5	1.38E6	✓	8.13E5	6.77E5	✓
C4	9.24E3	1.44E6	✓	7.67E5	1.43E6	✓	6.85E5	6.93E5	✓
D1	1.66E4	2.04E6	✓	5.16E5	9.71E5	✓	1.23E6	1.15E6	✓
IIA2	1.21E4	1.61E6	✓	5.69E5	1.09E6	✓	6.43E5	7.15E5	✓
IA3	1.64E4	2.02E6	✓	2.34E5	4.95E5	✓	2.77E5	2.61E5	✓
IA4	8.16E3	1.10E6	✓	1.89E5	3.74E5	✓	8.14E5	7.58E5	✓
BI	1.52E4	1.77E6	✓	6.65E5	1.18E6	✓	1.37E6	1.17E6	✓
IB2	1.25E4	1.63E6	✓	7.49E5	1.23E6	✓	9.28E5	7.50E5	✓
IB3	1.17E4	1.53E6	✓	5.59E5	1.18E6	✓	8.66E5	9.24E5	✓
IB4	1.16E4	1.57E6	✓	6.61E5	1.24E6	✓	1.23E6	1.13E6	✓
CI	9.85E3	1.32E6	✓	4.81E5	9.87E5	✓	7.99E5	8.76E5	✓
IC2	9.81E3	1.45E6	✓	2.53E5	5.62E5	✓	4.24E5	4.56E5	✓
IC3	5.34E3	7.62E5	✓	6.48E5	1.10E6	✓	7.23E5	6.71E5	✓
IC4	2.60E4	2.64E6	✓	7.68E5	1.37E6	✓	1.31E6	1.20E6	✓
AI	1.14E4	1.59E6	✓	6.51E5	1.12E6	✓	7.44E5	6.39E5	✓
A2	1.19E4	1.56E6	✓	5.10E5	1.14E6	✓	7.57E5	7.20E5	✓
A3	9.46E3	1.38E6	✓	7.25E5	1.34E6	✓	7.92E5	7.73E5	✓
A4	3.64E4	3.21E6	✓	2.98E5	7.03E5	✓	5.34E5	6.33E5	✓
BI	9.45E3	1.43E6	✓	1.81E5	4.21E5	✓	5.08E5	5.19E5	✓
B2	6.90E3	1.01E6	✓	2.83E5	5.57E5	✓	8.64E5	7.92E5	✓
IB3	3.08E4	2.91E6	✓	6.00E5	1.15E6	✓	1.69E6	1.46E6	✓
IB4	1.18E4	1.66E6	✓	7.98E5	1.33E6	✓	9.22E5	7.86E5	✓
CI	5.35E3	8.74E5	✓	6.02E5	1.27E6	✓	1.44E6	1.43E6	✓
C2	2.68E4	2.78E6	✓	5.52E5	1.14E6	✓	9.21E5	9.27E5	✓
C3	1.32E4	1.86E6	✓	4.36E5	1.06E6	✓	4.93E5	5.81E5	✓

SCAN	IA Di-4	2A	IA BCECE	2A	IA SNAPL	2A
IV A1	5.16E3	8.69E5 ✓	1.13E5	2.40E5 ✓	3.61E5	3.88E5 ✓
IV A2	6.79E3	1.12E6 ✓	5.74E5	8.16E5 ✓	7.69E5	6.36E5 ✓
IV A3	4.58E4	3.68E6 ✓	8.06E5	1.34E6 ✓	1.42E6	1.27E6 ✓
IV A4	1.03E4	1.52E6 ✓	9.04E5	1.54E6 ✓	1.41E6	1.28E6 ✓
IV B1	5.67E3	9.12E5 ✓	5.07E5	1.07E6 ✓	9.49E5	9.10E5 ✓
IV B2	9.39E3	1.48E6 ✓	6.66E5	1.36E6 ✓	7.96E5	8.33E5 ✓
IV B3	2.07E4	2.35E6 ✓	5.28E5	1.16E6 ✓	9.99E5	9.77E5 ✓
IV B4	9.84E3	1.59E6 ✓	1.25E5	2.27E5 ✓	3.89E5	4.26E5 ✓
IV C1	5.67E3	9.67E5 ✓	1.73E5	3.76E5 ✓	1.34E6	1.16E6 ✓
IV C2	1.34E4	1.81E6 ✓	8.43E5	1.54E6 ✓	1.32E6	1.18E6 ✓
IV C3	1.07E4	1.54E6 ✓	8.66E5	1.48E6 ✓	9.23E5	7.75E5 ✓
IV C4	9.45E3	1.51E6 ✓	7.02E5	1.40E6 ✓	7.10E5	7.80E5 ✓
IV A1	7.31E3	1.01E6 ✓	6.08E5	1.23E6 ✓	8.89E5	9.30E5 ✓
IV A2	7.86E3	1.26E6 ✓	5.77E5	1.25E6 ✓	5.39E5	6.51E5 ✓

SCAN	IA Fluo-3	2A	IA SBFI	2A	IA PBFI	2A
IA1		6.32E4 ✓	3.61E5	4.34E5 ✓	1.55E5	1.65E5 ✓
IA2		1.30E5 ✓	2.71E5	3.27E5 ✓	1.91E5	2.06E5 ✓
IA3		3.06E4 ✓	3.40E5	4.89E5 ✓	2.26E5	3.63E5 ✓
IA4		2.71E4 ✓	2.27E5	3.82E5 ✓	1.32E5	1.62E5 ✓
IB1		1.19E5 ✓	2.56E5	3.66E5 ✓	1.52E5	1.48E5 ✓
IB2		7.38E4 ✓	3.13E5	3.52E5 ✓	1.55E5	1.48E5 ✓
IB3		1.51E5 ✓	1.96E5 IB3	2.86E5 ✓	7.02E4	8.87E4 ✓
IB4		1.42E5 ✓	2.31E5 IB4	2.66E5 ✓	8.10E4	
IC1		1.42E5 ✓	2.07E5 IC1	2.54E5 ✓	3.16E5	7.63E4 ✓
IC2		4.39E4 ✓	3.37E5	4.90E5 ✓	1.56E5	3.02E5 ✓
IC3		1.66E4 ✓	2.08E5	3.20E5 ✓	1.05E5	3.30E5 ✓
IC4		8.68E4 ✓	2.94E5	3.73E5 ✓	1.53E5	1.60E5 ✓
IIA1		7.27E4 ✓	2.64E5	2.97E5 ✓	1.87E5	1.78E5 ✓
IIA2		1.55E5 ✓	1.98E5	2.94E5 ✓	1.01E5	1.19E5 ✓
IIA3		6.52E4 ✓	1.86E5	2.33E5 ✓	3.76E4	4.85E4 ✓
IIA4		1.42E5 ✓	1.94E5	2.12E5 ✓	7.23E4	8.29E4 ✓
IIB1		3.25E4 ✓	4.67E5	1.03E6 ✓	1.67E5	4.35E5 ✓
IIB2		1.65E4 ✓	2.10E5	3.31E5 ✓	4.50E4	7.79E4 ✓
IIB3		7.06E4 ✓	2.39E5	3.00E5 ✓	8.30E4	1.16E5 ✓
IIB4		7.81E4 ✓	4.24E5	4.18E5 ✓	7.64E4	8.79E4 ✓
IIC1		1.78E5 ✓	2.13E5	2.79E5 ✓	9.31E4	1.11E5 ✓
IIC2		4.14E4 ✓	1.96E5	2.34E5 ✓	7.09E4	8.45E4 ✓
IIC3		1.28E5 ✓	7.40E5	6.17E5 ✓	9.01E4	1.22E5 ✓

SCAN	1A F1110-3 2A	1A SBFI 2A	1A PBFI 2A		
IC4	4.10E4✓	4.00E5	6.12E5✓	1.63E5	3.33E5✓
IIA1	2.08E4✓	1.76E5	2.83E5✓	8.45E4	1.77E5✓
IIA2	6.28E4✓	2.10E5	2.81E5✓	7.78E4	1.14E5✓
IIA3	1.14E5✓	2.56E5	2.66E5✓	1.38E5	1.33E5✓
IIA4	1.56E5✓	2.31E5	3.15E5✓	1.05E5	1.20E5✓
IIB1	4.19E4✓	1.41E5	1.66E5✓	4.76E4	5.83E4✓
IIB2	9.94E4✓	1.75E5	2.18E5✓	8.61E4	1.07E5✓
IIB3	3.74E4✓	3.25E5	4.51E5✓	1.18E5	1.87E5✓
IIB4	2.05E4✓	2.31E5	3.57E5✓	6.62E4	1.22E5✓
IC1	9.83E4✓	3.73E5	4.27E5✓	7.39E4	9.90E4✓
IC2	1.26E5✓	2.56E5	3.19E5✓	1.54E5	1.50E5✓
IC3	1.93E5✓	2.68E5	3.27E5✓	9.05E4	1.05E5✓
IIA1	4.62E4✓	2.79E5	3.29E5✓	4.48E4	5.28E4✓
IIA2	1.12E5✓	2.96E5	3.55E5✓	7.45E4	8.76E4✓
IIA3	3.62E4✓	3.10E5	4.56E5✓	1.45E5	2.17E5✓
IIA4	4.61E4✓	3.92E5	5.06E5✓	6.26E4	1.11E5✓
IIB1	1.91E5✓	2.85E5	3.04E5✓	9.79E4	1.24E5✓
IVB2	5.40E4✓	2.27E5	3.05E5✓	1.34E5	1.29E5✓
IIB3	1.83E5✓	1.78E5	2.60E5✓	7.97E4	1.06E5✓
IIB4	8.00E4✓	1.77E5	2.06E5✓	5.09E4	6.40E4✓
IC1	1.61E5✓	6.11E5	5.36E5✓	1.25E5	1.42E5✓
IC2	5.31E4✓	3.65E5	5.73E5✓	1.72E5	4.94E5✓
IC3	3.14E4✓	1.78E5	2.65E5✓	8.93E4	1.40E5✓
IC4	1.42E5✓	1.88E5	2.42E5✓	5.43E4	8.99E4✓
IIA1	1.03E5✓	2.80E5	3.13E5✓	1.34E5	1.43E5✓
IIA2	9.42E4✓	7.67E4	1.05E5✓	8.13E4	9.76E4✓

2/8/96

FETAX experiment with T-BEBC cherry red, T-BEBC cherry green and T-1345-4 green tomatoes. All stocks were 2g/L made 2/8/96. Then 200mg/L stocks were made from the 2g/L stocks. The concentrations were made as follows:

From 2g/L stock:

	ml stock	ml FETAX
2g/L \Rightarrow	10	0
1g/L \Rightarrow	5	5
0.5g/L \Rightarrow	2.5	7.5
0.25g/L \Rightarrow	1.25	8.75

From 200mg/L stock:

	ml stock	ml FETAX
200mg/L \Rightarrow	10	0
100mg/L \Rightarrow	5	5
50mg/L \Rightarrow	2.5	7.5
25mg/L \Rightarrow	1.25	8.75
10mg/L \Rightarrow	0.5	9.5
5mg/L \Rightarrow	0.25	9.75
1mg/L \Rightarrow	0.1	9.9

Digitized on
Disk 225
Saved as
RED2-8-PRN
GREEN2-8-PRN
134562-5-PRN

DISH	CONCENTRATION	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	25	25	25	25	25
2	NC	25	25	25	25	25
3	NC	25	25	25	25	25
4	200mg/L cherry red	25	25	25	25	25
5	"	25	25	24	24	23
6	"	25	25	24	24	23
7	100mg/L cherry red	25	25	22	22	21
8	"	25	25	25	25	24
9	"	25	25	25	25	24
10	50mg/L cherry red	25	25	23	23	23
11	"	25	25	25	25	25
12	"	25	25	23	23	22
13	25mg/L cherry red	25	25	25	25	25
14	"	25	25	24	24	23
15	"	25	25	24	24	24
16	10mg/L cherry red	25	25	25	20	25
17	"	25	25	24	24	24
18	"	25	25	24	23	23
				20	23	23

2/8/96 cont

270

DIS#	CONCEN.	DAY0	DAY1	DAY2	DAY3	DAY4
------	---------	------	------	------	------	------

19	5mg/L cherry red	25	25	25	25	23
20	"	25	25	25	25	25
21	"	25	25	25	24	23
22	1mg/L cherry red	25	25	25	25	25
23	"	25	25	25	25	25
24	"	25	25	25	25	25
25	200mg/L cherry green	25	24	2	2	2
26	"	25	25	1	1	1
27	"	25	25	2	2	2
28	100mg/L cherry green	25	25	23	21	21
29	"	25	25	24	24	24
30	"	25	25	23	21	21
31	50mg/L cherry green	25	25	25	25	25
32	"	25	25	24	21	21
33	"	25	25	24	23	22
34	25mg/L cherry green	25	25	24	24	24
35	"	25	25	23	21	21
36	"	25	25	24	21	20
37	10mg/L cherry green	25	25	25	25	24 25
38	"	25	25	24	24	24
39	"	25	25	26	26	21
40	5mg/L cherry green	25	25	23	23	23
41	"	25	25	25	24	24
42	"	25	25	25	24	24
43	1mg/L cherry green	25	25	25	25	25
44	"	25	25	26	25	25
45	"	25	25	24	24	24
46	200mg/L 1345-4 green	25	25	24	24	24
47	"	25	25	25	25	25
48	"	25	25	25	25	25
49	100mg/L 1345-4 gr.	25	25	24	24	23
50	"	25	25	25	25	24
51	"	25	25	24	24	23
52	50mg/L 1345-4 gr.	25	25	24	23	23
53	"	25	25	25	24	24
54	"	25	25	25	23	23
55	25mg/L 1345-4 gr.	25	25	25	23	22
56	"	25	25	23	22	22
57	"	25	25	25	22	22

2/8/96 con't

271

PSH	CONCENT.	DAY0	DAY1	DAY2	DAY3	DAY4
58	10mg/L 1345-4 green	25	25	24	23-24	24
59	"	25	25	25	22-23	22
60	"	25	25	23	22-23	23
61	5 mg/L 1345-4 green	25	25	25	25	25
62	"	25	25	25	25	25
63	"	25	25	24	24	24
64	1 mg/L 1345-4 green	25	25	23	23	23
65	"	25	25	25	25	25
66	"	25	25	25	25	25
67	NC	25	25	24	24	23
68	NC	25	25	24	24	24
69	NC	25	25	24	23	20
70	2g/L cherry red	25	25	0	0	0
71	"	25	25	0	0	0
72	"	25	25	0	0	0
73	1g/L cherry red	25	25	0	0	0
74	"	25	25	0	0	0
75	"	25	25	0	0	0
76	0.5g/L cherry red	25	25	10	0	0
77	"	25	25	10	9	9
78	"	25	25	1	1	1
79	0.25g/L cherry red	25	25	14	12	12
80	"	25	25	17	16	16
81	"	25	25	16	15 (M ₁)	15
82	NC	25	25	25	23	23
83	NC	25	25	25	25	25
84	NC	25	25	25	25	24
85	2g/L cherry green	25	0	0	0	0
86	"	25	0	0	0	0
87	"	25	0	0	0	0
88	1g/L cherry green	25	0	0	0	0
89	"	25	0	0	0	0
90	"	25	0	0	0	0
91	0.5g/L cherry green	25	0	0	0	0
92	"	25	2	0	0	0
93	"	25	0	0	0	0
94	0.25g/L cherry green	25	19	0	0	0
95	"	25	20	0	0	0
96	"	25	25	0	0	0

2/8/96 Con't

272

154)	CONCENT.	DAY0	DAY1	DAY2	DAY3	DAY4
97	NC	25	25	21	21	21
98	NC	25	25	25	25	25
99	NC	25	25	25	25	24
100	2g/L 1345-4 green	25	25	0	0	0
101	"	25	25	0	0	0
102	"	25	23	0	0	0
103	1g/L 1345-4 green	25	25	0	0	0
104	"	25	25	0	0	0
105	"	25	25	16	1	1
106	.5g/L 1345-4 green	25	25	18	15	15
107	"	25	25	18	17	17
108	"	25	25	23	10	10
109	.25g/L 1345-4 green	25	25	21	22	21
110	"	25	25	21	22	22
111	"	25	25	22	21	21

Done with albinos.

↑
30%
Formalin

Saved as TOMTN2-8.WAI DISK214

2/13/96

Set up FETAX test with α Chac vs. Folic Acid with albinos. α Chac stock was made (50mg/L) today from Mendel's α C from 2-9-96. Folic Acid stock was made today, also (100mg/L). pH's were between 6.0 + 6.5.

10mg/L Folic Acid	=>	1 ml	Folic acid stock
20mg/L "	=>	2 ml	" "
30mg/L "	=>	3 ml	" "
40mg/L "	=>	4 ml	" "
50mg/L "	=>	5 ml	" "
2.5mg/L α Chac	=>	.5 ml	α Chac stock
5 mg/L α Chac	=>	1 ml	α Chac stock
10mg/L α Chac	=>	2 ml	α Chac stock

	CONCEN.	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	25	25	24	24	24
2	NC	25	25	24	24	24
3	10mg/L FA, OAC	25	25	24	24	24
4	"	25	25	25	25	25
5	20mg/L FA, OAC	25	25	24	24	24
6	"	25	25	25	23	23
7	30mg/L FA, OAC	25	25	25	25	25
8	"	25	25	25	25	25
9	40mg/L FA, OAC	25	25	23	23	23
10	"	25	25	25	25	24
11	50mg/L FA, OAC	25	25	24	24	23
12	"	25	25	25	25	25
13	OFA, 2.5mg/L AC	25	25	16	8	7
14	"	25	25	14	14	1
15	10mg/L FA, 2.5mg/L AC	25	25	22	20	18
16	"	25	25	23	16	15
17	20mg/L FA, 2.5mg/L AC	25	25	22	18	17
18	"	25	25	22	20 21	21
19	"	25	24 25	20	20	18
20	30mg/L FA, 2.5mg/L AC	25	25	25	25	25
21	"	25	25	22	17	16
22	"	25	25	24	24	24
23	40mg/L FA, 2.5mg/L AC	25	25	23	21	17
24	"	25	25	25	24	19
25	"	25	25	25	25	23
26	50mg/L FA, 2.5mg/L AC	25	25	24	24	24
27	"	25	25	22	19	18
28	OFA, 5mg/L AC	25	16	0	0	0
29	"	25	21	0	0	0
30	10mg/L FA, 5mg/L AC	25	25	1	0	0
31	"	25	24	2	0	0
32	20mg/L FA, 5mg/L AC	25	25	1	0	0
33	"	25	25	3	0	0
34	"	25	19	3	0	0
35	30mg/L FA, 5mg/L AC	25	25	3	1	0
36	"	25	24	1	0	0
37	"	25	25	1	0	0
38	40mg/L FA, 5mg/L AC	25	25	2	0	0
39	"	25	25	13	16	2

DISH	CONCEN	DAY0	DAY1	DAY2	DAY3	DAY4
40	40mg/L FA, 5mg/L AC	25	25	4	4	0
41	50mg/L FA, 5mg/L AC	25	25	3	2	0
42	"	25	25	3	2	0
43	FA, 10mg/L AC	25	0	0	0	0
44	"	25	0	0	0	0
45	10mg/L FA, 10mg/L AC	25	0	0	0	0
46	"	25	0	0	0	0
47	20mg/L FA, 10mg/L AC	25	0	0	0	0
48	"	25	0	0	0	0
49	"	25	0	0	0	0
50	30mg/L FA, 10mg/L AC	25	0	0	0	0
51	"	25	0	0	0	0
52	"	25	0	0	0	0
53	40mg/L FA, 10mg/L AC	25	0	0	0	0
54	"	25	0	0	0	0
55	"	25	0	0	0	0
56	50mg/L FA, 10mg/L AC	25	0	0	0	0
57	"	25	0	0	0	0

Saved spreadsheet on DISK 214 as DIAC2-13.WAL,
D2AC2-13.WAL, D3AC2-13.WAL, D4AC2-13.WAL.

Digitized on DISK 225 saved as ACFA2-13.PRN

↑
3% Formalin

2/15/96

Set up TMT concentrations with albino embryos. TMT stock was 10mg/L made 2/14/96.

[TMT]	ml TMT stock	ml FTX	
NC	0	10	set up @
0.1mg/L	.1	9.9	1:00 pm.
0.25mg/L	.25	9.75	
0.5mg/L	.5	9.5	15 embryos per
1mg/L	1	9	dish.

2/16/96

From 2/15/96 - put 40 μ l di-4 into each dish of 10 ml of TMT concentrations. Embryos are 24 hr + old. Used 1600 sp. film, 36ex. Stages 26, 27 (approx.). Fluorescence. Embryos incubated for 27 hours in TMT + 2.5 hrs. in di-4.

Pictures	[TMT]	obj.	Exp. time
1	NC	10X	1 sec
2	NC	10X	12 sec - didn't turn out
3	NC	10X	2 sec
4	NC	5X	1 sec
5	NC	5X	2 sec
6	• 1 mg/L	5X	1 sec
7	• 1 mg/L	5X	2 sec
8	• 1 mg/L	10X	1 sec
9	• 1 mg/L	10X	2 sec
10	• 25 μ g/L	10X	1 sec
11	• 25 μ g/L	10X	1 sec - didn't turn out
12	• 25 μ g/L	10X	2 sec
13	• 25 μ g/L	5X	1 sec
14	• 25 μ g/L	5X	2 sec
15	• 5 mg/L	5X	1 sec
16	• 5 mg/L	5X	2 sec
17	• 5 mg/L	10X	1 sec
18	• 5 mg/L	10X	2 sec
19	1 mg/L	10X	1 sec
20	1 mg/L	10X	2 sec
21	1 mg/L	5X	1 sec
22	1 mg/L	5X	2 sec
23	NC	5X	1 sec
24	NC	5X	2 sec
25	NC	10X	1 sec
26	NC	10X	2 sec.

All turned out good!

2/19/96 DISK214

Calculating % Survival with α -Chac +
folic acid data from 2/13/96 pg. 83-85.

DAY 1	0mg/L AC	2.5mg/L AC	5mg/L AC	10mg/L AC
0mg/L FA	100%	100%	74% 100%	0%
10mg/L FA	100%	100%	98%	0%
20mg/L FA	100%	98.7%	92%	0%
30mg/L FA	100%	100%	98.7%	0%
40mg/L FA	100%	100%	100%	0%
50mg/L FA	100%	100%	100%	0%

DAY 2				
0 mg/L FA	96%	60%	0%	0%
10 "	98%	90%	6%	6%
20 "	98%	85.3%	9.3%	0%
30 "	100%	94.7%	6.7%	0%
40 "	96%	97.3%	25.3%	0%
50 "	98%	92%	12%	0%

DAY 3				
0 mg/L FA	96%	44%	0%	0%
10 "	98%	72%	0%	0%
20 "	94%	78.7%	0%	0%
30 "	100%	88%	1.3%	0%
40 "	96%	93.3%	13.3%	0%
50 "	98%	86%	8%	0%

DAY 4				
0 mg/L FA	96%	16%	0%	0%
10 "	98%	66%	0%	0%
20 "	94%	74.6% 74.7%	0%	0%
30 "	100%	86.8% 86.7%	0%	0%
40 "	94%	78.7%	0%	0%
50 "	96%	84%	0%	0%

Graphs on DISK214 saved as DIAC2_13_IPG,
DIAC2_13_IPG, D3_11, D4_11,
COMBO-AC_IPG => 1 page w/ 4 graphs

2/21/96

Tried injecting embryos with 4% Fluro-gold, made up on 1/18/96. Used micro pipet pulled to make microelectrodes. Put on end of nanoject unit + drew Fluro-gold into micro pipet. Injected embryos (hopefully) with this setup. One problem we had ~~is~~ the embryo leaking when the microelectrode ^{was} pulled back out. Tried to see embryos fluorescing under the microscope but we had no luck seeing any fluorescence.

Set up more dishes of TMT. Used albino embryos and same setup as on page 85. Used TMT stock (made 2/14/96) 10mg/L. Embryos were laid 2/21/96. In TMT @ 10:30.

2/22/96

Added 40ul di-4 to embryos in dishes of TMT. (9:15 am) - Did not finish.

3/2/96

Modifications to Chicken data - Days 10 - 40. Spreadsheets are saved on Disk 220 along with graphs (in QuattroPro.)

Changes to:

Cardiac 10 - nothing

20 - Di-4 Column 2A/1A+ ÷ 10

30 - Di-4 Column 2A/1A+ ÷ 100

40 - Di-4 Column 2A/1A+ ÷ 10

3/2/96 continued

Gastronemius 10 - BCECF 2A/1A $\div 10$
 20 - Di-4 column 2A/1A $\div 10$
 30 - Di-4 added 10,500 to 1A and 2A
 then \div column 2A/1A by 10
 40 - Di-4 column 2A/1A $\div 10$

Intestinal 10 - BCECF column 2A/1A $\div 10$
 20 - Di-4 column 2A/1A $\div 10$
 30 - Di-4 added 12,500 to 1A and 2A
 then \div column 2A/1A by 100.
 40 - Di-4 column 2A/1A $\div 10$

Pectoral 10 - BCECF column 2A/1A $\div 10$
 20 - Di-4 column 2A/1A $\div 10$
 30 - added 13,000 to 1A and 2A then
 \div column 2A/1A by 100.
 40 - Di-4 column 2A/1A $\div 10$

Renal 10 - BCECF column 2A/1A $\div 10$
 20 - Di-4 column 2A/1A $\div 10$
 30 - Di-4 added 12,000 to 1A + 2A then
 \div column 2A/1A by 100.
 40 - Di-4 column 2A/1A $\div 10$.

Scrotic 10 - BCECF column 2A/1A $\div 10$
 20 - Di-4 column 2A/1A $\div 10$
 30 - Di-4 " " $\div 100$
 40 - Di-4 " " $\div 10$.

Vagus 10 - nothing
 20 - Di-4 column 2A/1A $\div 10$
 30 - Di-4 " " $\div 100$
 40 - Di-4 " " $\div 10$

NOTE * * Some di-4's were negative so 10,000
 was originally added to all 1A's + 2A's
 of Di-4, then other modifications were
 made.

3/4/96

this test did not
we like - dumped

279

FETAX test using high Folic Acid and
 α -Chaconine (50mg/L stock made 3/4/96) with
 albino embryos. Used Mendel's 2-9-96
 α -Chac. Page 83 has measurement for FA + AC.

ISH	CONCEN.	DAY0	3/5 DAY1	3/6 DAY2	3/7 DAY3	3/8 DAY4
1	NC	25	23	23	23	23
2	NC	25	24	24	24	24
3	NC	25	25	25	25	25
4	10mg/LFA, DAC	25	24	23	23	23
5	"	25	24	24	24	24
6	20mg/LFA, DAC	25	24	24	24	24
7	"	25	25	25	25	25
8	30mg/LFA, DAC	25	25	24.5	24	24
9	"	25	24	23	23	23
10	40mg/LFA, DAC	25	25	25	25	25
11	"	25	24	24	24	24
12	50mg/LFA, DAC	25	25	25	25	25
13	"	25	25	24	24	24
14	0FA, 2.5mg/LAC	25	25	1	1	1
15	"	25	25	15	14	11
16	10mg/LFA, 2.5mg/LAC	25	25	15	7	7
17	"	25	25	6	2	2
18	20mg/LFA, 2.5mg/LAC	25	25	0	0	0
19	"	25	25	2	1	1
20	"	25	25	4	3	3
21	30mg/LFA, 2.5mg/LAC	25	24	11	6	6
22	"	25	25	16	8	5
23	"	25	24	2	1	1
24	40mg/LFA, 2.5mg/LAC	25	25	10	7	5
25	"	25	25	8	7	7
26	"	25	25	6	2	2
27	50mg/LFA, 2.5mg/LAC	25	25	11	6	6
28	"	25	25	3	3	3
29	0FA, 5mg/LAC	25	22	0	0	0
30	"	25	23	0	0	0
31	10FA, 5mg/LAC	25	24	0	0	0
32	"	25	23	0	0	0

3/4/96 cont.

	CONCEN.	DAY0	DAY1	DAY2	DAY3	DAY4
33	20mg/LFA, 5mg/LAC	25	25	0	0	0
34	"	25	25	0	0	0
35	"	25	24	0	0	0
36	30mg/LFA, 5mg/LAC	25	25	0	0	0
37	"	25	24	0	0	0
38	"	25	25	0	0	0
39	40mg/LFA, 5mg/LAC	25	25	0	0	0
40	"	25	25	0	0	0
41	"	25	25	0	0	0
42	50mg/LFA, 5mg/LAC	25	24	1	1	1
43	"	25	25	0	0	0
44	OFA, 10mg/LAC	25	0	0	0	0
45	"	25	0	0	0	0
46	10mg/LFA, 10mg/LAC	25	0	0	0	0
47	"	25	0	0	0	0
48	20mg/LFA, 10mg/LAC	25	0	0	0	0
49	"	25	2	0	0	0
50	"	25	0	0	0	0
51	30mg/LFA, 10mg/LAC	25	5	0	0	0
52	"	25	12	0	0	0
53	"	25	0	0	0	0
54	40mg/LFA, 10mg/LAC	25	0	0	0	0
55	"	25	0	0	0	0
56	"	25	3	0	0	0
57	50mg/LFA, 10mg/LAC	25	1	0	0	0
58	"	25	0	0	0	0

↑
3% formalin

3/5/96

DBK 214

Calculating % Survival with α -Chaconine
and folic acid data from 3/4/96. Pg. 90-91.

DAY1	0mg/L AC	2.5mg/L AC	5mg/L AC	10mg/L AC
0 mg/L FA	96%	100%	90%	90%
10 mg/L FA	96%	100%	94%	0%
20 mg/L FA	98%	100%	98.7%	2.7%
30 mg/L FA	98%	97.3%	98.7%	22.7%
40 mg/L FA	98%	100%	100%	4%
50 mg/L FA	100%	100%	98%	2%

DAY2				
0 mg/L FA	96%	32%	0%	0%
10 "	94%	42%	0%	0%
20 "	98%	8%	0%	0%
30 "	96%	58%	0%	0%
40 "	98%	48%	0%	0%
50 "	94%	28%	2%	0%

DAY3				
0 mg/L FA	96%	30%	0%	0%
10 "	94%	18%	0%	0%
20 "	98%	5.3%	0%	0%
30 "	94%	20%	0%	0%
40 "	98%	21.3%	0%	0%
50 "	98%	18%	2%	0%

DAY4				
0 mg/L FA	96%	24%	0%	0%
10 "	94%	18%	0%	0%
20 "	98%	5.3%	0%	0%
30 "	94%	16%	0%	0%
40 "	98%	18.7%	0%	0%
50 "	98%	18.0%	2%	0%

Spreadsheets saved as DIAC3_4.wb1...

Graphs saved as DIAC3_4.1PG, D2AC3_4.1PG, etc...

Combination graph saved as Combo3_4.1PG

3/5/96

Set up 3 dishes (TMT) for injecting Fluoro-Gold. (NC, 1mg/L TMT, .5mg/L TMT). Put 15 albino embryos (24+hrs old) in each dish. Added 40 μ l di-4 to each dish, also.

Set up camera + intensifier. Tried getting embryos in focus. Need to turn intensifier 3 times counterclockwise in order to get embryos in focus.

3/7/96

Set up FETAX experiment with a Chaconine vs. high Folic Acid. (3rd test). a Chac stock (50mg/L) was made 3/4/96. Folic Acid stock (100mg/L) was made 3/7/96. See page 83 for AC + FA measurements in each dish. Used albino embryos.

Digitized on 2/25/2005
 DISK saved as 7-PRN
 ALFA3-3/7

DISH	Concent.	DAY 0	DAY 1	DAY 2	DAY 3	DAY 4
1	NC	25	24	24	24	24
2	NC	25	25	25	25	25
3	NC	25	25	25	25	25
4	10mg/L FA, OAC	25	25	25	25	25
5	"	25	25	25	25	25
6	20mg/L FA, OAC	25	25	25	25	25
7	"	25	25	25	24	24
8	30mg/L FA, OAC	25	25	25	25	25
9	"	25	25	25	25	25
10	40mg/L FA, OAC	25	25	25	25	25
11	"	25	25	25	25	25
12	50mg/L FA, OAC	25	25	25	25	25
13	"	25	25	25	25	25
14	OFA, 2.5mg/L AC	25	25	25	25	25
15	"	25	25	23	22	20
16	10mg/L FA, 2.5mg/L AC	25	25	25	24	24
17	"	25	25	21	21	21
18	20mg/L FA, 2.5mg/L AC	25	25	24	24	24
19	"	25	25	23	23	23
20	"	25	25	23	23	23

3/7/96 Con't

283

ISH	CONCEN.	DAY0	DAY1	DAY2	DAY3	DAY4
21	30mg/LFA, 2.5mg/LAC	25	25	24	24	24
22	"	25	25	25	24	24
23	"	25	25	24	24	24
24	40mg/LFA, 2.5mg/LAC	25	24	24	24	24
25	"	25	25	25	25	25
26	"	25	25	25	25	25
27	50mg/LFA, 2.5mg/LAC	25	25	25	25	25
28	"	25	25	25	25	25
29	OFA, 5mg/LAC	25	16	5	1	0
30	"	25	17	3	1	1
31	10mg/LAC, 5mg/LAC	25	24	10	5	1
32	"	25	24	17	9	0
33	20mg/LFA, 5mg/LAC	25	24	1	0	0
34	"	25	25	6	3	2
35	"	25	24	13	10	8
36	30mg/LFA, 5mg/LAC	25	25	11	8	6
37	"	25	25	12	10	5
38	"	25	25	18	14	14
39	40mg/LFA, 5mg/LAC	25	25	11	5	3
40	"	25	25	12	11	10
41	"	25	25	13	9	8
42	50mg/LFA, 5mg/LAC	25	25	16	10	7
43	"	25	25	7	2	2
44	OFA, 10mg/LAC	25	0	0	0	0
45	"	25	0	0	0	0
46	10mg/LFA, 10mg/LAC	25	0	0	0	0
47	"	25	0	0	0	0
48	20mg/LFA, 10mg/LAC	25	0	0	0	0
49	"	25	0	0	0	0
50	"	25	0	0	0	0
51	30mg/LFA, 10mg/LAC	25	0	0	0	0
52	"	25	0	0	0	0
53	"	25	0	0	0	0
54	40mg/LFA, 10mg/LAC	25	0	0	0	0
55	"	25	1	0	0	0
56	"	25	0	0	0	0
57	50mg/LFA, 10mg/LAC	25	0	0	0	0
58	"	25	8	0	0	0

spreadsheets saved as DIAC3-7.wal, D2AC3-7.wal, etc...

3/8/96 DISK 214

Calculating % Survival with a Chaconine +
Folic Acid data from 3/7/96. Pg 93-94. (3rd run)

DAY 1	0mg/LAC	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	98.7%	100%	66%	0%
10 "	100%	100%	96%	0%
20 "	100%	100%	97.3%	0%
30 "	100%	100%	100%	0%
40 "	100%	98.7%	100%	1.3%
50 "	100%	100%	100%	16%

DAY 2	0mg/LFA	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	98.7%	96%	16%	0%
10 "	100%	92%	54%	0%
20 "	100%	98.7%	26.7%	0%
30 "	100%	97.3%	54.7%	0%
40 "	100%	98.7%	48%	0%
50 "	100%	100%	46%	0%

DAY 3	0mg/LFA	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	98.7%	94%	4%	0%
10 "	100%	90%	28%	0%
20 "	98%	93.3%	17.3%	0%
30 "	100%	96%	42.7%	0%
40 "	100%	98.7%	33.3%	0%
50 "	100%	100%	24%	0%

DAY 4	0mg/LFA	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	98.7%	90%	2%	0%
10 "	100%	90%	2%	0%
20 "	98%	93.3%	13.3%	0%
30 "	100%	96%	33.3%	0%
40 "	100%	98.7%	28%	0%
50 "	100%	100%	18%	0%

Graphs saved as DIAC 3_7, IPG, DIAC 3_7, IPG, etc...
 Combination graph saved as Combo 3_7, IPG

3/13/96

Dyed daphnia neonates from today in 50 μ l di-4 ANEPSS for approx. 2 hours. Will be looking at them in the new fluorescent wells (black + white) from Nunc.

3/14/96 [TEST A] DISK 214

Set up FGTA experiment w/ a Chaconine vs. high Folic Acid (4th test). Received a Chac from Mendel on 3/13/96. a Chac stock (50mg/L) was made 3/14/96. Folic Acid stock (100mg/L) was made 3/14/96. See page 83 for AC + FA measurements in each dish. Used albino embryos.

DISH	CONCENT.	3/14 DAY 0	3/15 DAY 1	3/16 DAY 2	3/17 DAY 3	3/18 DAY 4
1	NC	25	25	25	22	22
2	NC	25	25	24	23	22
3	NC	25	25	25	25	23
4	OAC, 10mg/L FA	25	25	25	24	24
5	"	25	25	24	23	20
6	OAC, 20mg/L FA	25	24	24	24	24
7	"	25	25	25	23	21
8	OAC, 30mg/L FA	25	25	22	21	20
9	"	25	25	23	23	23
10	OAC, 40mg/L FA	25	25	24	24	24
11	"	25	25	24	22	20
12	OAC, 50mg/L FA	25	25	23	22	21
13	"	25	25	25	25	24
14	2.5mg/L AC, 0 FA	25	25	23	22	20
15	"	25	25	19	10	8
16	2.5 AC, 10 FA	25	25	22	20	16
17	"	25	25	22	13	11
18	2.5 AC, 20 FA	25	25	24	23	22
19	"	25	25	24	24	23
20	"	25	25	21	17	12
21	2.5 AC, 30 FA	25	25	23	22	20
22	"	25	25	21	16	16
23	"	25	25	23	14	11

3/14/96 con't

286

ISH	CONCENT	DAY0	DAY1	DAY2	DAY3	DAY4
24	2.5AL, 40FA	25	25	25	23	22
25	"	25	25	22	20	16
26	"	25	25	24	22	21
27	2.5AL, 50FA	25	25	24	23	22
28	"	25	25	25	22	21
29	5AL, 0FA	25	16	0	0	0
30	"	25	13	0	0	0
31	5AL, 10FA	25	24	3	1	0
32	"	25	20	1	0	0
33	5AL, 20FA	25	25	6	3	0
34	"	25	25	6	0	0
35	"	25	25	8	3	0
36	5AL, 30FA	25	25	6	0	0
37	"	25	23	11	4	0
38	"	25	25	13	7	1
39	5AL, 40FA	25	24	3	0	0
40	"	25	25	7	7	3
41	"	25	24	9	3	2
42	5AL, 50FA	25	25	11	7	4
43	"	25	25	5	1	0
44	10AC, 0FA	25	0	0	0	0
45	"	25	0	0	0	0
46	10AC, 10FA	25	0	0	0	0
47	"	25	0	0	0	0
48	10AC, 20FA	25	0	0	0	0
49	"	25	0	0	0	0
50	"	25	0	0	0	0
51	10AC, 30FA	25	0	0	0	0
52	"	25	0	0	0	0
53	"	25	0	0	0	0
54	10AC, 40FA	25	0	0	0	0
55	"	25	0	0	0	0
56	"	25	0	0	0	0
57	10AC, 50FA	25	0	0	0	0
58	"	25	2	0	0	0

Spreadsheets Saved on Disk 214 as
 DIAC3_14.WQ1, 02AC3_14.WQ1, etc...

Digitized on Disk 225 - saved as ACFA3_14.PRN

↑
 3% formalin

3/15/96

Disk 214B [TESTA]

Calculating % Survival w/ 2 Chac + Foliz
Acid data from 3/14/96, Pg 96-97 (4th run)

DAY1	0mg/LAC	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	100%	100%	58%	0%
10 "	100%	100%	88%	0%
20 "	98%	100%	100%	0%
30 "	100%	100%	97.3%	0%
40 "	100%	100%	97.3%	0%
50 "	100%	100%	100%	4%
		97.3%		

DAY2	0mg/LFA	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	98.7%	84%	0%	0%
10 "	98%	88%	8%	0%
20 "	98%	92%	26.7%	0%
30 "	90%	89.3%	60% 40%	0%
40 "	96%	94.7%	25.3%	0%
50 "	96%	98%	32%	0%

DAY3	0mg/LFA	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	93.3%	64%	0%	0%
10 "	94%	66%	2%	0%
20 "	94%	85.3%	8%	0%
30 "	88%	69.3%	14.7%	0%
40 "	92%	86.7%	13.3%	0%
50 "	94%	90%	16%	0%

DAY4	0mg/LFA	2.5mg/LAC	5mg/LAC	10mg/LAC
0mg/LFA	89.3%	56%	0%	0%
10 "	88%	54%	0.2%	0%
20 "	90%	76%	0%	0%
30 "	86%	66.7%	1.3%	0%
40 "	88%	78.7%	6.7%	0%
50 "	90%	86%	8%	0%

Graphs on Disk 214B saved as: D1AC314A.JPG,
D2AC314A.JPG, etc...

3/14/96 [TEST B] DSK214

Set up a 2nd FETAX experiment. Same exp. as TEST A. Same stock solutions, same embryos. Set up @ 4:00pm

		3/14	3/15	3/16	3/17	3/18
WELL	CONCEN. (mg/L)	DAY0	DAY1	DAY2	DAY3	DAY4
1	NC	25	25	23	23	23
2	NC	25	25	25	24	23
3	NC	25	25	25	24	23
4	OAC, 10FA	25	25	25	24	23
5	"	25	25	24	24	24
6	OAC, 20FA	25	25	24	22	22
7	"	25	25	25	24	21
8	OAC, 30FA	25	25	25	24 25	25
9	"	25	25	25	25	25
10	OAC, 40FA	25	25	25	25	24
11	"	25	25	24	24	24
12	OAC, 50FA	25	25	24 24	23	23
13	"	25	25	25 20	22	21
14	2.5AC, 0FA	25	25	20 7	7	7
15	"	25	25	17 20	12	12
16	2.5AC, 10FA	25	25	20 9	10	7
17	"	25	25	19	15	14
18	2.5AC, 20FA	25	25	25	17	16
19	"	25	25	21	19	17
20	"	25	25	22	13	10
21	2.5AC, 30FA	25	25	23	15	14
22	"	25	25	24	21	20
23	"	25	25	23	15	12
24	2.5AC, 40FA	25	25	25	25	25
25	"	25	25	25	17	13
26	"	25	25	24	20	16
27	2.5AC, 50FA	25	25	22	19	18
28	"	25	25	24	22	19
29	2.5AC, 0FA	25	24	2	0	0
30	"	25	23	0	0	0
31	5AC, 10FA	25	24	1	0	0
32	"	25	24	4	0	0
33		25				
34		25				

	CONCEN	DAY0	DAY1	DAY2	DAY3	DAY4
35	SAC, 20FA	25	25	5	3	3
36	"	25	25	4	2	2
37	"	25	25	1	0	0
38	SAC, 30FA	25	25	7	23	2
39	"	25	25	9	3	0
40	"	25	25	9	0	0
41	SAC, 40FA	25	25	5	4	1
42	"	25	25	10	3	3
43	"	25	25	4	0	0
44	SAC, 50FA	25	25	6	3	1
45	"	25	25	2	1	0
46	IOAC, 0FA	25	0	0	0	0
47	"	25	0	0	0	0
48	IOAC, 10FA	25	0	0	0	0
49	"	25	0	0	0	0
50	IOAC, 20FA	25	0	0	0	0
51	"	25	0	0	0	0
52	IOAC, 30FA	25	0	0	0	0
53	"	25	0	0	0	0
54	IOAC, 40FA	25	0	0	0	0
55	"	25	0	0	0	0
56	"	25	3	0	0	0
57	IOAC, 50FA	25	0	0	0	0
58	"	25	0	0	0	0

Digitized
on Disk 225
Saved as
ACFA314B.PRN

↑
3% formalin

Spread sheets saved on Disk 214 saved as:
D1AC314B.WQ1, D2AC314B.WQ1, D3AC314B.WQ1,
D4AC314B.WQ1